

# **System Management BIOS Reference Specification**

previously known as

**Desktop Management BIOS Specification**

**Version 2.3 — 12 August 1998**

**Co-authored by American Megatrends Inc., Award Software International Inc., Compaq Computer Corporation, Dell Computer Corporation, Hewlett-Packard Company, Intel Corporation, International Business Machines Corporation, Phoenix Technologies Limited, and SystemSoft Corporation.**

This document is provided AS IS for informational purposes only. AMERICAN MEGATRENDS INC., AWARD SOFTWARE INTERNATIONAL INC., COMPAQ COMPUTER CORPORATION, DELL COMPUTER CORPORATION, HEWLETT-PACKARD COMPANY, INTEL CORPORATION, INTERNATIONAL BUSINESS MACHINES CORPORATION, PHOENIX TECHNOLOGIES LIMITED, AND SYSTEMSOFT CORPORATION MAKE NO WARRANTIES, EXPRESS OR IMPLIED, IN THIS DOCUMENT.

American Megatrends Inc., Award Software International Inc., Compaq Computer Corporation, Dell Computer Corporation, Hewlett-Packard Company, Intel Corporation, International Business Machines Corporation, Phoenix Technologies Limited, or SystemSoft Corporation may have patents or pending patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. The furnishing of this document does not give you any license to such patents, trademarks, copyrights, or other intellectual property rights.

AMERICAN MEGATRENDS INC., AWARD SOFTWARE INTERNATIONAL INC., COMPAQ COMPUTER CORPORATION, DELL COMPUTER CORPORATION, HEWLETT-PACKARD COMPANY, INTEL CORPORATION, INTERNATIONAL BUSINESS MACHINES CORPORATION, PHOENIX TECHNOLOGIES LIMITED, AND SYSTEMSOFT CORPORATION DO NOT MAKE ANY REPRESENTATION OR WARRANTY REGARDING SPECIFICATIONS IN THIS DOCUMENT OR ANY PRODUCT OR ITEM DEVELOPED BASED ON THESE SPECIFICATIONS. AMERICAN MEGATRENDS INC., AWARD SOFTWARE INTERNATIONAL INC., COMPAQ COMPUTER CORPORATION, DELL COMPUTER CORPORATION, HEWLETT-PACKARD COMPANY, INTEL CORPORATION, INTERNATIONAL BUSINESS MACHINES CORPORATION, PHOENIX TECHNOLOGIES LIMITED, AND SYSTEMSOFT CORPORATION DISCLAIM ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND FREEDOM FROM INFRINGEMENT. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, AMERICAN MEGATRENDS INC., AWARD SOFTWARE INTERNATIONAL INC., COMPAQ COMPUTER CORPORATION, DELL COMPUTER CORPORATION, HEWLETT-PACKARD COMPANY, INTEL CORPORATION, INTERNATIONAL BUSINESS MACHINES CORPORATION, PHOENIX TECHNOLOGIES LIMITED, AND SYSTEMSOFT CORPORATION DO NOT MAKE ANY WARRANTY OF ANY KIND THAT ANY ITEM DEVELOPED BASED ON THESE SPECIFICATIONS, OR ANY PORTION OF A SPECIFICATION, WILL NOT INFRINGE ANY COPYRIGHT, PATENT, TRADE SECRET OR OTHER INTELLECTUAL PROPERTY RIGHT OF ANY PERSON OR ENTITY IN ANY COUNTRY. IT IS YOUR RESPONSIBILITY TO SEEK LICENSES FOR SUCH INTELLECTUAL PROPERTY RIGHTS WHERE APPROPRIATE. AMERICAN MEGATRENDS INC., AWARD SOFTWARE INTERNATIONAL INC., COMPAQ COMPUTER CORPORATION, DELL COMPUTER CORPORATION, HEWLETT-PACKARD COMPANY, INTEL CORPORATION, INTERNATIONAL BUSINESS MACHINES CORPORATION, PHOENIX TECHNOLOGIES LIMITED, OR SYSTEMSOFT CORPORATION SHALL NOT BE LIABLE FOR ANY DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OF THESE SPECIFICATIONS, INCLUDING LIABILITY FOR LOST PROFIT, BUSINESS INTERRUPTION, OR ANY OTHER DAMAGES WHATSOEVER. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY OR CONSEQUENTIAL OR INCIDENTAL DAMAGES; THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

ActiveMovie, ActiveX, BackOffice, Direct3D, DirectDraw, DirectInput, DirectMusic, DirectPlay, DirectSound, DirectX, Microsoft, NetMeeting, Win32, Windows, and Windows NT are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Intel, Pentium, and MMX are trademarks or registered trademarks of Intel Corporation. \*Other product and company names mentioned herein might be the trademarks of their respective owners.

© 1997, 1998 American Megatrends Inc., Award Software International, Compaq Computer Corporation, Dell Computer Corporation, Hewlett-Packard Company, Intel Corporation, International Business Machines Corporation, Phoenix Technologies Limited, and SystemSoft Corporation. All rights reserved.

## Document Information

The softcopy version of this specification is available from the following World Wide Web locations:

- <http://www.phoenix.com/techs>
- <ftp://download.intel.com/ial/wfm/smbios.pdf>
- <http://www.ibm.com/products/surepath>

## Document Revision History

| Version | Release Date | Description   |
|---------|--------------|---|
| 2.0D    | 09/14/1995   | Initial Release of DRAFT COPY   |
| 2.0M    | 12/12/1995   | Final draft released, with the following changes: <ul style="list-style-type: none"> <li>• Specified that dmiStorageBase (Function 50h) and NVStorageBase (Function 55h) must be paragraph-aligned.</li> <li>• Added Command value to change a string to function 52h; Command enumeration values modified.</li> <li>• Removed redundant enumerations from Processor Family list</li> <li>• Corrected Memory Subsystem Example</li> <li>• Corrected/clarified Indexed I/O access-methods for event-log; Access Method enumeration values and Access Method Address union modified</li> <li>• Added clarifications to some of the event log types</li> </ul>   |
| 2.00    | 03/06/1996   | Final release, with the following changes: <ul style="list-style-type: none"> <li>• Specified that all structures end with a terminating NULL, even if the formatted portion of the structure contains string-reference fields and all the string fields are set to 0.</li> <li>• Corrected the Memory Subsystem Example, handles are now correctly created with a 'dw'.</li> <li>• Fixed formatting of some bit definition fields and function examples.</li> </ul>  |
| 2.00.1  | 07/18/1996   | Minor updates for new technology and clarifications. <ul style="list-style-type: none"> <li>• Added definitions for Pentium® Pro, Burst EDO, and SDRAM.</li> <li>• Added clarifications to the Memory Controller Error Status.</li> </ul>   |
| 2.1     | 06/16/1997   | Added definition for static table interface, to allow the information to be accessed from new operating systems, see <i>2.1 Table Convention</i> on page 9. In addition: <ul style="list-style-type: none"> <li>• Changed references to DMI BIOS to SMBIOS throughout; these changes are unmarked.</li> <li>• Added SubFunction DMI_CLEAR_EVENT_LOG2 to Function 54h - SMBIOS Control.</li> <li>• For those structure entries which are string numbers, changed the Value field definition of the field from Varies to STRING throughout; these changes are unmarked.</li> <li>• BIOS Information structure: Added support for 4-digit year and additional BIOS Characteristics via Characteristics Extension Byte 1.</li> <li>• System Information structure: Added Wakeup Type and UUID fields.</li> <li>• System Enclosure and Chassis structure: Added Bootup State, Power Supply State, Thermal State, and Security Status to allow the DMTF Physical Container Global Table to be populated.</li> <li>• Processor Information structure: Voltage value can now be specified, rather than using bit-flags, and added enumeration values for Pentium® Pro, Pentium® II, and Slot 1. Also added notes to this section, indicating that the enumerated values for the structure are assigned by the DMTF. This structure was also updated to include the Cache Information handles identifying the L1, L2, and L3 caches associated with the processor.</li> <li>• Memory Controller Information structure: Added Enabled Error Correcting field. Also added note that this structure can never be updated to add string values, to preserve backwards compatibility.</li> <li>• Cache Information structure: Added Speed, Error Correction Type, Type, and Associativity fields.</li> <li>• Port Connector Information structure: Added enumerated values to Connector Types and Port Types.</li> <li>• System Slots structure: Added AGP enumeration values to Slot Type field.</li> <li>• BIOS Language Information structure: Added abbreviated-format for language strings and corrected example.</li> <li>• System Event Log structure: OEM-specific Access Methods can now be defined, added standard log header definitions, and a mechanism to allow the log entry's variable data formats to be described. Added note that this structure can never be updated to include string values, to preserve backwards compatibility.</li> <li>• Added Physical Memory Array, Memory Device, Memory Error Information, Memory Array Mapped Address, and Memory Device Mapped Address structures to support the population of the DMTF Enhanced Physical Memory groups.</li> <li>• Added Built-in Pointing Device structure to support the population of the DMTF Pointing Device group.</li> <li>• Added Portable Battery structure to support the population of the DMTF Portable Battery group.</li> <li>• Added appendices that contain a structure checklist and table-convention parsing pseudo-code.</li> </ul> |

| Version | Release Date | Description  |
|---------|--------------|--|
| 2.2     | 03/16/1998   | <p>The following changes were made to v2.1 of the document to produce this version:</p> <ul style="list-style-type: none"> <li>• Accepted all changes introduced at Version 2.1</li> <li>• Added ACPI statement-of-direction for dynamic state and event notification</li> <li>• <u>Table-convention is required for v2.2 and later compliance</u></li> <li>• Corrected Structure Table entry point length value.</li> <li>• Added Command type 06h to the Plug-and-Play Set SMBIOS Structure function (52h).</li> <li>• Added new processor enumerations from the updated DMTF MASTER.MIF</li> <li>• System Enclosure: Added enumeration value for "Sealed-case PC", to support Net PC-type chassis'.</li> <li>• Memory Controller Information: Corrected description of how the BIOS computes the structure Length.</li> <li>• System Event Log: <ul style="list-style-type: none"> <li>• Added definition for end-of-log data, Event Log Type 0FFh.</li> <li>• Added generic system-management event type; the handle of an associated probe or cooling device identifies the specific failing device.</li> </ul> </li> <li>• Memory Error Information: Corrected structure size and offsets.</li> <li>• Portable Battery: Corrected the structure length and some of the offsets, added Smart Battery-formatted fields</li> <li>• Memory Device: Added RIMM form factor</li> <li>• Added the following new structures <ul style="list-style-type: none"> <li>• System Reset structure to support the population of the DMTF Automatic System Reset group.</li> <li>• Hardware Security structure to support the population of the DMTF System Hardware Security group.</li> <li>• System Power Control structure to support the population of the DMTF System Power Control group.</li> <li>• Added Voltage Probe structure to support the population of the DMTF Voltage Probe group.</li> <li>• Cooling Device structure to support the population of the DMTF Cooling Device group.</li> <li>• Temperature Probe structure to support the population of the DMTF Temperature Probe group.</li> <li>• Electrical Current Probe structure to support the population of the DMTF Electrical Current Probe group.</li> <li>• Out-of-Band Remote Access structure to support the population of the DMTF Out-of-Band Remote Access group.</li> <li>• Inactive structure type to support standard structure superset definitions.</li> <li>• End-of-Table structure type to facilitate easier traversing of the structure data.</li> </ul> </li> </ul> |
| 2.3     | 08/12/1998   | <p>The following changes were made to v2.2 of the document to produce this version:</p> <ul style="list-style-type: none"> <li>• Accepted all changes introduced at Version 2.2</li> <li>• Clarified and corrected referenced documents</li> <li>• A minimum set of structures (and their data) is now required for SMBIOS compliance.</li> <li>• Documented an additional structure usage guideline, to optional structure growth.</li> <li>• BIOS Information: <ul style="list-style-type: none"> <li>• 4-digit year format for BIOS Release Date required for SMBIOS 2.3 and later</li> <li>• Added BIOS Characteristic Extension Byte 2 to include status that the BIOS supports the <u>BIOS Boot Specification</u>.</li> </ul> </li> <li>• System Information: Added enumeration for Wake-up Type</li> <li>• System Enclosure or Chassis: Added OEM-defined field.</li> <li>• Processor Information: <ul style="list-style-type: none"> <li>• Added enumerated values for new processors from the updated MASTER.MIF and identified that one structure is present for each processor instance.</li> <li>• Modified interpretation of Lx Cache Handle fields for v2.3 and later implementations</li> </ul> </li> <li>• Memory Module Information: Corrected example, adding double-null to terminate the structure.</li> <li>• System Slots: Added hot-plug characteristic definition and clarified usage of the PCI "Slot ID" field.</li> <li>• Memory Device: <ul style="list-style-type: none"> <li>• Added enumerations for Form Factor and Device Type</li> <li>• Added new field for memory Speed</li> </ul> </li> <li>• System Event Log: Added note describing how century portion of the 2-digit year within a log record is to be interpreted.</li> <li>• Voltage Probe, Temperature Probe, Electrical Current Probe, Cooling Device: <ul style="list-style-type: none"> <li>• Added Nominal Value field</li> </ul> </li> <li>• Added the following new structures <ul style="list-style-type: none"> <li>• Boot Integrity Services (BIS) Entry Point</li> <li>• System Boot Information</li> <li>• 64-bit Memory Error Information</li> <li>• Management Device</li> <li>• Management Device Component</li> <li>• Management Device Threshold Data</li> </ul> </li> </ul>   |

# Table Of Contents

---

|  |           |
|--|-----------|
| <b>1. OVERVIEW</b>   | <b>8</b>  |
| 1.1 STATEMENT OF DIRECTION — DYNAMIC INFORMATION AND EVENTS        | 8         |
| 1.2 REFERENCES   | 8         |
| 1.3 CONVENTIONS USED IN THIS DOCUMENT                              | 8         |
| <b>2. ACCESSING SMBIOS INFORMATION</b>                             | <b>9</b>  |
| 2.1 TABLE CONVENTION   | 9         |
| 2.1.1 SMBIOS STRUCTURE TABLE ENTRY POINT                           | 9         |
| <b>2.2 PLUG-AND-PLAY CALLING CONVENTION</b>                        | <b>10</b> |
| 2.2.1 SMBIOS FUNCTIONS   | 11        |
| 2.2.2 ERROR RETURN CODES   | 12        |
| 2.2.3 SMBIOS STRUCTURE ACCESS INTERFACE                            | 12        |
| 2.2.3.1 Function 50h – Get SMBIOS Information                      | 12        |
| 2.2.3.2 Function 51h – Get SMBIOS Structure                        | 14        |
| 2.2.3.3 Function 52h – Set SMBIOS Structure                        | 15        |
| 2.2.4 STRUCTURE CHANGE NOTIFICATION INTERFACE                      | 17        |
| 2.2.4.1 Function 53h – Get Structure Change Information            | 18        |
| 2.2.5 CONTROL INTERFACE  | 19        |
| 2.2.5.1 Function 54h – SMBIOS Control                              | 19        |
| 2.2.6 GENERAL PURPOSE NONVOLATILE STORAGE INTERFACE                | 21        |
| 2.2.6.1 Function 55H – Get General-Purpose NonVolatile Information | 22        |
| 2.2.6.2 Function 56H – Read General-Purpose NonVolatile Data       | 23        |
| 2.2.6.3 Function 57H – Write General-Purpose NonVolatile Data      | 24        |
| <b>3. SMBIOS STRUCTURES</b>  | <b>25</b> |
| 3.1 STRUCTURE STANDARDS  | 25        |
| 3.1.1 STRUCTURE EVOLUTION AND USAGE GUIDELINES                     | 25        |
| 3.1.2 STRUCTURE HEADER FORMAT                                      | 26        |
| 3.1.3 TEXT STRINGS   | 26        |
| <b>3.2 REQUIRED STRUCTURES AND DATA</b>                            | <b>27</b> |
| <b>3.3 STRUCTURE DEFINITIONS</b>                                   | <b>28</b> |
| 3.3.1 BIOS INFORMATION (TYPE 0)                                    | 28        |
| 3.3.1.1 BIOS Characteristics                                       | 30        |
| 3.3.1.2 BIOS Characteristics Extension Bytes                       | 30        |
| 3.3.2 SYSTEM INFORMATION (TYPE 1)                                  | 31        |
| 3.3.2.1 System — Wake-up Type                                      | 31        |
| 3.3.3 BASE BOARD INFORMATION (TYPE 2)                              | 32        |
| 3.3.4 SYSTEM ENCLOSURE OR CHASSIS (TYPE 3)                         | 32        |
| 3.3.4.1 System Enclosure or Chassis Types                          | 33        |
| 3.3.4.2 System Enclosure or Chassis States                         | 33        |
| 3.3.4.3 System Enclosure or Chassis Security Status                | 33        |
| 3.3.5 PROCESSOR INFORMATION (TYPE 4)                               | 34        |
| 3.3.5.1 Processor Information - Processor Type                     | 35        |
| 3.3.5.2 Processor Information - Processor Family                   | 36        |
| 3.3.5.3 Processor ID Field Format                                  | 37        |

|  |    |
|--|----|
| 3.3.5.4 Processor Information – Voltage                    | 37 |
| 3.3.5.5 Processor Information - Processor Upgrade          | 37 |
| 3.3.6 MEMORY CONTROLLER INFORMATION (TYPE 5)               | 38 |
| 3.3.6.1 Memory Controller Error Detecting Method           | 39 |
| 3.3.6.2 Memory Controller Error Correcting Capability      | 39 |
| 3.3.6.3 Memory Controller Information - Interleave Support | 39 |
| 3.3.6.4 Memory Controller Information - Memory Speeds      | 40 |
| 3.3.7 MEMORY MODULE INFORMATION (TYPE 6)                   | 40 |
| 3.3.7.1 Memory Module Information - Memory Types           | 41 |
| 3.3.7.2 Memory Module Information - Memory Size            | 41 |
| 3.3.7.3 Memory Subsystem Example                           | 42 |
| 3.3.8 CACHE INFORMATION (TYPE 7)                           | 43 |
| 3.3.8.1 Cache Information - SRAM Type                      | 44 |
| 3.3.8.2 Cache Information — Error Correction Type          | 44 |
| 3.3.8.3 Cache Information — System Cache Type              | 45 |
| 3.3.8.4 Cache Information — Associativity                  | 45 |
| 3.3.9 PORT CONNECTOR INFORMATION (TYPE 8)                  | 45 |
| 3.3.9.1 Port Information Example                           | 46 |
| 3.3.9.2 Port Information - Connector Types                 | 46 |
| 3.3.9.3 Port Types   | 47 |
| 3.3.10 SYSTEM SLOTS (TYPE 9)                               | 48 |
| 3.3.10.1 System Slots - Slot Type                          | 48 |
| 3.3.10.2 System Slots - Slot Data Bus Width                | 49 |
| 3.3.10.3 System Slots - Current Usage                      | 49 |
| 3.3.10.4 System Slots - Slot Length                        | 49 |
| 3.3.10.5 System Slots — Slot ID                            | 49 |
| 3.3.10.6 Slot Characteristics 1                            | 50 |
| 3.3.10.7 Slot Characteristics 2                            | 50 |
| 3.3.11 ON BOARD DEVICES INFORMATION (TYPE 10)              | 51 |
| 3.3.11.1 Onboard Device Types                              | 51 |
| 3.3.12 OEM STRINGS (TYPE 11)                               | 52 |
| 3.3.13 SYSTEM CONFIGURATION OPTIONS (TYPE 12)              | 52 |
| 3.3.14 BIOS LANGUAGE INFORMATION (TYPE 13)                 | 53 |
| 3.3.15 GROUP ASSOCIATIONS (TYPE 14)                        | 54 |
| 3.3.16 SYSTEM EVENT LOG (TYPE 15)                          | 55 |
| 3.3.16.1 Supported Event Log Type Descriptors              | 57 |
| 3.3.16.2 Indexed I/O Access Method                         | 57 |
| 3.3.16.3 Access Method Address — DWORD Layout              | 58 |
| 3.3.16.4 Event Log Organization                            | 59 |
| 3.3.16.5 Log Header Format                                 | 59 |
| 3.3.16.6 Log Record Format                                 | 61 |
| 3.3.17 PHYSICAL MEMORY ARRAY (TYPE 16)                     | 64 |
| 3.3.17.1 Memory Array — Location                           | 65 |
| 3.3.17.2 Memory Array — Use                                | 66 |
| 3.3.17.3 Memory Array — Error Correction Types             | 66 |
| 3.3.18 MEMORY DEVICE (TYPE 17)                             | 66 |
| 3.3.18.1 Memory Device — Form Factor                       | 68 |
| 3.3.18.2 Memory Device — Type                              | 68 |
| 3.3.18.3 Memory Device — Type Detail                       | 69 |
| 3.3.19 32-BIT MEMORY ERROR INFORMATION (TYPE 18)           | 69 |
| 3.3.19.1 Memory Error — Error Type                         | 70 |
| 3.3.19.2 Memory Error — Error Granularity                  | 70 |
| 3.3.19.3 Memory Error — Error Operation                    | 70 |
| 3.3.20 MEMORY ARRAY MAPPED ADDRESS (TYPE 19)               | 71 |
| 3.3.21 MEMORY DEVICE MAPPED ADDRESS (TYPE 20)              | 72 |
| 3.3.22 BUILT-IN POINTING DEVICE (TYPE 21)                  | 73 |

|   |           |
|---|-----------|
| 3.3.22.1 Pointing Device — Type   | 74        |
| 3.3.22.2 Pointing Device — Interface  | 74        |
| 3.3.23 PORTABLE BATTERY (TYPE 22)   | 74        |
| 3.3.23.1 Portable Battery — Device Chemistry                                  | 76        |
| 3.3.24 SYSTEM RESET (TYPE 23)   | 77        |
| 3.3.25 HARDWARE SECURITY (TYPE 24)  | 78        |
| 3.3.26 SYSTEM POWER CONTROLS (TYPE 25)  | 79        |
| 3.3.26.1 System Power Controls — Calculating the Next Scheduled Power-on Time | 79        |
| 3.3.27 VOLTAGE PROBE (TYPE 26)  | 80        |
| 3.3.27.1 Voltage Probe — Location and Status                                  | 80        |
| 3.3.28 COOLING DEVICE (TYPE 27)   | 81        |
| 3.3.28.1 Cooling Device — Device Type and Status                              | 82        |
| 3.3.29 TEMPERATURE PROBE (TYPE 28)  | 82        |
| 3.3.29.1 Temperature Probe — Location and Status                              | 83        |
| 3.3.30 ELECTRICAL CURRENT PROBE (TYPE 29)                                     | 83        |
| 3.3.30.1 Current Probe — Location and Status                                  | 84        |
| 3.3.31 OUT-OF-BAND REMOTE ACCESS (TYPE 30)                                    | 85        |
| 3.3.32 BOOT INTEGRITY SERVICES (BIS) ENTRY POINT (TYPE 31)                    | 85        |
| 3.3.33 SYSTEM BOOT INFORMATION (TYPE 32)                                      | 86        |
| 3.3.33.1 System Boot Status   | 86        |
| 3.3.34 64-BIT MEMORY ERROR INFORMATION (TYPE 33)                              | 87        |
| 3.3.35 MANAGEMENT DEVICE (TYPE 34)  | 87        |
| 3.3.35.1 Management Device — Type   | 88        |
| 3.3.35.2 Management Device — Address Type                                     | 88        |
| 3.3.36 MANAGEMENT DEVICE COMPONENT (TYPE 35)                                  | 88        |
| 3.3.37 MANAGEMENT DEVICE THRESHOLD DATA (TYPE 36)                             | 90        |
| 3.3.38 INACTIVE (TYPE 126)  | 90        |
| 3.3.39 END-OF-TABLE (TYPE 127)  | 91        |
| <b>4. STRUCTURE CHECKLIST</b>   | <b>92</b> |
| 4.1 CORRELATION TO DMTF GROUPS  | 92        |
| 4.2 CONFORMANCE GUIDELINES  | 93        |
| <b>5. USING THE TABLE CONVENTION</b>  | <b>97</b> |

# 1. Overview

Desktop Management Interface (DMI) is a method of managing computers in an enterprise. The main component of DMI is the Management Information Format Database, or MIF. This database contains all the information about the computing system and its components. Using DMI, a system administrator can obtain the types, capabilities, operational status, installation date, and other information about the system components.

The *Desktop Management Interface Specification* and its companion `MASTER.MIF` define “manageable attributes that are expected to be supported by DMI-enabled computer systems”. Many of these attributes have no standard interface to the management software, but are known by the system BIOS. The *System Management BIOS Reference Specification* provides that interface via data structures through which the system attributes are reported — see *Accessing SMBIOS Information* on page 9 for the definition of these interfaces.

## 1.1 Statement of Direction — Dynamic Information and Events

The current version of this specification provides an inter-operable method (see *2.1 Table Convention* on page 9) for the access of static system data. A future version of this specification will define methods compatible with the *Automatic Configuration and Power Interface Specification* (ACPI) that provide access to dynamic system data and events.

## 1.2 References

- *Advanced Configuration and Power Interface Specification*, Version 1.0, December 23 1996, <http://www.teleport.com/~acpi>
- *BIOS Boot Specification*, Version 1.01, 11 January 1996, <http://www.phoenix.com/techs/specs.html>
- *Boot Integrity Services API*, Version 1.00, <date TBD>, <http://www.intel.com/ial/wfm/wfmspecs.htm>
- *Desktop Management Interface Specification*, Version 2.0, March 29, 1996, [www.dmtf.org/tech/specs.html](http://www.dmtf.org/tech/specs.html)
- DMTF MASTER.MIF, Version 980518, [www.dmtf.org/tech/apps.html](http://www.dmtf.org/tech/apps.html)
- *DMTF DMI 2.0 Conformance Requirements* Version 1.1, 10 December 1997, [www.dmtf.org/tech/specs.html](http://www.dmtf.org/tech/specs.html)
- *DMTF Mobile Supplement to Standard Groups* Version 1.02, 23 September 1997, [www.dmtf.org/tech/apps.html](http://www.dmtf.org/tech/apps.html)
- *“El Torito” Bootable CD-ROM Format Specification*, Version 1.0, January 25 1995, <http://www.ptltd.com/techs/specs.html>
- *PCI IRQ Routing Table Specification*, Version 1.0, 27 February 1996, <http://www.microsoft.com/hwdev/busbios/PCIIRQ.HTM>
- *Plug and Play BIOS Specification*, Version 1.0A, May 5, 1994, <ftp://ftp.microsoft.com/developr/drg/Plug-and-Play/Pnpspecs/pnpbios.exe>
- *Simple Boot Flag Specification*, Version 1.0, 06 April, 1998, [http://www.microsoft.com/hwdev/desinit/simp\\_bios.htm](http://www.microsoft.com/hwdev/desinit/simp_bios.htm)
- *Smart Battery Data Specification*, Version 1.0, 15 February 1995, [www.sbs-forum.org](http://www.sbs-forum.org)
- *System Standard Groups Definition*, Version 1.0, 1 May 1996, <http://www.dmtf.org/tech/apps.html>

## 1.3 Conventions Used in this Document

1. All numbers specified in this document are in decimal format unless otherwise indicated. A number followed by the letter ‘h’ indicates hexadecimal format; a number followed by the letter ‘b’ indicates binary format.



For example, the values 10, 0Ah, and 1010b are equivalent.

2. Any value not listed in an enumerated list is reserved for future assignment by either this specification or the DMTF (depending on the list-value controlling body).
3. Most of the enumerated values defined in this specification simply track the like values specified by the DMTF — either within the DMTF's *MASTER.MIF* or the *DMTF Mobile Supplement to Standard Groups*. Enumerated values that are controlled by the DMTF are identified within their respective subsection; additional values for these fields are assigned by the DMTF, not this specification.

## 2. Accessing SMBIOS Information

There are two access methods defined for the SMBIOS structures:

1. The first method, defined in v2.0 of this specification, provides the SMBIOS structures through a Plug-and-Play function interface, see 2.2 *Plug-and-Play Calling Convention* on page 10.
2. A table-based method, defined in v2.1 of this specification, provides the SMBIOS structures as a packed list of data referenced by a table entry point; see 2.1 *Table Convention* on page 9.

A BIOS compliant with v2.1 of this specification can provide one or both methods. A BIOS compliant with v2.2 and later of this specification must provide the table-based method and can optionally provide the Plug-and-Play function interface.

**Note:** An SMBIOS implementation that provides only the table-based method might cause some existing DMI browsers to no longer work.

### 2.1 Table Convention

The table convention allows the SMBIOS structures to be accessed under 32-bit protected-mode operating systems such as Microsoft Windows NT\*. This convention provides a searchable entry-point structure that contains a pointer to the packed SMBIOS structures residing somewhere in 32-bit physical address space.

**Note:** The table convention is required for SMBIOS v2.2 and later implementations.

#### 2.1.1 SMBIOS Structure Table Entry Point

The SMBIOS Entry Point structure, described below, can be located by application software by searching for the anchor-string on paragraph (16-byte) boundaries within the physical memory address range 000F0000h to 000FFFFFh. This entry point encapsulates an intermediate anchor string that is used by some existing DMI browsers.

**Note:** While the SMBIOS Major and Minor Versions (offsets 06h and 07h) currently duplicate the information present in the SMBIOS BCD Revision (offset 1Dh), they provide a path for future growth in this specification. The BCD Revision, for example, provides only a single digit for each of the major and minor version numbers.

| Offset | Name                           | Length  | Description   |
|--------|--------------------------------|---------|---|
| 00h    | Anchor String                  | 4 BYTEs | _SM_, specified as four ASCII characters (5F 53 4D 5F).   |
| 04h    | Entry Point Structure Checksum | BYTE    | Checksum of the Entry Point Structure (EPS). This value, when added to all other bytes in the EPS, will result in the value 00h (using 8-bit addition calculations). Values in the EPS are summed starting at offset 00h, for Entry Point Length bytes. |

| Offset    | Name                        | Length  | Description   |
|-----------|-----------------------------|---------|---|
| 05h       | Entry Point Length          | BYTE    | Length of the Entry Point Structure, starting with the Anchor String field, in bytes, currently 1Fh.<br><br><i>Note:</i> This value was incorrectly stated in v2.1 of this specification as 1Eh. Because of this, there might be v2.1 implementations that use either the 1Eh or 1Fh value, but v2.2 or later implementations must use the 1Fh value.         |
| 06h       | SMBIOS Major Version        | BYTE    | Identifies the major version of this specification implemented in the table structures, e.g. the value will be 0Ah for revision 10.22 and 02h for revision 2.1.   |
| 07h       | SMBIOS Minor Version        | BYTE    | Identifies the minor version of this specification implemented in the table structures, e.g. the value will be 16h for revision 10.22 and 01h for revision 2.1.   |
| 08h       | Maximum Structure Size      | WORD    | Size of the largest SMBIOS structure, in bytes, and encompasses the structure's formatted area and text strings. This is the value returned as StructureSize from the Plug-and-Play <i>Get SMBIOS Information</i> function.   |
| 0Ah       | Entry Point Revision        | BYTE    | Identifies the EPS revision implemented in this structure and identifies the formatting of offsets 0Bh to 0Fh, one of:<br>00h Entry Point is based on SMBIOS 2.1 definition, formatted area is reserved and set to all 00h.<br>01h-FFh Reserved for assignment via this specification   |
| 0Bh - 0Fh | Formatted Area              | 5 BYTES | The value present in the Entry Point Revision field defines the interpretation to be placed upon these 5 bytes.   |
| 10h       | Intermediate anchor string  | 5 BYTES | _DMI_, specified as five ASCII characters (5F 44 4D 49 5F).<br><i>Note:</i> This field is paragraph-aligned, to allow legacy DMI browsers to find this entry point within the SMBIOS Entry Point Structure.   |
| 15h       | Intermediate Checksum       | BYTE    | Checksum of Intermediate Entry Point Structure (IEPS). This value, when added to all other bytes in the IEPS, will result in the value 00h (using 8-bit addition calculations). Values in the IEPS are summed starting at offset 10h, for 0Fh bytes.  |
| 16h       | Structure Table Length      | WORD    | Total length of SMBIOS Structure Table, pointed to by the Structure Table Address, in bytes.  |
| 18h       | Structure Table Address     | DWORD   | The 32-bit physical starting address of the read-only SMBIOS Structure Table, that can start at any 32-bit address. This area contains all of the SMBIOS structures fully packed together. These structures can then be parsed to produce exactly the same format as that returned from a Get SMBIOS Structure function call.                                 |
| 1Ch       | Number of SMBIOS Structures | WORD    | Total number of structures present in the SMBIOS Structure Table. This is the value returned as NumStructures from the Get SMBIOS Information function.   |
| 1Eh       | SMBIOS BCD Revision         | BYTE    | Indicates compliance with a revision of this specification. It is a BCD value where the upper nibble indicates the major version and the lower nibble the minor version. For revision 2.1, the returned value is 21h. If the value is 00h, only the Major and Minor Versions in offsets 6 and 7 of the Entry Point Structure provide the version information. |

## 2.2 Plug-and-Play Calling Convention

To prevent the proliferation of interfaces for accessing information embedded in the System BIOS, the *System Management BIOS Reference Specification* will follow the System Device Node model used by Plug and Play, and use Plug and Play BIOS functions to access DMI information. Plug and Play functions 50h-5Fh have been assigned to the SMBIOS BIOS Interface.

Each of the SMBIOS BIOS Plug-and-Play functions is available both in real-mode and 16-bit protected-mode. A function called in 16-bit protected-mode supports both 16-bit and 32-bit stack segments.

## 2.2.1 SMBIOS Functions

This table defines the current SMBIOS Functions.

| SMBIOS Function               | Function Number | Description  | Required/Optional  |
|-------------------------------|-----------------|--|--|
| GET_DMI_INFORMATION           | 50h             | Returns the Number of Structures, the Size of the Largest Structure, and the SMBIOS Revision.                                | Required for calling interface                             |
| GET_DMI_STRUCTURE             | 51h             | Copies the information for the specified Structure into the buffer specified by the caller.                                  | Required for calling interface                             |
| SET_DMI_STRUCTURE             | 52h             | Copies the information for the specified SMBIOS structure from the buffer specified by the caller.                           | Optional   |
| GET_DMI_STRUCTURE_CHANGE_INFO | 53h             | Returns the SMBIOS Structure Change Information into a 16-byte buffer specified by the caller.                               | Required for Dynamic Structure-change Notification Support |
| DMI_CONTROL                   | 54h             | Controls a system action   | Optional   |
| GET_GPNV_INFORMATION          | 55h             | Returns information about the General Purpose Non-Volatile Storage Area  | Required for GPNV Support                                  |
| READ_GPNV_DATA                | 56h             | Reads the entire specified GPNV contents into a buffer specified by the caller.  | Required for GPNV Support                                  |
| WRITE_GPNV_DATA               | 57h             | Copies the contents of the user specified buffer into the GPNV. The function causes the entire specified GPNV to be updated. | Required for GPNV Support                                  |
| Reserved for Future Use       | 58h-5Fh         | Reserved, will return DMI_FUNCTION_NOT_SUPPORTED.  | Reserved   |

## 2.2.2 Error Return Codes

After the call has been made, the following return codes are available in the AX Register.

| Return Code                | Value | Description   |
|----------------------------|-------|---|
| DMI_SUCCESS                | 00h   | Function Completed Successfully   |
| DMI_UNKNOWN_FUNCTION       | 81h   | Unknown, or invalid, function number passed   |
| DMI_FUNCTION_NOT_SUPPORTED | 82h   | The function is not supported on this system  |
| DMI_INVALID_HANDLE         | 83h   | SMBIOS Structure number/handle passed is invalid or out of range.   |
| DMI_BAD_PARAMETER          | 84h   | The function detected invalid parameter or, in the case of a "Set SMBIOS Structure" request, detected an invalid value for a to-be-changed structure field. |
| DMI_INVALID_SUBFUNCTION    | 85h   | The SubFunction parameter supplied on a SMBIOS Control function is not supported by the system BIOS.  |
| DMI_NO_CHANGE              | 86h   | There are no changed SMBIOS structures pending notification.  |
| DMI_ADD_STRUCTURE_FAILED   | 87h   | Returned when there was insufficient storage space to add the desired structure.  |
| DMI_READ_ONLY              | 8Dh   | A "Set SMBIOS Structure" request failed because one or more of the to-be-changed structure fields are read-only.  |
| DMI_LOCK_NOT_SUPPORTED     | 90h   | The GPNV functions do not support locking for the specified GPNV handle.  |
| DMI_CURRENTLY_LOCKED       | 91h   | The GPNV lock request failed - the GPNV is already locked.  |
| DMI_INVALID_LOCK           | 92h   | The caller has failed to present the predefined GPNVLock value which is expected by the BIOS for access of the GPNV area.                                   |

## 2.2.3 SMBIOS Structure Access Interface

### 2.2.3.1 Function 50h – Get SMBIOS Information

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                                /* PnP BIOS Function 50h */
    unsigned char FAR *dmiBIOSRevision,          /* Revision of the SMBIOS Extensions */
    unsigned short FAR *NumStructures,           /* Max. Number of Structures the BIOS will return */
    unsigned short FAR *StructureSize,         /* Size of largest SMBIOS Structure */
    unsigned long FAR *dmiStorageBase,         /* 32-bit physical base address for memory-mapped */
                                                /* SMBIOS data */
    unsigned short FAR *dmiStorageSize,        /* Size of the memory-mapped SMBIOS data */
    unsigned short BiosSelector );             /* PnP BIOS readable/writable selector */
```

#### Description:

*Required for SMBIOS Calling Interface Support.* This function will return the revision of the SMBIOS Extensions and the maximum number of SMBIOS structures that the system BIOS will return information for in *NumStructures*. These structures represent the SMBIOS information that is embedded in the System BIOS. In addition to the number of structures, the system BIOS will return the size, in bytes, of the largest SMBIOS structure (and all of its supporting data) in *StructureSize*. This information can be utilized by the system software to determine the amount of memory required to get all of the SMBIOS structures. **Note:** The system BIOS may return a value that is larger than the actual largest SMBIOS

structure to facilitate hot docking or other dynamic SMBIOS information. The BIOS may also return fewer than *NumStructures* when the structures are retrieved using Function 51h. If the BIOS does not support SMBIOS calling interface capability, DMI\_FUNCTION\_NOT\_SUPPORTED (82h) will be returned.

The *dmiBIOSRevision* parameter indicates compliance with a revision of this specification. It is a BCD value where the upper nibble indicates the major version and the lower nibble the minor version. For revision 2.0 the returned value will be 20h.

*dmiStorageBase* is updated by the BIOS call with the paragraph-aligned, 32-bit absolute physical base address of any memory-mapped SMBIOS structure information. If non-zero, this value allows the caller to construct a 16-bit data segment descriptor with a limit of *dmiStorageSize* and read/write access for subsequent input to functions 51h to 54h. If *dmiStorageBase* is 0, protected-mode mapping is not required.

In addition, *dmiStorageSize* identifies the *dmiWorkBuffer* size for input to function 52h and the *Data* buffer size for function 54h's DMI\_CLEAR\_EVENT\_LOG2 sub-function. **Note:** This feature is SMBIOS version-specific; for v2.0 implementations, the value of *dmiStorageSize* has no meaning if *dmiStorageBase* is 0. In this case, the buffer-sizing is provided by (*NumStructures* \* *StructureSize*).

The *BiosSelector* parameter enables the system BIOS, if necessary, to update system variables that are contained in the system BIOS memory space. If this function is called from protected mode, the caller must create a data segment descriptor using the 16-bit Protected Mode data segment base address specified in the Plug and Play Installation Check data structure, a limit of 64KB, and the descriptor must be read/write capable. If this function is called from real mode, *BiosSelector* should be set to the Real mode 16-bit data segment address as specified in the Plug and Play Installation Check Structure. Refer to section 4.4 of the Plug and Play BIOS Specification revision 1.0a for more information on the Plug and Play Installation Check Structure and the elements that make up the structure.

This function is available in real mode and 16-bit protected mode.

### Returns:

If successful - DMI\_SUCCESS

If an Error (Bit 7 set) or a Warning occurred the Error Code will be returned in AX, the FLAGS and all other registers will be preserved.

### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```

push      BiosSelector
push      segment/selector of dmiStorageSize      ; Pointer to DMISStorageSize
push      offset of dmiStorageSize
push      segment/selector of dmiStorageBase     ; Pointer to DMISStorageBase
push      offset of dmiStorageBase
push      segment/selector of StructureSize      ; Pointer to StructureSize
push      offset of StructureSize
push      segment/selector of NumStructures      ; Pointer to NumStructures
push      offset NumStructures
push      segment/selector of dmiBIOSRevision   ; Pointer to DMIBIOSRevision
push      offset dmiBIOSRevision
push      GET_DMI_INFORMATION                   ; Function number, 50h
call     FAR PTR entryPoint
add      sp, 24                                 ; Clean up stack
cmp     ax, DMI_SUCCESS
jne     error

```

### 2.2.3.2 Function 51h – Get SMBIOS Structure

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 51h */
    unsigned short FAR *Structure, /* Structure number/handle to retrieve*/
    unsigned char FAR *dmiStrucBuffer, /* Pointer to buffer to copy structure data to */
    unsigned short dmiSelector,     /* SMBIOS data read/write selector */
    unsigned short BiosSelector );  /* PnP BIOS readable/writable selector */
```

#### Description:

*Required for SMBIOS Calling Interface Support.* This function will copy the information for the specified SMBIOS Structure into the buffer specified by the caller. The *Structure* argument is a pointer to the unique SMBIOS Structure number (handle). If *Structure* contains zero, the system BIOS will return the first SMBIOS Structure. The *dmiStrucBuffer* argument contains the pointer to the caller's memory buffer. If the function returns either DMI\_SUCCESS or DMI\_INVALID\_HANDLE, *Structure* is updated with either the next sequential structure handle or the end-of-list indicator 0FFFFh.

The protected-mode read/write selector *dmiSelector* has base equal to *dmiStorageBase* and limit of at least *dmiStorageSize* — so long as the *dmiStorageBase* value returned from Function 50h was non-zero.

The *BiosSelector* parameter enables the system BIOS, if necessary, to update system variables that are contained in the system BIOS memory space. If this function is called from protected mode, the caller must create a data segment descriptor using the 16-bit Protected Mode data segment base address specified in the Plug and Play Installation Check data structure, a limit of 64KB, and the descriptor must be read/write capable. If this function is called from real mode, *BiosSelector* should be set to the Real mode 16-bit data segment address as specified in the Plug and Play Installation Check Structure. Refer to section 4.4 of the [Plug and Play BIOS Specification](#) revision 1.0a for more information on the Plug and Play Installation Check Structure and the elements that make up the structure.

This function is available in real mode and 16-bit protected mode.

#### Returns:

If successful - DMI\_SUCCESS

If an Error (Bit 7 set) or a Warning occurred, the Error Code will be returned in AX, the FLAGS and all other registers will be preserved

#### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```
push    BiosSelector
push    dmiSelector
push    segment/selector of dmiStrucBuffer    ; Pointer to dmiStrucBuffer
push    offset of dmiStrucBuffer
push    segment/selector of Structure        ; Pointer to Structure
push    offset of Structure
push    GET_DMI_STRUCTURE                    ; Function number, 51h
call    FAR PTR entryPoint
add     sp, 14                               ; Clean up stack
cmp     ax, DMI_SUCCESS                      ; Function completed successfully?
jne     error
```

### 2.2.3.3 Function 52h – Set SMBIOS Structure

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function, /* PnP BIOS Function 52h */
    unsigned char FAR *dmiDataBuffer, /* Pointer to buffer containing new/change data */
    unsigned char FAR *dmiWorkBuffer, /* Pointer to work buffer area for the BIOS */
    unsigned char Control, /* Conditions for performing operation */
    unsigned short dmiSelector, /* SMBIOS data read/write selector */
    unsigned short BiosSelector ); /* PnP BIOS readable/writeable selector */
```

#### Description:

*Optional.* This function will set the SMBIOS structure identified by the type (and possibly handle) found in the SMBIOS structure header in the buffer pointed to by *dmiDataBuffer*. Values that the BIOS allows to be set in the supplied structure will either be updated by the call, or will cause the BIOS to perform some defined action (such as enabling a hardware option, etc.).

Unless otherwise specified, all structures and structure values defined in Section 3, *SMBIOS Structures*, are read-only and cannot be set. Attempts to set these structures will return a DMI\_READ\_ONLY error. A structure field that is composed of read/write and read-only subfields can still be set -- so long as the read-only portion of the field is unmodified. Attempting to write to a read-only subfield will also cause a DMI\_READ\_ONLY to be returned.

The *dmiDataBuffer* parameter references a structure of the following format:

| Offset | Field              | Length | Description  |
|--------|--------------------|--------|--|
| 00h    | <i>Command</i>     | BYTE   | Identifies the structure-setting operation to be performed, one of: <ul style="list-style-type: none"> <li>00h A single byte of information is to be changed in the structure identified by StructureHeader</li> <li>01h A word (two bytes) of information is to be changed in the structure identified by StructureHeader</li> <li>02h A double-word (four bytes) of information is to be changed in the structure identified by StructureHeader</li> <li>03h The structure identified by StructureHeader is to be added to the SMBIOS structure pool</li> <li>04h The structure identified by StructureHeader is to be deleted from the SMBIOS structure pool</li> <li>05h A string's value is to be changed in the structure identified by StructureHeader.</li> <li>06h A block of information (other than byte, word, or dword in size) is to be changed in the structure identified by StructureHeader.</li> <li>07h-0FFh Reserved for future assignment by this specification.</li> </ul> |
| 01h    | <i>FieldOffset</i> | BYTE   | For a structure change Command, identifies the starting offset within the changed structure's fixed data of the to-be-changed item. For a string-value change Command, identifies the offset within the structure's fixed data associated with the string's "number". This field is ignored for all other Commands.  |
| 02h    | <i>ChangeMask</i>  | DWORD  | For a fixed-length structure-change Command, identifies the ANDing mask to be applied to the existing structure data prior to applying the ChangeValue. The number of significant bytes within this area is defined by the Command. This field is ignored for all other Commands.  |

| Offset | Field                  | Length  | Description   |
|--------|------------------------|---------|---|
| 06h    | <i>ChangeValue</i>     | DWORD   | For a fixed-length structure-change Command, identifies the data value to be ORed with the existing structure data – after applying the <i>ChangeMask</i> . The number of significant bytes within this area is defined by the Command. This field is ignored for all other Commands.   |
| 0Ah    | <i>DataLength</i>      | WORD    | For a structure-add Command, identifies the full length of the to-be-added structure. The length includes the structure header, the fixed-length portion of the structure, and any string data which accompanies the added structure – including all null-terminators. For a string-value change Command, identifies the length of the string data (including the null-terminator); if the length is 1 (indicating that only the null-terminator is provided), the current string's data is deleted so long as the string's data-access rights are met. For a variable-length block change Command, identifies the length of the contiguous data block to be changed. This field is ignored for all other Commands. |
| 0Ch    | <i>StructureHeader</i> | 4 BYTES | Contains the structure header (see <i>Structure Header Format</i> on page 26) of the structure to be added, changed, or deleted.  |
| 10h    | <i>StructureData</i>   | Var     | For a structure-add Command, contains the data to be associated with the SMBIOS Structure identified by the <i>StructureHeader</i> . For a string-value change Command, contains the string's data (the number of characters is identified by <i>DataLength</i> ). For a variable-length block change Command, contains the block's data (the number of bytes is identified by <i>DataLength</i> ). This field is ignored for all other Commands.   |

The *dmiWorkBuffer* parameter references a work buffer for use by the BIOS in performing the request; the contents of the buffer are destroyed by the BIOS' processing. This work buffer must be read/write and sized to hold the entire SMBIOS structure pool, based on the information returned by *Function 50h – Get SMBIOS Information* (see page 12) plus the size of any structure to be added by the request. For SMBIOS v2.0 implementations, the pool size is specified by the maximum of (*StructureSize* \* *NumStructures*) and (when *dmiStorageBase* is non-zero) *dmiStorageSize*; for v2.1 and later implementations, the pool size is specified by *dmiStorageSize*.

The *Control* flag provides a mechanism for indicating to the BIOS whether the set request is to take effect immediately, or if this is a check to validate the to-be-updated data.

*Control* is defined as:

|          |  |
|----------|--|
| Bit 0    | 0 = Do not set the specified structure, but validate its parameters.<br>1 = Set the structure immediately. |
| Bits 1:7 | Reserved, must be 0.   |

If bit 0 of *Control* is 0, then the *dmiDataBuffer* values are checked for validity. If any are not valid, then the function returns *DMI\_BAD\_PARAMETER*; if any read-only field is modified, the function returns *DMI\_READ\_ONLY*. Validity checking is useful to determine if the BIOS supports setting a structure field to a particular value – or whether the BIOS supports writing to a specific structure field. For example, it may be useful for an OEM to determine beforehand whether the OEM's BIOS supports a "Reboot to Diagnostics Now" setting in an OEM-defined structure.

The protected-mode read/write selector *dmiSelector* has base equal to *dmiStorageBase* and a limit of at least *dmiStorageSize*, so long as the *dmiStorageBase* returned from *Function 50h – Get SMBIOS Information* was non-zero.

The *BiosSelector* parameter enables the system BIOS, if necessary, to update system variables that are contained in the system BIOS memory space. If this function is called from protected mode, the caller must create a data segment descriptor using the 16-bit Protected Mode data segment base address specified in the Plug and Play Installation Check data structure, a limit of 64KB, and the descriptor must



be read/write capable. If this function is called from real mode, BiosSelector should be set to the Real mode 16-bit data segment address as specified in the Plug and Play Installation Check Structure. Refer to section 4.4 of the [Plug and Play BIOS Specification](#) revision 1.0a for more information on the Plug and Play Installation Check Structure and the elements that make up the structure.

This function is available in real mode and 16-bit protected mode.

**Note:** If the system BIOS supports structure-change notification, a structure-change event will be issued by the BIOS upon its successful completion of a structure-setting (rather than validation) function call. See *Structure Change Notification Interface* on page 17 for more information.

### Returns:

If successful - DMI\_SUCCESS

If an error occurred, the Error Code will be returned in AX. The FLAGS and all other registers will be preserved.

### Errors:

|                          |   |
|--------------------------|---|
| DMI_BAD_PARAMETER        | A parameter contains an invalid or unsupported value.   |
| DMI_READ_ONLY            | A parameter is read-only and differs from the present value – an attempt was made to modify a read-only value.  |
| DMI_ADD_STRUCTURE_FAILED | The desired structure could not be added due to insufficient storage space.   |
| DMI_INVALID_HANDLE       | For an add (03h) <i>Command</i> , the structure handle present in the <i>StructureHeader</i> already exists or, for a change (00h to 02h and 05h) or delete (04h) <i>Command</i> , the structure handle does not exist. |

### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```

push     BiosSelector
push     dmiSelector
push     Control
push     segment/selector of dmiWorkBuffer      ;pointer to BIOS temporary buffer
push     offset of dmiWorkBuffer
push     segment/selector of dmiDataBuffer     ; pointer to structure
push     offset of dmiDataBuffer
push     SET_DMI_STRUCTURE                     ; Function number, 52h
call     FAR PTR EntryPoint
add     sp, 16                                ; clean stack
cmp     ax, DMI_SUCCESS                       ; Successful?
jne     error                                  ; No, go handle error

```

## 2.2.4 Structure Change Notification Interface

Certain classes of systems may provide the capability for the addition or removal of system devices while the system unit is powered on, such as inserting a Notebook unit into a Docking Station. System BIOS support is necessary for providing SMBIOS Structure Change Notification accessible to system software so that when devices are added or removed the system software will comprehend any changes in the SMBIOS Structures. Structure Change Notification can be implemented as either a polled method or as asynchronous Plug-and-Play events. For information on how Plug-and-Play event notification is accessed, see section 4.6 of the [Plug and Play BIOS Specification](#) revision 1.0a.

When system software is notified on an event by either mechanism, it can then call the BIOS runtime function (Plug and Play BIOS Function 3 - Get Event) to get the type of event. In addition to the events defined in the [Plug and Play BIOS Specification](#), the following event has been defined.

**Note:** Some DMI structure values might be inherently changing (e.g. an OEM-specific structure which returns system temperature and voltage values). Due to the frequency of the values' change, the BIOS might not return Structure Change status for this type of structure.

DMI\_STRUCTURE\_CHANGE\_EVENT            7FFFh

This message indicates that there has been a change in the DMI Information being maintained by the System BIOS. Upon receiving a DMI\_STRUCTURE\_CHANGE\_EVENT, system software can call the BIOS runtime function 53h (Get Structure Change Information) to determine the exact cause of the SMBIOS structure-change event.

### 2.2.4.1 Function 53h – Get Structure Change Information

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 53h */
    unsigned char FAR *dmiChangeStructure, /* Pointer to SMBIOS Change structure */
    unsigned short dmiSelector,    /* SMBIOS data read/write selector */
    unsigned short BiosSelector ); /* PnP BIOS readable/writable selector */
```

#### Description:

*Required for SMBIOS Dynamic Structure Change Notification Support.* This function will allow system software to get information about what type of SMBIOS structure-change occurred. The SMBIOS structure-change information will be returned in the 16-byte memory buffer pointed to by *dmiChangeStructure* in the following format:

| Field                   | Offset  | Length   | Value     |
|-------------------------|---------|----------|-----------|
| SMBIOS Change Status    | 00h     | BYTE     | ENUM      |
| SMBIOS Change Type      | 01h     | BYTE     | Bit Field |
| SMBIOS Structure Handle | 02h     | WORD     | Varies    |
| Reserved                | 04h-0Fh | 12 BYTES | 00h       |

#### SMBIOS Change Status:

00h            No Change  
 01h            Other  
 02h            Unknown  
 03h            Single SMBIOS Structure Affected  
 04h            Multiple SMBIOS Structures Affected  
 05h - 0FFh    Reserved

#### SMBIOS Change Type:

Bit 0            One or more structures was changed, when 1.  
 Bit 1            One or more structures was added, when 1. See “Function 52h – Set DMI Structure” for information about adding SMBIOS structures.  
 Byte 2:7        Reserved, must be 0

If DMI Change Status 03h (Single Structure Affected) is returned, the number (or handle) of the affected structure is present in the "DMI Structure Handle" field; DMI Change Type identifies whether the structure was changed (01h) or added (02h).

If DMI Change Status 04h (Multiple DMI Structures Affected) is returned, the caller must enumerate all the structures to determine what was changed and/or added. DMI Change Type identifies whether multiple structures were changed (01h), multiple structures were added (02h), or structures were both changed and added (03h).

The DMI Change Status Byte remains valid until Function 53h is called. The calling of Function 53h will reset the DMI Change Status Byte to zero. If the call is issued in the absence of a DMI event, the function returns error code 86h (DMI\_NO\_CHANGE).

The protected-mode read/write selector *dmiSelector* has base equal to *dmiStorageBase* and limit of at least *dmiStorageSize* — so long as the *dmiStorageBase* value returned from Function 50h was non-zero.

The *BiosSelector* parameter enables the system BIOS, if necessary, to update system variables that are contained in the system BIOS memory space. If this function is called from protected mode, the caller must create a data segment descriptor using the 16-bit Protected Mode data segment base address specified in the Plug and Play Installation Check data structure, a limit of 64KB, and the descriptor must be read/write capable. If this function is called from real mode, *BiosSelector* should be set to the Real mode 16-bit data segment address as specified in the Plug and Play Installation Check Structure. Refer to section 4.4 of the [Plug and Play BIOS Specification](#) revision 1.0a for more information on the Plug and Play Installation Check Structure and the elements that make up the structure.

This function is available in real mode and 16-bit protected mode.

### Returns:

If successful - DMI\_SUCCESS

If an Error (Bit 7 set) or a Warning occurred the Error Code will be returned in AX, the FLAGS and all other registers will be preserved

### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```

push      BiosSelector
push      dmiSelector
push      segment/selector of dmiChangeStructure
push      offset of dmiChangeStructure
push      GET_DMI_STRUCTURE_CHANGE_INFO           ; Function number, 53h
call      FAR PTR entryPoint
add       sp, 10                                 ; Clean up stack
cmp       ax, DMI_SUCCESS                        ; Function completed successfully?
jne
jne       error

```

## 2.2.5 Control Interface

### 2.2.5.1 Function 54h – SMBIOS Control

#### Synopsis:

```

short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 54h */
    short SubFunction,            /* Defines the specific control operation */
    void FAR *Data,              /* Input/output data buffer, SubFunction specific */
    unsigned char Control,       /* Conditions for setting the structure */
    unsigned short dmiSelector,  /* SMBIOS data read/write selector */
    unsigned short BiosSelector ); /* PnP BIOS readable/writeable selector */

```

#### Description:

*Optional.* This function provides the interface to perform implementation-specific functions for the system, as defined by the *SubFunction* parameter and its (optional) *Data* values.

| SubFunction | Name                | Description   |
|-------------|---------------------|---|
| 0000h       | DMI_CLEAR_EVENT_LOG | Clears the event log as described in <i>System Event Log (Type 15)</i> on page 55. The <i>Data</i> parameter is reserved and must be set to |

| SubFunction | Name                       | Description   |
|-------------|----------------------------|---|
|             |                            | 0.  |
| 0001h       | DMI_CONTROL_LOGGING        | Data points to a 2-word (4-byte) buffer that describes how to control event logging – see 2.2.5.1.1 for bit-wise definitions. The first word (offset 0:1) identifies the ANDing mask to be applied to the existing log-control value prior to ORing the second word (offset 2:3). The second word is modified by the BIOS to contain the log-control value on entry to this function.   |
| 0002h       | DMI_CLEAR_EVENT_LOG2       | Clears the event log as described in <i>System Event Log (Type 15)</i> on page 55. The <i>Data</i> parameter is the 32-bit physical address of a work buffer needed to perform this operation. The buffer must be read/write and sized to hold <i>dmiStorageSize</i> bytes. The contents of the buffer are destroyed by the BIOS' processing. This sub-function is defined for v2.1 and later implementations of this specification and is preferred over the DMI_CLEAR_EVENT_LOG (0000h) sub-function. |
| 0003h-3FFFh | Reserved                   | Reserved for future definition by this specification.   |
| 4000h-7FFFh | Reserved for BIOS vendor   | Available for use by the BIOS vendor.   |
| 8000h-FFFFh | Reserved for system vendor | Available for use by the system vendor.   |

**Note:** A BIOS might support the Log Control function but not support all the *SubFunction* values.

The *Control* flag provides a mechanism for indicating to the BIOS whether the operation is to be performed immediately, or if this is a check to validate the operation's availability and/or data.

*Control* is defined as:

|          |  |
|----------|--|
| Bit 0    | 0 = Do not perform the operation, but validate its parameters.<br>1 = Perform the operation immediately. |
| Bits 1:7 | Reserved, must be 0.   |

If bit 0 of *Control* is 0, then the *SubFunction* and contents of *Data* are checked for validity. If any are not valid, then the function returns DMI\_BAD\_PARAMETER. Validity checking is useful to determine if the BIOS supports a specific DMI Control *SubFunction*.

The protected-mode read/write selector *dmiSelector* has base equal to *dmiStorageBase* and limit of at least *dmiStorageSize* — so long as the *dmiStorageBase* value returned from Function 50h was non-zero.

The *BiosSelector* parameter enables the system BIOS, if necessary, to update system variables that are contained in the system BIOS memory space. If this function is called from protected mode, the caller must create a data segment descriptor using the 16-bit Protected Mode data segment base address specified in the Plug and Play Installation Check data structure, a limit of 64KB, and the descriptor must be read/write capable. If this function is called from real mode, *BiosSelector* should be set to the Real mode 16-bit data segment address as specified in the Plug and Play Installation Check Structure. Refer to section 4.4 of the [Plug and Play BIOS Specification](#) revision 1.0a for more information on the Plug and Play Installation Check Structure and the elements that make up the structure.

This function is available in real mode and 16-bit protected mode.

#### Returns:

If successful - DMI\_SUCCESS

If an error occurred, the Error Code will be returned in AX. The FLAGS and all other registers will be preserved.

#### Errors:

DMI\_BAD\_PARAMETER      The *Data* contents were not valid for the requested *SubFunction*.

DMI\_INVALID\_SUBFUNCTION The *SubFunction* requested is not supported by the system BIOS.

**Example:**

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```

push      BiosSelector
push      dmiSelector
push      Control
push      segment/selector of Data          ; pointer to SubFunction data
push      offset of Data
push      SubFunction
push      DMI_CONTROL                      ; Function number, 54h
call     FAR PTR entryPoint
add      sp, 14                            ; clean stack
cmp      ax, DMI_SUCCESS                   ; Successful?
jne      error                             ; No, go handle error

```

**2.2.5.1.1 DMI\_CONTROL\_LOGGING Control Word**

| Word Bit Position | Meaning if Set  |
|-------------------|---|
| 0                 | Enable Event Logging (overall)                                  |
| 1                 | Enable Correctable Memory Error Events' Logging                 |
| 2                 | Disable the logging of POST errors                              |
| 3 - 15            | Reserved for future assignment by this specification, set to 0. |

**2.2.6 General Purpose Nonvolatile Storage Interface**

A General-Purpose NonVolatile (GPNV) area is a persistent general-purpose storage area managed by the System Management BIOS. Multiple GPNV areas can be supported by a particular BIOS implementation. The size, format and location of a GPNV are not defined by this specification nor is the number of GPNV areas — these attributes are OEM-specific.

A GPNV storage area is not a requirement for a System Management BIOS. It is one method that might be used to store the System Event Log (see section 3.3.16, page 55). A GPNV storage area is not necessarily dedicated to the System Management functions of the BIOS, it can also be used by other services which require non-volatile storage.

A *Handle* parameter is passed into the GPNV function calls to specify which GPNV area is to be accessed. The *Handle* for the first GPNV area is 0, with remaining GPNV areas identified by *Handle* values 1, 2, 3... *n*, where (*n*+1) is the total number of GPNV areas supported by a particular BIOS implementation.

A *GPNVLock* parameter provides a mechanism for cooperative use of the GPNV. The *GPNVLock* value is set on a Read GPNV request (function 56h) and cleared on a Write GPNV request (function 57h). The BIOS compares the value of the *GPNVLock* which is set on a Read GPNV request with the value of the *GPNVLock* passed as a parameter into the GPNV Write request — if they match, the GPNV Write request succeeds and the GPNV data area will be updated on completion of the GPNV Write; if the lock values do not match, the BIOS does not update the GPNV area and DMI\_CURRENTLY\_LOCKED is returned. *Note:* GPNV locks are held until unlocked, even through system power and reboot cycles. The method used to preserve the GPNV Locks through boot cycles is left up to the system designer.

A BIOS might choose to “hide” a GPNV area by defining a special lock value which is required to access the area. In this case, the special *GPNVLock* value must be supplied with the GPNV read and write requests or the function is failed by the BIOS with DMI\_INVALID\_LOCK.

A lock set request *succeeds* when there is no outstanding lock set at the time that the Read GPNV request (Function 56h) is made. A lock set request *fails* when there is already a lock set as the result of

a previous Read GPNV request (which has not yet been cleared with a Function 57h Write GPNV request) or when a predefined lock value is required in order to access a particular GPNV area and the *GPNVLock* value provided by the caller does not match the required value.

The BIOS makes no attempt to enforce mutually-exclusive access to the GPNV — it is up to callers of GPNV Read to ensure unique *GPNVLock* values (e.g. process ID ).

### 2.2.6.1 Function 55H – Get General-Purpose NonVolatile Information

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 55h */
    unsigned short FAR *Handle,    /* Identifies which GPNV to access */
    unsigned short FAR *MinGPNVSize, /* Minimum buffer size in bytes for accessing GPNV */
    unsigned short FAR *GPNVSize,  /* Size allocated for GPNV within the R/W Block */
    unsigned long FAR *NVStorageBase, /* 32-bit physical base address for... */
    /* ... mem. mapped nonvolatile storage media */
    unsigned short BiosSelector ); /* PnP BIOS readable/writable selector */
```

**Description:** *Required for GPNV support.* This function returns information about a General Purpose NonVolatile (GPNV) area. The *Handle* argument is a pointer to a number that identifies which GPNV's information is requested, a value of 0 accesses the first (or only) area.

On return:

- \**Handle* is updated either with the handle of the next GPNV area or, if there are no more areas, 0FFFFh. GPNV handles are assigned sequentially by the system, from 0 to the total number of areas (minus 1).
- \**MinGPNVSize* is updated with the minimum size, in bytes, of any buffer used to access this GPNV area. For a Flash based GPNV area, this would be the size of the Flash block containing the actual GPNV.
- \**GPNVSize* is updated with the size, in bytes, of this GPNV area (which is less than or equal to the *MinGPNVSize* value).
- \**NVStorageBase* is updated with the paragraph-aligned, 32-bit absolute physical base address of this GPNV. If non-zero, this value allows the caller to construct a 16-bit data segment descriptor with a limit of *MinGPNVSize* and read/write access. If the value is 0, protected-mode mapping is not required for this GPNV.

#### Returns:

If successful - DMI\_SUCCESS

If an Error (Bit 7 set) or a Warning occurred the Error Code will be returned in AX, the FLAGS and all other registers will be preserved

#### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```
push    BiosSelector
push    segment/selector of NVStorageBase
push    offset of NVStorageBase
push    segment/selector of GPNVSize
push    offset of GPNVSize
push    segment/selector of MinGPNVSize
push    offset of MinGPNVSize
push    segment/selector of Handle
push    offset of Handle
push    GET_GPNV_INFORMATION          ; Function number, 55h
call    FAR PTR entryPoint
add     sp, 20                        ; Clean up stack
cmp     ax, DMI_SUCCESS               ; Function completed successfully?
jne     error
```

### 2.2.6.2 Function 56H – Read General-Purpose NonVolatile Data

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 56h */
    unsigned short Handle,         /* Identifies which GPNV is to be read */
    unsigned char FAR *GPNVBuffer, /* Address of buffer in which to return GPNV */
    short FAR *GPNVLock,          /* Lock value */
    unsigned short GPNVSelector,  /* Selector for GPNV Storage */
    unsigned short BiosSelector ); /* PnP BIOS readable/writable selector */
```

**Description:** *Required for GPNV support.* This function is used to read an entire GPNV area into the buffer specified by *GPNVBuffer*. It is the responsibility of the caller to ensure that *GPNVBuffer* is large enough to store the entire GPNV storage block - this buffer must be at least the *MinGPNVSize* returned by Function 55h - Get GPNV Information. The *Handle* argument identifies the specific GPNV to be read. On a successful read of a GPNV area, that GPNV area will be placed in the *GPNVBuffer* beginning at offset 0. The protected-mode selector *GPNVSelector* has base equal to *NVStorageBase* and limit of at least *MinGPNVSize* — so long as the *NVStorageBase* value returned from Function 55h was non-zero.

Passing a *GPNVLock* value of -1 to the GPNV Read causes the *GPNVLock* value to be ignored — in this case the underlying logic makes no attempt to store a lock value for comparison with lock values passed into GPNV Write. Any value provided for *GPNVLock* besides -1 is accepted as a valid value for a lock request.

#### Returns:

If the GPNV lock is supported and the lock set request succeeds, the caller's *GPNVLock* is set to the value of the current lock and the function returns DMI\_SUCCESS.

If the GPNV request fails, one of the following values is returned:

- DMI\_LOCK\_NOT\_SUPPORTED
- DMI\_INVALID\_LOCK
- DMI\_CURRENTLY\_LOCKED

For return status codes DMI\_SUCCESS, DMI\_LOCK\_NOT\_SUPPORTED and DMI\_CURRENTLY\_LOCKED, the GPNV Read function returns the current contents of the GPNV associated with *Handle* as the first *GPNVSize* bytes within *GPNVBuffer*, starting at offset 0. If a lock request fails with DMI\_CURRENTLY\_LOCKED status, the caller's *GPNVLock* will be set to the value of the current lock.

#### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```
push    BiosSelector
push    GPNVSelector
push    segment/selector of GPNVLock
push    offset of GPNVLock
push    segment/selector of GPNVBuffer
push    offset of GPNVBuffer
push    Handle
push    READ_GPNV_DATA           ; Function number, 56h
call    FAR PTR entryPoint
add     sp, 16                   ; Clean up stack
cmp     ax, DMI_SUCCESS          ; Function completed successfully?
jne     error
```

### 2.2.6.3 Function 57H – Write General-Purpose NonVolatile Data

#### Synopsis:

```
short FAR (*entryPoint)(
    short Function,                /* PnP BIOS Function 57h */
    unsigned short Handle,         /* Identifies which GPNV is to be written */
    unsigned char FAR *GPNVBuffer, /* Address of buffer containing complete GPNV to write*/
    short GPNVLock,               /* Lock value */
    unsigned short GPNVSelector,   /* Selector for GPNV Storage */
    unsigned short BiosSelector ); /* PnP BIOS readable/writable selector */
```

**Description:** *Required for GPNV support.* This function is used to write an entire GPNV from the *GPNVBuffer* into the nonvolatile storage area. The *Handle* argument identifies the specific GPNV to be written. The protected-mode selector *GPNVSelector* has base equal to *NVStorageBase* and limit of at least *MinGPNVRWSize* — so long as the *NVStorageBase* value returned from *Get GPNV Information* was non-zero. The caller should first call *Read GPNV Data* (with a lock) to get the current area contents, modify the data, and pass it into this function — this ensures that the *GPNVBuffer* which is written contains a complete definition for the entire GPNV area. If the BIOS uses some form of block erase device, the caller must also allocate enough buffer space for the BIOS to store all data from the part during the reprogramming operation, not just the data of interest.

The data to be written to the GPNV selected by *Handle* must reside as the first *GPNVSize* bytes of the *GPNVBuffer*. *Note:* The remaining (*MinGPNVRWSize*-*GPNVSize*) bytes of the *GPNVBuffer* area are used as a scratch-area by the BIOS call in processing the write request; the contents of that area of the buffer are destroyed by this function call.

The *GPNVLock* provides a mechanism for cooperative use of the GPNV, and is set during a GPNV Read (Function 56h). If the input *GPNVLock* value is -1 the caller requests a forced write to the GPNV area, ignoring any outstanding *GPNVLock*. If the caller is not doing a forced write, the value passed in *GPNVLock* to the GPNV Write must be the same value as that (set and) returned by a previous GPNV Read (Function 56h).

#### Returns:

The GPNV Write function returns a value of *DMI\_LOCK\_NOT\_SUPPORTED* when a *GPNVLock* value other than -1 is specified and locking is not supported. A return status of *DMI\_CURRENTLY\_LOCKED* indicates that the call has failed due to an outstanding lock on the GPNV area which does not match the caller's *GPNVLock* value. Any outstanding *GPNVLock* value (which was set by a previous *Function 56H – Read General-Purpose NonVolatile Data*) gets cleared on a successful write of the GPNV.

#### Example:

The following example illustrates how the 'C' style call interface could be made from an assembly language module:

```
push    BiosSelector
push    GPNVSelector
push    GPNVLock
push    segment/selector of GPNVBuffer
push    offset of GPNVBuffer
push    Handle
push    WRITE_GPNV_DATA                ; Function number, 57h
call    FAR PTR entryPoint
add     sp, 14                          ; Clean up stack
cmp     ax, DMI_SUCCESS                 ; Function completed successfully?
jne     error
```



## 3. SMBIOS Structures

The total number of structures can be obtained either through the *Get SMBIOS Information* function (see 2.2.3.1 on page 12) or from the SMBIOS Entry Point Structure (see 2.1 *Table Convention* on page 9). The System Information is presented to an application as a set of structures that are obtained by either calling the *Get SMBIOS Structure* function once per structure (see 2.2.3.2 on page 14) or by traversing the SMBIOS structure table referenced by the SMBIOS Entry Point Structure (see 2.1 *Table Convention* on page 9).

### 3.1 Structure Standards

Each SMBIOS structure has a formatted section and an optional unformatted section. The formatted section of each structure begins with a 4-byte header. Remaining data in the formatted section is determined by the structure type, as is the overall length of the formatted section.

#### 3.1.1 Structure Evolution and Usage Guidelines

As the industry evolves, the structures defined in this specification will evolve. To ensure that the evolution occurs in a nondestructive fashion, the following guidelines must be followed:

1. If a new field is added to an existing structure, that field is added at the end of the formatted area of that structure and the structure's *Length* field is increased by the new field's size.
2. Any software which interprets a structure shall use the structure's *Length* field to determine the formatted area size for the structure rather than hard-coding or deriving the *Length* from a structure field.
3. Each structure shall be terminated by a double-null (0000h), either directly following the formatted area (if no strings are present) or directly following the last string. This includes system- and OEM-specific structures and allows upper-level software to easily traverse the structure table. See below for structure-termination examples.
4. The unformatted section of the structure is used for passing variable data such as text strings, see 3.1.3 *Text Strings* for more information.
5. When an enumerated field's values are controlled by the DMTF, new values can be used as soon as they are defined by the DMTF without requiring an update to this specification.
6. Starting with v2.3, each SMBIOS structure type has a *minimum* length — enabling the addition of new, but optional, fields to SMBIOS structures. In no case shall a structure's length result in a field being less than fully populated. For example, a Voltage Probe structure with *Length* of 15h is invalid since the *Nominal Value* field would not be fully specified.

Software that interprets a structure field must verify that the structure's length is sufficient to encompass the optional field; if the length is insufficient, the optional field's value as *Unknown*. For example, if a Voltage Probe structure has a *Length* field of 14h, the probe's *Nominal Value* is *Unknown*. A Voltage Probe structure with *Length* greater than 14h always includes a *Nominal Value* field.

**Example:** BIOS Information with strings

```

BIOS_InfO      LABEL BYTE
db             0                ; Indicates BIOS Structure Type
db             13h              ; Length of information in bytes
dw             ?                ; Reserved for handle
db             01h              ; String 1 is the Vendor Name
db             02h              ; String 2 is the BIOS version
dw             0E800h           ; BIOS Starting Address
db             03h              ; String 3 is the BIOS Build Date

```

```

db      1                ; Size of BIOS ROM is 128K (64K * (1 + 1))
dq      BIOS_Char        ; BIOS Characteristics
db      0                ; BIOS Characteristics Extension Byte 1
db      `System BIOS Vendor Name`,0 ;
db      `4.04`,0         ;
db      `00/00/0000`,0   ;
db      0                ; End of strings

```

**Example:** BIOS Information without strings (example-only)

```

BIOS_Info LABEL BYTE
db      0                ; Indicates BIOS Structure Type
db      13h             ; Length of information in bytes
dw      ?              ; Reserved for handle
db      00h            ; No Vendor Name provided
db      00h            ; No BIOS version provided
dw      0E800h         ; BIOS Starting Address
db      00h            ; No BIOS Build Date provided
db      1              ; Size of BIOS ROM is 128K (64K * (1 + 1))
dq      BIOS_Char        ; BIOS Characteristics
db      0                ; BIOS Characteristics Extension Byte 1
dw      0000h          ; Structure terminator

```

### 3.1.2 Structure Header Format

Each SMBIOS structure begins with a 4-byte header, as follows:

| Offset | Name   | Length | Description  |
|--------|--------|--------|--|
| 00h    | Type   | BYTE   | Specifies the type of structure. Types 0 through 127 (7Fh) are reserved for and defined by this specification. Types 128 through 256 (80h to FFh) are available for system- and OEM-specific information.  |
| 01h    | Length | BYTE   | Specifies the length of the formatted area of the structure, starting at the Type field. The length of the structure's string-set is <u>not</u> included.  |
| 02h    | Handle | WORD   | Specifies the structure's handle, a unique 16-bit number in the range 0 to 0FFFEh (for version 2.0) or 0 to 0FEFFh (for version 2.1 and later). The handle can be used with the <i>Get SMBIOS Structure</i> function to retrieve a specific structure; the handle numbers are not required to be contiguous. For v2.1 and later, handle values in the range 0FF00h to 0FFFFh are reserved for use by this specification.<br><br>If the system configuration changes, a previously assigned handle might no longer exist. However once a handle has been assigned by the BIOS, the BIOS cannot re-assign that handle number to another structure. |

### 3.1.3 Text Strings

Text strings associated with a given SMBIOS structure are returned in the *dmiStrucBuffer*, appended directly after the formatted portion of the structure. This method of returning string information eliminates the need for application software to deal with pointers embedded in the SMBIOS structure. Each string is terminated with a null (00h) BYTE and the set of strings is terminated with an additional null (00h) BYTE. When the formatted portion of a SMBIOS structure references a string, it does so by specifying a non-zero string number within the structure's string-set. For example, if a string field contains 02h, it references the second string following the formatted portion of the SMBIOS structure. If a string field references no string, a null (0) is placed in that string field. If the formatted portion of the structure contains string-reference fields and all the string fields are set to 0 (no string references), the formatted section of the structure is followed by two null (00h) BYTES. See 3.1.1 *Structure Evolution and Usage Guidelines* on page 25 for a string-containing example.

**Note:** Each text string is limited to 64 significant characters due to system MIF limitations.

## 3.2 Required Structures and Data

Beginning with SMBIOS v2.3, compliant SMBIOS implementations include the following base set of required structures and data within those structures. For a detailed list of conformance guidelines, refer to 4.2 *Conformance Guidelines* on page 93.

| Structure Name and Type         | Data Requirements   |
|---------------------------------|---|
| BIOS Information (Type 0)       | One and only one structure is present in the structure-table. <i>BIOS Version</i> and <i>BIOS Release Date</i> strings are non-null; the date field uses a 4-digit year (e.g. 1999). All other fields reflect full BIOS support information   |
| System Information (Type 1)     | <i>Manufacturer</i> and <i>Product Name</i> strings are non-null. <i>UUID</i> field identifies the system's non-zero UUID value. <i>Wake-up Type</i> field identifies the wake-up source and cannot be <u>Unknown</u> .   |
| System Enclosure (Type 3)       | <i>Manufacturer</i> string is non-null; the <i>Type</i> field identifies the type of enclosure ( <u>Unknown</u> is disallowed).   |
| Processor Information (Type 4)  | One structure is required for each system processor. The presence of two structures with the <i>Processor Type</i> field set to <i>Central Processor</i> , for instance, identifies that the system is capable of dual-processor operations.<br><br><i>Socket Designation</i> string is non-null. <i>Processor Type</i> , <i>Max Speed</i> , and <i>Processor Upgrade</i> fields are all set to "known" values — i.e. the <u>Unknown</u> value is disallowed for each field.<br>If the associated processor is present (i.e. the <i>CPU Socket Populated</i> sub-field of the <i>Status</i> field indicates that the socket is populated), the <i>Processor Manufacturer</i> string is non-null and the <i>Processor Family</i> , <i>Current Speed</i> , and <i>CPU Status</i> sub-field of the <i>Status</i> field are all set to "known" values.<br><br>Each of the <i>Lx Cache Handle</i> fields is either set to 0xFFFF (no further cache description) or references a valid <i>Cache Information Structure</i> . |
| Cache Information (Type 7)      | One structure is required for each external-to-the-processor cache. <i>Socket Designation</i> string is non-null if the cache is external to the processor. If the cache is present (i.e. the <i>Installed Size</i> is non-zero), the <i>Cache Configuration</i> field is set to a "known" value — i.e. the <u>Unknown</u> value is disallowed.   |
| System Slots (Type 9)           | One structure is required for each upgradeable system slot. A structure is not required if the slot must be populated for proper system operation (e.g. the system contains a single memory-card slot).<br><br><i>Slot Designation</i> string is non-null. <i>Slot Type</i> , <i>Slot Data Bus Width</i> , <i>Slot ID</i> , and <i>Slot Characteristics 1 &amp; 2</i> are all set to "known" values.<br><br>If device presence is detectable within the slot (e.g. PCI), the <i>Current Usage</i> field must be set to either <i>Available</i> or <i>In-use</i> . Otherwise (e.g. ISA), the <u>Unknown</u> value for the field is also allowed.   |
| Physical Memory Array (Type 16) | One structure is required for the system memory. <i>Location</i> , <i>Use</i> , <i>Memory Error Correction</i> , and <i>Maximum Capacity</i> are all set to "known" values. <i>Number of Memory Devices</i> is non-zero and identifies the number of <i>Memory Device</i> structures that are associated with this <i>Physical Memory Array</i> .   |

| Structure Name and Type                | Data Requirements  |
|--|--|
| Memory Device (Type 17)                | <p>One structure is required for each socketed system-memory device, whether or not the socket is currently populated; if the system includes soldered system-memory, one additional structure is required to identify that memory device.</p> <p><i>Device Locator</i> string is set to a non-null value. <i>Memory Array Handle</i> contains the handle associated with the <i>Physical Memory Array</i> structure to which this device belongs. <i>Data Width</i>, <i>Size</i>, <i>Form Factor</i>, and <i>Device Set</i> are all set to “known” values. If the device is present (i.e. <i>Size</i> is non-zero), the <i>Total Width</i> field is not set to 0xFFFF (<i>Unknown</i>).</p> |
| Memory Array Mapped Address (Type 19)  | <p>One structure is required for each contiguous block of memory addresses mapped to a <i>Physical Memory Array</i>.</p> <p><i>Ending Address</i> is larger than <i>Starting Address</i>. Each structure's address range is unique and non-overlapping. <i>Memory Array Handle</i> references a <i>Physical Memory Array</i> structure. <i>Partition Width</i> is non-zero.</p>  |
| Memory Device Mapped Address (Type 20) | <p>Sufficient structures are required to map all enabled memory devices to their respective memory-array mapped addresses.</p> <p><i>Ending Address</i> is larger than <i>Starting Address</i>. <i>Memory Device Handle</i> references a <i>Memory Device</i> structure. <i>Memory Mapped Address Handle</i> references a <i>Memory Array Mapped Address</i> structure. <i>Partition Row Position</i> is neither 0 nor 0xFF, nor is it greater than the <i>Partition Width</i> of the referenced <i>Memory Array Mapped Address</i> structure. <i>Interleave Position</i> and <i>Interleaved Data Depth</i> are not set to 0xFF (<i>Unknown</i>).</p>  |
| System Boot Information (Type 32)      | <p>The structure's length is at least 0x0B, i.e. at least one byte of <i>System Boot Status</i> is provided</p>  |

### 3.3 Structure Definitions

#### 3.3.1 BIOS Information (Type 0)

| Offset | Name                          | Length | Value  | Description   |
|--------|-------------------------------|--------|--------|---|
| 00h    | Type                          | BYTE   | 0      | BIOS Information Indicator  |
| 01h    | Length                        | BYTE   | Varies | 12h + number of <i>BIOS Characteristics Extension</i> Bytes. If no Extension Bytes are used the Length will be 12h. For v2.1 and v2.2 implementations, the length is 13h since one extension byte is defined. For v2.3 and later implementations, the length is at least 14h since two extension bytes are defined. |
| 02h    | Handle                        | WORD   | Varies |   |
| 04h    | Vendor                        | BYTE   | STRING | String number of the BIOS Vendor's Name   |
| 05h    | BIOS Version                  | BYTE   | STRING | String number of the BIOS Version. This is a free form string which may contain Core and OEM version information.   |
| 06h    | BIOS Starting Address Segment | WORD   | Varies | Segment location of BIOS starting address, e.g.0E800h. Note: The size of the runtime BIOS image can be computed by subtracting the Starting Address Segment from 10000h and multiplying the result by 16.   |

|     |                                      |                    |            |   |
|-----|--------------------------------------|--------------------|------------|---|
| 08h | BIOS Release Date                    | BYTE               | STRING     | String number of the BIOS release date. The date string, if supplied, is in either mm/dd/yy or mm/dd/yyyy format. If the year portion of the string is two digits, the year is assumed to be 19yy.<br><b>Note:</b> The mm/dd/yyyy format is <u>required</u> for SMBIOS version 2.3 and later. |
| 09h | BIOS ROM Size                        | BYTE               | Varies (n) | Size (n) where $64K * (n+1)$ is the size of the <u>physical</u> device containing the BIOS, in bytes  |
| 0Ah | BIOS Characteristics                 | QWORD              | Bit Field  | Defines which functions the BIOS supports. PCI, PCMCIA, Flash, etc. See 3.3.1.1.  |
| 12h | BIOS Characteristics Extension Bytes | Zero or more BYTES | Bit Field  | Optional space reserved for future supported functions. The number of Extension Bytes that are present is indicated by the Length in offset 1 minus 12h. See 3.3.1.2 for extensions defined for v2.1 and later implementations.   |

### 3.3.1.1 BIOS Characteristics

| QWORD Bit Position | Meaning if Set   |
|--------------------|--|
| Bit 0              | Reserved   |
| Bit 1              | Reserved   |
| Bit 2              | Unknown  |
| Bit 3              | BIOS Characteristics Not Supported   |
| Bit 4              | ISA is supported   |
| Bit 5              | MCA is supported   |
| Bit 6              | EISA is supported  |
| Bit 7              | PCI is supported   |
| Bit 8              | PC Card (PCMCIA) is supported  |
| Bit 9              | Plug and Play is supported   |
| Bit 10             | APM is supported   |
| Bit 11             | BIOS is Upgradeable (Flash)  |
| Bit 12             | BIOS shadowing is allowed  |
| Bit 13             | VL-VESA is supported   |
| Bit 14             | ESCD support is available  |
| Bit 15             | Boot from CD is supported  |
| Bit 16             | Selectable Boot is supported   |
| Bit 17             | BIOS ROM is socketed   |
| Bit 18             | Boot From PC Card (PCMCIA) is supported  |
| Bit 19             | EDD (Enhanced Disk Drive) Specification is supported                                       |
| Bit 20             | Int 13h - Japanese Floppy for NEC 9800 1.2mb (3.5", 1k Bytes/Sector, 360 RPM) is supported |
| Bit 21             | Int 13h - Japanese Floppy for Toshiba 1.2mb (3.5", 360 RPM) is supported                   |
| Bit 22             | Int 13h - 5.25" / 360 KB Floppy Services are supported                                     |
| Bit 23             | Int 13h - 5.25" / 1.2MB Floppy Services are supported                                      |
| Bit 24             | Int 13h - 3.5" / 720 KB Floppy Services are supported                                      |
| Bit 25             | Int 13h - 3.5" / 2.88 MB Floppy Services are supported                                     |
| Bit 26             | Int 5h, Print Screen Service is supported  |
| Bit 27             | Int 9h, 8042 Keyboard services are supported   |
| Bit 28             | Int 14h, Serial Services are supported   |
| Bit 29             | Int 17h, Printer Services are supported  |
| Bit 30             | Int 10h, CGA/Mono Video Services are supported   |
| Bit 31             | NEC PC-98  |
| Bits32:47          | Reserved for BIOS Vendor   |
| Bits 48:63         | Reserved for System Vendor   |

### 3.3.1.2 BIOS Characteristics Extension Bytes

**Note:** All Characteristics Extension Bytes are reserved for assignment via this specification.

#### 3.3.1.2.1 BIOS Characteristics Extension Byte 1

This information, available for SMBIOS version 2.1 and later, appears at offset 12h within the BIOS Information structure.

| Byte Bit Position | Meaning if Set          |
|-------------------|-------------------------|
| Bit 0             | ACPI supported          |
| Bit 1             | USB Legacy is supported |
| Bit 2             | AGP is supported        |

| Byte Bit Position | Meaning if Set                    |
|-------------------|-----------------------------------|
| Bit 3             | I2O boot is supported             |
| Bit 4             | LS-120 boot is supported          |
| Bit 5             | ATAPI ZIP Drive boot is supported |
| Bit 6             | 1394 boot is supported            |
| Bit 7             | Smart Battery supported           |

### 3.3.1.2.2 BIOS Characteristics Extension Byte 2

This information, available for SMBIOS version 2.3 and later, appears at offset 13h within the BIOS Information structure.

| Byte Bit Position | Meaning if Set   |
|-------------------|--|
| Bit 0             | <i>BIOS Boot Specification</i> supported               |
| Bits 1:7          | Reserved for future assignment via this specification. |

## 3.3.2 System Information (Type 1)

The information in this structure defines attributes of the overall system and is intended to be associated with the *Component ID* group of the system's MIF.

| Offset | Spec Version | Name          | Length   | Value      | Description  |
|--------|--------------|---------------|----------|------------|--|
| 00h    | 2.0+         | Type          | BYTE     | 1          | Component ID Information Indicator   |
| 01h    | 2.0+         | Length        | BYTE     | 08h or 19h | Length dependent on version supported, 08h for 2.0 or 19h for 2.1 and later.   |
| 02h    | 2.0+         | Handle        | WORD     | Varies     |  |
| 04h    | 2.0+         | Manufacturer  | BYTE     | STRING     | Number of Null terminated string   |
| 05h    | 2.0+         | Product Name  | BYTE     | STRING     | Number of Null terminated string   |
| 06h    | 2.0+         | Version       | BYTE     | STRING     | Number of Null terminated string   |
| 07h    | 2.0+         | Serial Number | BYTE     | STRING     | Number of Null terminated string   |
| 08h    | 2.1+         | UUID          | 16 BYTEs | Varies     | Universal Unique ID number. If the value is all FFh, the ID is not currently present in the system, but is settable. If the value is all 00h, the ID is not present in the system. |
| 18h    | 2.1+         | Wake-up Type  | BYTE     | ENUM       | Identifies the event that caused the system to power up. See 3.3.2.1.  |

### 3.3.2.1 System — Wake-up Type

| Byte Value | Meaning           |
|------------|-------------------|
| 00h        | Reserved          |
| 01h        | Other             |
| 02h        | Unknown           |
| 03h        | APM Timer         |
| 04h        | Modem Ring        |
| 05h        | LAN Remote        |
| 06h        | Power Switch      |
| 07h        | PCI PME#          |
| 08h        | AC Power Restored |

### 3.3.3 Base Board Information (Type 2)

The information in this structure defines attributes of the system's baseboard (also known as the motherboard or planar).

| Offset | Name          | Length | Value  | Description                      |
|--------|---------------|--------|--------|----------------------------------|
| 00h    | Type          | BYTE   | 2      | Base Board Information Indicator |
| 01h    | Length        | BYTE   | 08h    |                                  |
| 02h    | Handle        | WORD   | Varies |                                  |
| 04h    | Manufacturer  | BYTE   | STRING | Number of Null terminated string |
| 05h    | Product       | BYTE   | STRING | Number of Null terminated string |
| 06h    | Version       | BYTE   | STRING | Number of Null terminated string |
| 07h    | Serial Number | BYTE   | STRING | Number of Null terminated string |

### 3.3.4 System Enclosure or Chassis (Type 3)

The information in this structure defines attributes of the system's mechanical enclosure(s). For example, if a system included a separate enclosure for its peripheral devices, two structures would be returned: one for the main, system enclosure and the second for the peripheral device enclosure. The additions to this structure in v2.1 of this specification support the population of the [DMTF|Physical Container Global Table](#) group.

| Offset | Spec Version | Name               | Length | Value  | Description  |
|--------|--------------|--------------------|--------|--------|--|
| 00h    | 2.0+         | Type               | BYTE   | 3      | System Enclosure Indicator   |
| 01h    | 2.0+         | Length             | BYTE   | Varies | 09h for v2.0 implementations; 0Dh for v2.1 and later implementations which don't include <i>OEM-defined</i> ; 11h for v2.3 and later implementations that include <i>OEM-defined</i> . |
| 02h    | 2.0+         | Handle             | WORD   | Varies |  |
| 04h    | 2.0+         | Manufacturer       | BYTE   | STRING | Number of Null terminated string   |
| 05h    | 2.0+         | Type               | BYTE   | Varies | Bit 7 Chassis lock present if 1. Otherwise, either a lock is not present or it is unknown if the enclosure has a lock. Bits 6:0 Enumeration value, see below.                          |
| 06h    | 2.0+         | Version            | BYTE   | STRING | Number of Null terminated string   |
| 07h    | 2.0+         | Serial Number      | BYTE   | STRING | Number of Null terminated string   |
| 08h    | 2.0+         | Asset Tag Number   | BYTE   | STRING | Number of Null terminated string   |
| 09h    | 2.1+         | Bootup State       | BYTE   | ENUM   | Identifies the state of the enclosure when it was last booted. See 3.3.4.2 for definitions.  |
| 0Ah    | 2.1+         | Power Supply State | BYTE   | ENUM   | Identifies the state of the enclosure's power supply (or supplies) when last booted. See 3.3.4.2 for definitions.  |
| 0Bh    | 2.1+         | Thermal State      | BYTE   | ENUM   | Identifies the enclosure's thermal state when last booted. See 3.3.4.2 for definitions.  |
| 0Ch    | 2.1+         | Security Status    | BYTE   | ENUM   | Identifies the enclosure's physical security status when last booted. See 3.3.4.3 for definitions.   |
| 0Dh    | 2.3+         | OEM-defined        | DWORD  | Varies | Contains OEM- or BIOS vendor-specific information.   |



### 3.3.4.1 System Enclosure or Chassis Types

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning               |
|------------|-----------------------|
| 01h        | Other                 |
| 02h        | Unknown               |
| 03h        | Desktop               |
| 04h        | Low Profile Desktop   |
| 05h        | Pizza Box             |
| 06h        | Mini Tower            |
| 07h        | Tower                 |
| 08h        | Portable              |
| 09h        | LapTop                |
| 0Ah        | Notebook              |
| 0Bh        | Hand Held             |
| 0Ch        | Docking Station       |
| 0Dh        | All in One            |
| 0Eh        | Sub Notebook          |
| 0Fh        | Space-saving          |
| 10h        | Lunch Box             |
| 11h        | Main Server Chassis   |
| 12h        | Expansion Chassis     |
| 13h        | SubChassis            |
| 14h        | Bus Expansion Chassis |
| 15h        | Peripheral Chassis    |
| 16h        | RAID Chassis          |
| 17h        | Rack Mount Chassis    |
| 18h        | Sealed-case PC        |

### 3.3.4.2 System Enclosure or Chassis States

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning         |
|------------|-----------------|
| 01h        | Other           |
| 02h        | Unknown         |
| 03h        | Safe            |
| 04h        | Warning         |
| 05h        | Critical        |
| 06h        | Non-recoverable |

### 3.3.4.3 System Enclosure or Chassis Security Status

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                       |
|------------|-------------------------------|
| 01h        | Other                         |
| 02h        | Unknown                       |
| 03h        | None                          |
| 04h        | External interface locked out |
| 05h        | External interface enabled    |

### 3.3.5 Processor Information (Type 4)

The information in this structure defines the attributes of a single processor; a separate structure instance is provided for each system processor socket/slot. For example, a system with an IntelDX2™ processor would have a single structure instance while a system with an IntelSX2™ processor would have a structure to describe the main CPU and a second structure to describe the 80487 co-processor.

**Note:** One structure is provided for each processor instance in a system. For example, a system that supports up to two processors includes two *Processor Information* structures — even if only one processor is currently installed. Software that interprets the SMBIOS information can count the *Processor Information* structures to determine the maximum possible configuration of the system.

| Offset | Spec Version | Name                   | Length | Value  | Description  |
|--------|--------------|------------------------|--------|--------|--|
| 00h    | 2.0+         | Type                   | BYTE   | 4      | Processor Information Indicator  |
| 01h    | 2.0+         | Length                 | BYTE   | Varies | The Length is 1Ah for v2.0 implementations or 20h for v2.1 and later implementations.  |
| 02h    | 2.0+         | Handle                 | WORD   | Varies |  |
| 04h    | 2.0+         | Socket Designation     | BYTE   | STRING | String number for Reference Designation. Example string 'J202',0   |
| 05h    | 2.0+         | Processor Type         | BYTE   | ENUM   | See 3.3.5.1 on page 35   |
| 06h    | 2.0+         | Processor Family       | BYTE   | ENUM   | See 3.3.5.2 on page 36   |
| 07h    | 2.0+         | Processor Manufacturer | BYTE   | STRING | String number of Processor Manufacturer  |
| 08h    | 2.0+         | Processor ID           | QWORD  | Varies | Raw processor identification data. See 3.3.5.3 for details.  |
| 10h    | 2.0+         | Processor Version      | BYTE   | STRING | String number describing the Processor   |
| 11h    | 2.0+         | Voltage                | BYTE   | Varies | See 3.3.5.4.   |
| 12h    | 2.0+         | External Clock         | WORD   | Varies | External Clock Frequency, in MHz. If the value is unknown, the field is set to 0.  |
| 14h    | 2.0+         | Max Speed              | WORD   | Varies | Maximum internal processor speed, as supported by the system. 0E9h for a 233MHz processor. If the value is unknown, the field is set to 0.   |
| 16h    | 2.0+         | Current Speed          | WORD   | Varies | Same format as Max Speed   |
| 18h    | 2.0+         | Status                 | BYTE   | Varies | Bit 7 Reserved, must be 0<br>Bit 6 CPU Socket Populated<br>1 - CPU Socket Populated<br>0 - CPU Socket Unpopulated<br>Bits 5:3 Reserved, must be zero<br>Bits 2:0 CPU Status<br>0h - Unknown<br>1h - CPU Enabled<br>2h - CPU Disabled by User via BIOS Setup<br>3h - CPU Disabled By BIOS (POST Error)<br>4h - CPU is Idle, waiting to be enabled.<br>5-6h - Reserved<br>7h - Other |

| Offset | Spec Version | Name              | Length | Value  | Description   |
|--------|--------------|-------------------|--------|--------|---|
| 19h    | 2.0+         | Processor Upgrade | BYTE   | ENUM   | See 3.3.5.5   |
| 1Ah    | 2.1+         | L1 Cache Handle   | WORD   | Varies | The handle of a Cache Information structure which defines the attributes of the primary (Level 1) cache for this processor. For v2.1 and v2.2 implementations, the value is 0FFFFh if the processor has no L1 cache. For v2.3 and later implementations, the value is 0FFFFh if the Cache Information structure is not provided. <sup>1</sup>   |
| 1Ch    | 2.1+         | L2 Cache Handle   | WORD   | Varies | The handle of a Cache Information structure which defines the attributes of the secondary (Level 2) cache for this processor. For v2.1 and v2.2 implementations, the value is 0FFFFh if the processor has no L2 cache. For v2.3 and later implementations, the value is 0FFFFh if the Cache Information structure is not provided. <sup>1</sup> |
| 1Eh    | 2.1+         | L3 Cache Handle   | WORD   | Varies | The handle of a Cache Information structure which defines the attributes of the tertiary (Level 3) cache for this processor. For v2.1 and v2.2 implementations, the value is 0FFFFh if the processor has no L3 cache. For v2.3 and later implementations, the value is 0FFFFh if the Cache Information structure is not provided. <sup>1</sup>  |

### 3.3.5.1 Processor Information - Processor Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning           |
|------------|-------------------|
| 01h        | Other             |
| 02h        | Unknown           |
| 03h        | Central Processor |
| 04h        | Math Processor    |
| 05h        | DSP Processor     |
| 06h        | Video Processor   |

<sup>1</sup> Beginning with v2.3 implementations, if the *Cache Handle* is 0FFFFh, management software must make no assumptions about the cache's attributes and should report all cache-related attributes as unknown. The definitive absence of a specific cache is identified by referencing a *Cache Information* structure and setting that structure's *Installed Size* field to 0.

### 3.3.5.2 Processor Information - Processor Family

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning   |
|------------|---|
| 01h        | Other   |
| 02h        | Unknown   |
| 03h        | 8086  |
| 04h        | 80286   |
| 05h        | Intel386™ processor                               |
| 06h        | Intel486™ processor                               |
| 07h        | 8087  |
| 08h        | 80287   |
| 09h        | 80387   |
| 0Ah        | 80487   |
| 0Bh        | Pentium® processor Family                         |
| 0Ch        | Pentium® Pro processor                            |
| 0Dh        | Pentium® II processor                             |
| 0Eh        | Pentium® processor with MMX™ technology           |
| 0Fh        | Celeron™ processor                                |
| 10h        | Pentium® II Xeon™ processor                       |
| 11h        | Reserved for specific Pentium® processor versions |
| 12h        | M1 Family   |
| 13h-18h    | Reserved for specific M1 versions                 |
| 19h        | K5 Family   |
| 1Ah-1Fh    | Reserved for specific K5 versions                 |
| 20h        | Power PC Family                                   |
| 21h        | Power PC 601                                      |
| 22h        | Power PC 603                                      |
| 23h        | Power PC 603+                                     |
| 24h        | Power PC 604                                      |
| 30h        | Alpha Family <sup>2</sup>                         |
| 40h        | MIPS Family                                       |
| 50h        | SPARC Family                                      |
| 60h        | 68040 Family                                      |
| 61h        | 68xxx   |
| 62h        | 68000   |
| 63h        | 68010   |
| 64h        | 68020   |
| 65h        | 68030   |
| 70h        | Hobbit Family                                     |
| 80h        | Weitek  |
| 90h        | PA-RISC Family                                    |
| A0h        | V30 Family  |

<sup>2</sup> Some v2.0 specification implementations used *Processor Family* type value 30h to represent a Pentium® Pro processor.

### 3.3.5.3 Processor ID Field Format

The Processor ID field contains processor-specific information which describes the processor's features.

#### 3.3.5.3.1 X86-Class CPUs

For x86 class CPUs, the field's format depends on the processor's support of the CPUID instruction. If the instruction is supported, the *Processor ID* field contains two DWORD-formatted values. The first (offsets 08h-0Bh) is the EAX value returned by a CPUID instruction with input EAX set to 1; the second (offsets 0Ch-0Fh) is the EDX value returned by that instruction.

Otherwise, only the first two bytes of the *Processor ID* field are significant (all others are set to 0) and contain (in WORD-format) the contents of the DX register at CPU reset.

### 3.3.5.4 Processor Information – Voltage

Two forms of information can be specified by the SMBIOS in this field, dependent on the value present in bit 7 (the most-significant bit). If bit 7 is 0 (legacy mode), the remaining bits of the field represent the specific voltages that the processor socket can accept, as follows:

Bit 7 Set to 0, indicating 'legacy' mode for processor voltage

Bits 6:4 Reserved, must be zero

Bits 3:0 *Voltage Capability*. A Set bit indicates that the voltage is supported.

Bit 0 - 5V

Bit 1 - 3.3V

Bit 2 - 2.9V

Bit 3 - Reserved, must be zero.

**Note:** Setting of multiple bits indicates the socket is configurable

If bit 7 is set to 1, the remaining seven bits of the field are set to contain the processor's current *voltage times 10*. For example, the field value for a processor voltage of 1.8 volts would be 92h = 80h + (1.8 \* 10) = 80h + 18 = 80h + 12h.

### 3.3.5.5 Processor Information - Processor Upgrade

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                |
|------------|------------------------|
| 01h        | Other                  |
| 02h        | Unknown                |
| 03h        | Daughter Board         |
| 04h        | ZIF Socket             |
| 05h        | Replaceable Piggy Back |
| 06h        | None                   |
| 07h        | LIF Socket             |
| 08h        | Slot 1                 |
| 09h        | Slot 2                 |

### 3.3.6 Memory Controller Information (Type 5)

The information in this structure defines the attributes of the system's memory controller(s) and the supported attributes of any memory-modules present in the sockets controlled by this controller.

**Note:** This structure, and its companion Memory Module Information (Type 6), are **obsolete** starting with version 2.1 of this specification; the Physical Memory Array (Type 16) and Memory Device (Type 17) structures should be used instead to allow proper population of the DMI 2.0 required groups. BIOS providers might choose to implement both memory description types to allow existing DMI browsers to properly display the system's memory attributes.

| Offset | Spec Version | Name                        | Length | Value      | Description  |
|--------|--------------|-----------------------------|--------|------------|--|
| 00h    | 2.0+         | Type                        | BYTE   | 5          | Memory Controller Indicator  |
| 01h    | 2.0+         | Length                      | BYTE   | Varies     | Computed by the BIOS as either $15 + (2 * x)$ for v2.0 implementations or $16 + (2 * x)$ for v2.1 and later implementations, where $x$ is the value present in offset 0Eh.   |
| 02h    | 2.0+         | Handle                      | WORD   | Varies     |  |
| 04h    | 2.0+         | Error Detecting Method      | BYTE   | ENUM       | See 3.3.6.1  |
| 05h    | 2.0+         | Error Correcting Capability | BYTE   | Bit Field  | See 3.3.6.2  |
| 06h    | 2.0+         | Supported Interleave        | BYTE   | ENUM       | See 3.3.6.3  |
| 07h    | 2.0+         | Current Interleave          | BYTE   | ENUM       | See 3.3.6.3  |
| 08h    | 2.0+         | Maximum Memory Module Size  | BYTE   | Varies (n) | The size of the largest memory module supported (per slot), specified as $n$ , where $2^{**}n$ is the maximum size in MB. The maximum amount of memory supported by this controller is that value times the number of slots, as specified in offset 0Eh of this structure. |
| 09h    | 2.0+         | Supported Speeds            | WORD   | Bit Field  | See 3.3.6.4 for bit-wise descriptions.   |
| 0Bh    | 2.0+         | Supported Memory Types      | WORD   | Bit Field  | See 3.3.7.1 on page 41 for bit-wise descriptions.  |
| 0Dh    | 2.0+         | Memory Module Voltage       | BYTE   | Bit Field  | This field describes the required voltages for each of the memory module sockets controlled by this controller:<br>Bits 7:3 Reserved, must be zero<br>Bit 2 2.9V<br>Bit 1 3.3V<br>Bit 0 5V<br>Note: Setting of multiple bits indicates the sockets are configurable        |

| Offset                 | Spec Version | Name                                  | Length  | Value     | Description  |
|------------------------|--------------|---------------------------------------|---------|-----------|--|
| 0Eh                    | 2.0+         | Number of Associated Memory Slots (x) | BYTE    | Varies    | Defines how many of the <i>Memory Module Information</i> blocks are controlled by this controller.                                 |
| 0Fh to 0Fh + (2*x) - 1 | 2.0+         | Memory Module Configuration Handles   | x WORDs | Varies    | A list of memory information structure handles controlled by this controller. Value in offset 0Eh (x) defines the count.           |
| 0Fh + (2*x)            | 2.1+         | Enabled Error Correcting Capabilities | BYTE    | Bit Field | Identifies the error-correcting capabilities that were enabled when the structure was built. See 3.3.6.2 for bit-wise definitions. |

### 3.3.6.1 Memory Controller Error Detecting Method

| Byte Value | Meaning      |
|------------|--------------|
| 01h        | Other        |
| 02h        | Unknown      |
| 03h        | None         |
| 04h        | 8-bit Parity |
| 05h        | 32-bit ECC   |
| 06h        | 64-bit ECC   |
| 07h        | 128-bit ECC  |
| 08h        | CRC          |

### 3.3.6.2 Memory Controller Error Correcting Capability

| Byte | Bit Position | Meaning                     |
|------|--------------|-----------------------------|
|      | Bit 0        | Other                       |
|      | Bit 1        | Unknown                     |
|      | Bit 2        | None                        |
|      | Bit 3        | Single Bit Error Correcting |
|      | Bit 4        | Double Bit Error Correcting |
|      | Bit 5        | Error Scrubbing             |

### 3.3.6.3 Memory Controller Information - Interleave Support

| Byte Value | Meaning                |
|------------|------------------------|
| 01h        | Other                  |
| 02h        | Unknown                |
| 03h        | One Way Interleave     |
| 04h        | Two Way Interleave     |
| 05h        | Four Way Interleave    |
| 06h        | Eight Way Interleave   |
| 07h        | Sixteen Way Interleave |

### 3.3.6.4 Memory Controller Information - Memory Speeds

This bit-field describes the speed of the memory modules supported by the system.

| Word | Bit Position | Meaning                |
|------|--------------|------------------------|
|      | Bit 0        | Other                  |
|      | Bit 1        | Unknown                |
|      | Bit 2        | 70ns                   |
|      | Bit 3        | 60ns                   |
|      | Bit 4        | 50ns                   |
|      | Bits 5:15    | Reserved, must be zero |

### 3.3.7 Memory Module Information (Type 6)

One *Memory Module Information* structure is included for each memory-module socket in the system. The structure describes the speed, type, size, and error status of each system memory module. The supported attributes of each module are described by the “owning” *Memory Controller Information* structure.

**Note:** This structure, and its companion Memory Controller Information (Type 5), are **obsolete** starting with version 2.1 of this specification; the Physical Memory Array (Type 16) and Memory Device (Type 17) structures should be used instead to allow proper population of the DMI 2.0 required groups. BIOS providers might choose to implement both memory description types to allow existing DMI browsers to properly display the system’s memory attributes.

| Offset | Name                | Length | Value     | Description   |
|--------|---------------------|--------|-----------|---|
| 00h    | Type                | BYTE   | 6         | Memory Module Configuration Indicator   |
| 01h    | Length              | BYTE   | 0Ch       |   |
| 02h    | Handle              | WORD   | Varies    |   |
| 04h    | Socket Designation  | BYTE   | STRING    | String Number for Reference Designation. Example ‘J202’,0   |
| 05h    | Bank Connections    | BYTE   | Varies    | Each nibble indicates a bank (RAS#) connection, 0xF means no connection. Example: If banks 1 & 3 (RAS# 1 & 3) were connected to a SIMM socket the byte for that socket would be 13h. If only bank 2 (RAS 2) were connected the byte for that socket would be 2Fh. |
| 06h    | Current Speed       | BYTE   | Varies    | The speed of the memory module, in ns (e.g. 70d for a 70ns module). If the speed is unknown, the field is set to 0.   |
| 07h    | Current Memory Type | WORD   | Bit Field | See 3.3.7.1   |
| 09h    | Installed Size      | BYTE   | Varies    | See 3.3.7.2   |
| 0Ah    | Enabled Size        | BYTE   | Varies    | See 3.3.7.2   |



| Offset | Name         | Length | Value  | Description  |
|--------|--------------|--------|--------|--|
| 0Bh    | Error Status | BYTE   | Varies | Bits 7:3 Reserved, set to 0's<br>Bit 2 If set, the Error Status information should be obtained from the event log; bits 1 and 0 are reserved.<br>Bit 1 Correctable errors received for the module, if set. This bit will only be reset during a system reset.<br>Bit 0 Uncorrectable errors received for the module, if set. All or a portion of the module has been disabled. This bit is only reset on power-on. |

### 3.3.7.1 Memory Module Information - Memory Types

This bit-field describes the physical characteristics of the memory modules which are supported by (and currently installed in) the system.

| Word Bit Position | Meaning                |
|-------------------|------------------------|
| Bit 0             | Other                  |
| Bit 1             | Unknown                |
| Bit 2             | Standard               |
| Bit 3             | Fast Page Mode         |
| Bit 4             | EDO                    |
| Bit 5             | Parity                 |
| Bit 6             | ECC                    |
| Bit 7             | SIMM                   |
| Bit 8             | DIMM                   |
| Bit 9             | Burst EDO              |
| Bit 10            | SDRAM                  |
| Bits 11:15        | Reserved, must be zero |

### 3.3.7.2 Memory Module Information - Memory Size

The Size fields of the Memory Module Configuration Information structure define the amount of memory currently installed (and enabled) in a memory-module connector.

The *Installed Size* fields identify the size of the memory module which is installed in the socket, as determined by reading and correlating the module's presence-detect information. If the system does not support presence-detect mechanisms, the *Installed Size* field is set to 7Dh to indicate that the installed size is not determinable. The *Enabled Size* field identifies the amount of memory currently enabled for the system's use from the module. If a module is known to be installed in a connector, but all memory in the module has been disabled due to error, the *Enabled Size* field is set to 7Eh.

| Byte Bit Range | Meaning  |
|----------------|--|
| Bits 0:6       | Size (n), where 2**n is the size in MB with three special-case values:<br>7Dh Not determinable (Installed Size only)<br>7Eh Module is installed, but no memory has been enabled<br>7Fh Not installed |
| Bit 7          | Defines whether the memory module has a single- (0) or double-bank (1) connection.   |

### 3.3.7.3 Memory Subsystem Example

A system utilizes a memory controller which supports up to 4-32MB 5V 70ns parity SIMMs. The memory module sockets are used in pairs A1/A2 and B1/B2 to provide a 64-bit data path to the CPU. No mechanism is provided by the system to read the SIMM IDs. RAS-0 and -1 are connected to the front- and back-size banks of the SIMMs in the A1/A2 sockets and RAS-2 and -3 are similarly connected to the B1/B2 sockets. The current installation is an 8MB SIMM in sockets A1 and A2, 16MB total.

---

|    |           |   |
|----|-----------|---|
| db | 5         | ; Memory Controller Information                       |
| db | 23        | ; Length = 15 + 2*4                                   |
| dw | 14        | ; Memory Controller Handle                            |
| db | 4         | ; 8-bit parity error detection                        |
| db | 00000100b | ; No error correction provided                        |
| db | 03h       | ; 1-way interleave supported                          |
| db | 03h       | ; 1-way interleave currently used                     |
| db | 5         | ; Maximum memory-module size supported is 32MB (2**5) |
| dw | 00000100b | ; Only 70ns SIMMs supported                           |
| dw | 00A4h     | ; Standard, parity SIMMs supported                    |
| db | 00000001b | ; 5V provided to each socket                          |
| db | 4         | ; 4 memory-module sockets supported                   |
| dw | 15        | ; 1st Memory Module Handle                            |
| dw | 16        |   |
| dw | 17        |   |
| dw | 18        | ; 4th ...   |
| dw | 0000h     | ; End-of-structure termination                        |

---

|    |           |  |
|----|-----------|--|
| db | 6         | ; Memory Module Information                                |
| db | 0Ch       |  |
| dw | 15        | ; Handle   |
| db | 1         | ; Reference Designation string #1                          |
| db | 01h       | ; Socket connected to RAS-0 and RAS-1                      |
| db | 00000010b | ; Current speed is Unknown, since can't read SIMM IDs      |
| db | 00000100b | ; Upgrade speed is 70ns, since that's all that's supported |
| dw | 00A4h     | ; Current SIMM must be standard parity                     |
| db | 7Dh       | ; Installed size indeterminable (no SIMM IDs)              |
| db | 83h       | ; Enabled size is double-bank 8MB (2**3)                   |
| db | 0         | ; No errors  |
| db | "A1",0    | ; String#1: Reference Designator                           |
| db | 0         | ; End-of-strings   |

---

|    |        |   |
|----|--------|---|
| db | 6      | ; Memory Module Information                           |
| db | 0Ch    |   |
| dw | 16     | ; Handle  |
| db | 1      | ; Reference Designation string #1                     |
| db | 01h    | ; Socket connected to RAS-0 and RAS-1                 |
| db | 0      | ; Current speed is Unknown, since can't read SIMM IDs |
| dw | 00A4h  | ; Current SIMM must be standard parity                |
| db | 7Dh    | ; Installed size indeterminable (no SIMM IDs)         |
| db | 83h    | ; Enabled size is double-bank 8MB (2**3)              |
| db | 0      | ; No errors   |
| db | "A2",0 | ; String#1: Reference Designator                      |
| db | 0      | ; End-of-strings                                      |

---

|    |        |   |
|----|--------|---|
| db | 6      | ; Memory Module Information                           |
| db | 0Ch    |   |
| dw | 17     | ; Handle  |
| db | 1      | ; Reference Designation string #1                     |
| db | 23h    | ; Socket connected to RAS-2 and RAS-3                 |
| db | 0      | ; Current speed is Unknown, since can't read SIMM IDs |
| dw | 0001h  | ; Nothing appears to be installed (Other)             |
| db | 7Dh    | ; Installed size indeterminable (no SIMM IDs)         |
| db | 7Fh    | ; Enabled size is 0 (nothing installed)               |
| db | 0      | ; No errors   |
| db | "B1",0 | ; String#1: Reference Designator                      |
| db | 0      | ; End-of-strings                                      |

---

```

db      6           ; Memory Module Information
db      0Ch
dw      18         ; Handle
db      1           ; Reference Designation string #1
db      23h        ; Socket connected to RAS-2 and RAS-3
db      0           ; Current speed is Unknown, since can't read SIMM IDs
dw      0001h      ; Nothing appears to be installed (Other)
db      7Dh        ; Installed size indeterminable (no SIMM IDs)
db      7Fh        ; Enabled size is 0 (nothing installed)
db      0           ; No errors
db      "B2",0     ; String#1: Reference Designator
db      0           ; End-of-strings

```

### 3.3.8 Cache Information (Type 7)

The information in this structure defines the attributes of CPU cache device in the system. One structure is specified for each such device, whether the device is internal to or external to the CPU module. Cache modules can be associated with a processor structure in one or two ways depending on the SMBIOS version, see 3.3.5 *Processor Information (Type 4)* on page 34 and 3.3.15 *Group Associations (Type 14)* on page 54 for more information.

| Offset | Spec Version | Name                | Length | Value  | Description  |
|--------|--------------|---------------------|--------|--------|--|
| 00h    | 2.0+         | Type                | BYTE   | 7      | Cache Information Indicator  |
| 01h    | 2.0+         | Length              | BYTE   | Varies | The value is 0Fh for v2.0 implementations, or 13h for v2.1 implementations.  |
| 02h    | 2.0+         | Handle              | WORD   | Varies |  |
| 04h    | 2.0+         | Socket Designation  | BYTE   | STRING | String Number for Reference Designation<br>Example: "CACHE1", 0  |
| 05h    | 2.0+         | Cache Configuration | WORD   | Varies | Bits 15:10 Reserved, must be zero<br>Bits 9:8 Operational Mode<br>00b Write Through<br>01b Write Back<br>10b Varies with Memory Address<br>11b Unknown<br>Bit 7 Enabled/Disabled (at boot time)<br>1b Enabled<br>0b Disabled<br>Bits 6:5 Location, relative to the CPU module:<br>00b Internal<br>01b External<br>10b Reserved<br>11b Unknown<br>Bit 4 Reserved, must be zero<br>Bit 3 Cache Socketed<br>1b Socketed<br>0b Not Socketed<br>Bits 2:0 Cache Level - 1 through 8, e.g. an L1 cache would use value 000b and an L3 cache would use 010b. |

| Offset | Spec Version | Name                  | Length | Value     | Description  |
|--------|--------------|-----------------------|--------|-----------|--|
| 07h    | 2.0+         | Maximum Cache Size    | WORD   | Varies    | Maximum size that can be installed<br>Bit 15 Granularity<br>0 - 1K granularity<br>1 - 64K granularity<br>Bits 14:0 Max size in given granularity |
| 09h    | 2.0+         | Installed Size        | WORD   | Varies    | Same format as Max Cache Size field, set to 0 if no cache is installed.  |
| 0Bh    | 2.0+         | Supported SRAM Type   | WORD   | Bit Field | See 3.3.8.1  |
| 0Dh    | 2.0+         | Current SRAM Type     | WORD   | Bit Field | See 3.3.8.1  |
| 0Fh    | 2.1+         | Cache Speed           | BYTE   | Varies    | The cache module speed, in nanoseconds. The value is 0 if the speed is unknown.  |
| 10h    | 2.1+         | Error Correction Type | BYTE   | ENUM      | The error-correction scheme supported by this cache component, see 3.3.8.2.  |
| 11h    | 2.1+         | System Cache Type     | BYTE   | ENUM      | The logical type of cache, see 3.3.8.3.  |
| 12h    | 2.1+         | Associativity         | BYTE   | ENUM      | The associativity of the cache, see 3.3.8.4.   |

### 3.3.8.1 Cache Information - SRAM Type

| Word | Bit Position | Meaning                |
|------|--------------|------------------------|
|      | Bit 0        | Other                  |
|      | Bit 1        | Unknown                |
|      | Bit 2        | Non-Burst              |
|      | Bit 3        | Burst                  |
|      | Bit 4        | Pipeline Burst         |
|      | Bit 5        | Synchronous            |
|      | Bit 6        | Asynchronous           |
|      | Bits 7:15    | Reserved, must be zero |

### 3.3.8.2 Cache Information — Error Correction Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning        |
|------------|----------------|
| 01h        | Other          |
| 02h        | Unknown        |
| 03h        | None           |
| 04h        | Parity         |
| 05h        | Single-bit ECC |
| 06h        | Multi-bit ECC  |

### 3.3.8.3 Cache Information — System Cache Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning     |
|------------|-------------|
| 01h        | Other       |
| 02h        | Unknown     |
| 03h        | Instruction |
| 04h        | Data        |
| 05h        | Unified     |

### 3.3.8.4 Cache Information — Associativity

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning               |
|------------|-----------------------|
| 01h        | Other                 |
| 02h        | Unknown               |
| 03h        | Direct Mapped         |
| 04h        | 2-way Set-Associative |
| 05h        | 4-way Set-Associative |
| 06h        | Fully Associative     |

### 3.3.9 Port Connector Information (Type 8)

The information in this structure defines the attributes of a system port connector, e.g. parallel, serial, keyboard, mouse ports. The port's type and connector information are provided. One structure is present for each port provided by the system.

| Offset | Name                          | Length | Value  | Description  |
|--------|-------------------------------|--------|--------|--|
| 00h    | Type                          | BYTE   | 8      | Connector Information Indicator  |
| 01h    | Length                        | BYTE   | 9h     |  |
| 02h    | Handle                        | WORD   | Varies |  |
| 04h    | Internal Reference Designator | BYTE   | STRING | String number for Internal Reference Designator, i.e. internal to the system enclosure, e.g. 'J101', 0 |
| 05h    | Internal Connector Type       | BYTE   | ENUM   | Internal Connector type. See 3.3.9.2   |
| 06h    | External Reference Designator | BYTE   | STRING | String number for the External Reference Designation external to the system enclosure, e.g. 'COM A', 0 |
| 07h    | External Connector Type       | BYTE   | ENUM   | External Connector type. See 3.3.9.2   |
| 08h    | Port Type                     | BYTE   | ENUM   | Describes the function of the port. See 3.3.9.3  |

### 3.3.9.1 Port Information Example

The following structure shows an example where a DB-9 Pin Male connector on the System Backpanel (COM A) is connected to the System Board via a 9 Pin Dual Inline connector (J101).

```

db      8           ; Indicates Connector Type
db      9h          ; Length
dw      ?           ; Reserved for handle
db      01h         ; String 1 - Internal Reference Designation
db      18h         ; 9 Pin Dual Inline
db      02h         ; String 2 - External Reference Designation
db      08h         ; DB-9 Pin Male
db      09h         ; 16550A Compatible
db      'J101',0    ; Internal reference
db      'COM A',0   ; External reference
db      0

```

If an External Connector is not used (as in the case of a CD-ROM Sound connector) then the External Reference Designator and the External Connector type should be set to zero. If an Internal Connector is not used (as in the case of a soldered on Parallel Port connector which extends outside of the chassis) then the Internal Reference Designation and Connector Type should be set to zero.

### 3.3.9.2 Port Information - Connector Types

| Byte Value | Meaning                          |
|------------|----------------------------------|
| 00h        | None                             |
| 01h        | Centronics                       |
| 02h        | Mini Centronics                  |
| 03h        | Proprietary                      |
| 04h        | DB-25 pin male                   |
| 05h        | DB-25 pin female                 |
| 06h        | DB-15 pin male                   |
| 07h        | DB-15 pin female                 |
| 08h        | DB-9 pin male                    |
| 09h        | DB-9 pin female                  |
| 0Ah        | RJ-11                            |
| 0Bh        | RJ-45                            |
| 0Ch        | 50 Pin MiniSCSI                  |
| 0Dh        | Mini-DIN                         |
| 0Eh        | Micro-DIN                        |
| 0Fh        | PS/2                             |
| 10h        | Infrared                         |
| 11h        | HP-HIL                           |
| 12h        | Access Bus (USB)                 |
| 13h        | SSA SCSI                         |
| 14h        | Circular DIN-8 male              |
| 15h        | Circular DIN-8 female            |
| 16h        | On Board IDE                     |
| 17h        | On Board Floppy                  |
| 18h        | 9 Pin Dual Inline (pin 10 cut)   |
| 19h        | 25 Pin Dual Inline (pin 26 cut)  |
| 1Ah        | 50 Pin Dual Inline               |
| 1Bh        | 68 Pin Dual Inline               |
| 1Ch        | On Board Sound Input from CD-ROM |
| 1Dh        | Mini-Centronics Type-14          |
| 1Eh        | Mini-Centronics Type-26          |

| Byte Value | Meaning   |
|------------|---|
| 1Fh        | Mini-jack (headphones)  |
| 20h        | BNC   |
| 21h        | 1394  |
| A0h        | PC-98   |
| A1h        | PC-98Hireso   |
| A2h        | PC-H98  |
| A3h        | PC-98Note   |
| A4h        | PC-98Full   |
| FFh        | Other - Use Reference Designator Strings to supply information. |

### 3.3.9.3 Port Types

| Byte Value | Meaning                        |
|------------|--------------------------------|
| 00h        | None                           |
| 01h        | Parallel Port XT/AT Compatible |
| 02h        | Parallel Port PS/2             |
| 03h        | Parallel Port ECP              |
| 04h        | Parallel Port EPP              |
| 05h        | Parallel Port ECP/EPP          |
| 06h        | Serial Port XT/AT Compatible   |
| 07h        | Serial Port 16450 Compatible   |
| 08h        | Serial Port 16550 Compatible   |
| 09h        | Serial Port 16550A Compatible  |
| 0Ah        | SCSI Port                      |
| 0Bh        | MIDI Port                      |
| 0Ch        | Joy Stick Port                 |
| 0Dh        | Keyboard Port                  |
| 0Eh        | Mouse Port                     |
| 0Fh        | SSA SCSI                       |
| 10h        | USB                            |
| 11h        | FireWire (IEEE P1394)          |
| 12h        | PCMCIA Type II                 |
| 13h        | PCMCIA Type II                 |
| 14h        | PCMCIA Type III                |
| 15h        | Cardbus                        |
| 16h        | Access Bus Port                |
| 17h        | SCSI II                        |
| 18h        | SCSI Wide                      |
| 19h        | PC-98                          |
| 1Ah        | PC-98-Hireso                   |
| 1Bh        | PC-H98                         |
| 1Ch        | Video Port                     |
| 1Dh        | Audio Port                     |
| 1Eh        | Modem Port                     |
| 1Fh        | Network Port                   |
| A0h        | 8251 Compatible                |
| A1h        | 8251 FIFO Compatible           |
| 0FFh       | Other                          |

### 3.3.10 System Slots (Type 9)

The information in this structure defines the attributes of a system slot. One structure is provided for each slot in the system.

| Offset | Spec Version | Name                   | Length | Value     | Description  |
|--------|--------------|------------------------|--------|-----------|--|
| 00h    | 2.0+         | Type                   | BYTE   | 9         | System Slot Structure Indicator                        |
| 01h    | 2.0+         | Length                 | BYTE   | Varies    | 0Ch for v2.0 implementations; 0Dh for v2.1 and later.  |
| 02h    | 2.0+         | Handle                 | WORD   | Varies    |  |
| 04h    | 2.0+         | Slot Designation       | BYTE   | STRING    | String number for reference designation e.g. 'PCI-1',0 |
| 05h    | 2.0+         | Slot Type              | BYTE   | ENUM      | See 3.3.10.1   |
| 06h    | 2.0+         | Slot Data Bus Width    | BYTE   | ENUM      | See 3.3.10.2   |
| 07h    | 2.0+         | Current Usage          | BYTE   | ENUM      | See 3.3.10.3   |
| 08h    | 2.0+         | Slot Length            | BYTE   | ENUM      | See 3.3.10.4   |
| 09h    | 2.0+         | Slot ID                | WORD   | Varies    | See 3.3.10.5   |
| 0Bh    | 2.0+         | Slot Characteristics 1 | BYTE   | Bit Field | See 3.3.10.6   |
| 0Ch    | 2.1+         | Slot Characteristics 2 | BYTE   | Bit Field | See 3.3.10.7   |

#### 3.3.10.1 System Slots - Slot Type

| Byte Value | Meaning                      |
|------------|------------------------------|
| 01h        | Other                        |
| 02h        | Unknown                      |
| 03h        | ISA                          |
| 04h        | MCA                          |
| 05h        | EISA                         |
| 06h        | PCI                          |
| 07h        | PC Card (PCMCIA)             |
| 08h        | VL-VESA                      |
| 09h        | Proprietary                  |
| 0Ah        | Processor Card Slot          |
| 0Bh        | Proprietary Memory Card Slot |
| 0Ch        | I/O Riser Card Slot          |
| 0Dh        | NuBus                        |
| 0Eh        | PCI - 66MHz Capable          |
| 0Fh        | AGP                          |
| 10h        | AGP 2X                       |
| 11h        | AGP 4X                       |
| A0h        | PC-98/C20                    |
| A1h        | PC-98/C24                    |
| A2h        | PC-98/E                      |
| A3h        | PC-98/Local Bus              |
| A4h        | PC-98/Card                   |



### 3.3.10.2 System Slots - Slot Data Bus Width

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning |
|------------|---------|
| 01h        | Other   |
| 02h        | Unknown |
| 03h        | 8 bit   |
| 04h        | 16 bit  |
| 05h        | 32 bit  |
| 06h        | 64 bit  |
| 07h        | 128 bit |

### 3.3.10.3 System Slots - Current Usage

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning   |
|------------|-----------|
| 01h        | Other     |
| 02h        | Unknown   |
| 03h        | Available |
| 04h        | In use    |

### 3.3.10.4 System Slots - Slot Length

| Byte Value | Meaning      |
|------------|--------------|
| 01h        | Other        |
| 02h        | Unknown      |
| 03h        | Short Length |
| 04h        | Long Length  |

### 3.3.10.5 System Slots — Slot ID

The *Slot ID* field of the System Slot structure provides a mechanism to correlate the physical attributes of the slot to its logical access method (which varies based on the *Slot Type* field). The Slot ID field has meaning only for the slot types described below:

| Slot Type | Slot ID Field Meaning  |
|-----------|--|
| MCA       | Identifies the logical Micro Channel slot number, in the range 1 to 15, in offset 09h. Offset 0Ah is set to 0. |
| EISA      | Identifies the logical EISA slot number, in the range 1 to 15, in offset 09h. Offset 0Ah is set to 0.          |

| Slot Type | Slot ID Field Meaning   |
|-----------|---|
| PCI/AGP   | Identifies the value present in the Slot Number field of the PCI Interrupt Routing table entry that is associated with this slot, in offset 09h — offset 0Ah is set to 0. The table is returned by the "Get PCI Interrupt Routing Options" PCI BIOS function call and provided directly in the <i>PCI IRQ Routing Table Specification</i> (\$PIRQ). Software can determine the PCI bus number and device associated with the slot by matching the "Slot ID" to an entry in the routing-table ... and ultimately determine what device is present in that slot.<br><br><i>Note:</i> This definition also applies to the 66MHz-capable PCI slots. |
| PCMCIA    | Identifies the Adapter Number (offset 09h) and Socket Number (offset 0Ah) to be passed to PCMCIA Socket Services to identify this slot.   |

### 3.3.10.6 Slot Characteristics 1

| BYTE<br>Bit Position | Meaning if Set   |
|----------------------|--|
| Bit 0                | Characteristics Unknown  |
| Bit 1                | Provides 5.0 Volts   |
| Bit 2                | Provides 3.3 Volts   |
| Bit 3                | Slot's opening is shared with another slot, e.g. PCI/EISA shared slot. |
| Bit 4                | PC Card slot supports PC Card-16                                       |
| Bit 5                | PC Card slot supports CardBus  |
| Bit 6                | PC Card slot supports Zoom Video                                       |
| Bit 7                | PC Card slot supports Modem Ring Resume                                |

### 3.3.10.7 Slot Characteristics 2

| BYTE<br>Bit Position | Meaning if Set  |
|----------------------|---|
| Bit 0                | PCI slot supports Power Management Enable (PME#) signal |
| Bit 1                | Slot supports hot-plug devices                          |
| Bits 2:7             | Reserved, set to 0                                      |

### 3.3.11 On Board Devices Information (Type 10)

The information in this structure defines the attributes of devices which are onboard (soldered onto) a system element, usually the baseboard. In general, an entry in this table implies that the BIOS has some level of control over the enabling of the associated device for use by the system.

**Important Note:** Since this structure was originally defined with the *Length* implicitly defining the number of devices present, no further fields can be added to this structure without adversely affecting existing software's ability to properly parse the data. Thus, if additional fields are required for this structure type a brand new structure must be defined to add a device count field, carry over the existing fields, and add the new information.

| Offset      | Name   | Length | Value  | Description   |
|-------------|--|--------|--------|---|
| 00h         | Type   | BYTE   | 10     | On Board Devices Information Indicator  |
| 01h         | Length   | BYTE   | Varies | Computed by the BIOS as $4 + 2 * (\text{Number of Devices})$ . The user of this structure determines the number of devices as $(\text{Length} - 4) / 2$ . |
| 02h         | Handle   | WORD   | Varies |   |
| $4+2*(n-1)$ | Device <sub>n</sub> Type, n ranges from 1 to Number of Devices | BYTE   | Varies | Bit 7 Device <sub>n</sub> Status<br>1 - Device Enabled<br>0 - Device Disabled<br>Bits 6:0 Type of Device (See 3.3.11.1)                                   |
| $5+2*(n-1)$ | Description String   | BYTE   | STRING | String number of device description   |

**Note:** There may be a single structure instance containing the information for all onboard devices or there may be a unique structure instance for each onboard device.

#### 3.3.11.1 Onboard Device Types

| Byte Value | Meaning         |
|------------|-----------------|
| 01h        | Other           |
| 02h        | Unknown         |
| 03h        | Video           |
| 04h        | SCSI Controller |
| 05h        | Ethernet        |
| 06h        | Token Ring      |
| 07h        | Sound           |

### 3.3.12 OEM Strings (Type 11)

| Offset | Name   | Length | Value  | Description           |
|--------|--------|--------|--------|-----------------------|
| 00h    | Type   | BYTE   | 11     | OEM Strings Indicator |
| 01h    | Length | BYTE   | 5h     |                       |
| 02h    | Handle | WORD   | Varies |                       |
| 04h    | Count  | BYTE   | Varies | Number of strings     |

This structure contains free form strings defined by the OEM. Examples of this are: Part Numbers for Reference Documents for the system, contact information for the manufacturer, etc.

### 3.3.13 System Configuration Options (Type 12)

| Offset | Name   | Length | Value  | Description                         |
|--------|--------|--------|--------|-------------------------------------|
| 00h    | Type   | BYTE   | 12     | Configuration Information Indicator |
| 01h    | Length | BYTE   | 5h     |                                     |
| 02h    | Handle | WORD   | Varies |                                     |
| 04h    | Count  | BYTE   | Varies | Number of strings                   |

This structure contains information required to configure the base board's Jumpers and Switches. Examples of this are: "JP2: 1-2 Cache Size is 256K, 2-3 Cache Size is 512K"  
"SW1-1: Close to Disable On Board Video"

### 3.3.14 BIOS Language Information (Type 13)

The information in this structure defines the installable language attributes of the BIOS.

| Offset | Spec Version | Name                  | Length   | Value     | Description   |
|--------|--------------|-----------------------|----------|-----------|---|
| 00h    | 2.0+         | Type                  | BYTE     | 13        | Language Information Indicator  |
| 01h    | 2.0+         | Length                | BYTE     | 16h       |   |
| 02h    | 2.0+         | Handle                | WORD     | Varies    |   |
| 04h    | 2.0+         | Installable Languages | BYTE     | Varies    | Number of languages available. Each available language will have a description string. This field contains the number of strings that follow the formatted area of the structure. |
| 05h    | 2.1+         | Flags                 | BYTE     | Bit Field | Bits 7:1 Reserved<br>Bit 0 If set to 1, the Current Language strings use the abbreviated format. Otherwise, the strings use the long format. See below for details.               |
| 06h    | 2.0+         | Reserved              | 15 BYTES | 0         | Reserved for future use   |
| 015h   | 2.0+         | Current Language      | BYTE     | STRING    | String number (one-based) of the currently installed language.  |

The strings describing the languages follow the *Current Language* byte. The format of the strings depends on the value present in bit 0 of the byte at offset 05h in the structure.

If the bit is 0, each language string is in the form “ISO 639 Language Name | ISO 3166 Territory Name | Encoding Method”. See the Example 1 below.

If the bit is 1, each language string consists of the 2-character ISO 639 Language Name directly followed by the 2-character ISO 3166 Territory Name. See Example 2 below.

**Note:** Refer to the [Desktop Management Interface Specification, V1.0, Appendix A \(ISO 639\) and Appendix B \(ISO 3166\)](#) for additional information.

#### Example 1: BIOS Language Information (Long Format)

```

db      13                ; language information
db      16h              ; length
dw      ??               ; handle
db      3                ; three languages available
db      0                ; use long-format for language strings
db      15 dup (0)      ; reserved
db      2                ; current language is French Canadian
db      'en|US|iso8859-1',0 ; language 1 is US English
db      'fr|CA|iso8859-1',0 ; language 2 is French Canadian
db      'ja|JP|unicode',0 ; language 3 is Japanese
db      0                ; Structure termination

```

#### Example 2: BIOS Language Information (Abbreviated Format)

```

db      13                ; language information
db      16h              ; length
dw      ??               ; handle
db      3                ; three languages available
db      01h             ; use abbreviated format for language strings
db      15 dup (0)      ; reserved
db      2                ; current language is French Canadian
db      'enUS',0        ; language 1 is US English
db      'frCA',0        ; language 2 is French Canadian
db      'jaJP',0        ; language 3 is Japanese
db      0                ; Structure termination

```

### 3.3.15 Group Associations (Type 14)

**Important Note:** Since this structure was originally defined with the Length implicitly defining the number of items present, no further fields can be added to this structure without adversely affecting existing software's ability to properly parse the data. Thus, if additional fields are required for this structure type a brand new structure must be defined to add an item count field, carry over the existing fields, and add the new information.

| Offset | Name        | Length | Value  | Description  |
|--------|-------------|--------|--------|--|
| 00h    | Type        | BYTE   | 14     | Group Associations Indicator   |
| 01h    | Length      | BYTE   | Varies | Computed by the BIOS as $5 + (3 \text{ bytes for each item in the group})$ . The user of this structure determines the number of items as $(Length - 5) / 3$ . |
| 02h    | Handle      | WORD   | Varies |  |
| 04h    | Group Name  | BYTE   | STRING | String number of string describing the group   |
| 05h    | Item Type   | BYTE   | Varies | Item (Structure) Type of this member   |
| 06h    | Item Handle | WORD   | Varies | Handle corresponding to this structure   |

The Group Associations structure is provided for OEMs who want to specify the arrangement or hierarchy of certain components (including other Group Associations) within the system. For example, you can use the Group Associations structure to indicate that two CPU's share a common external cache system. These structures might look as follows:

#### First Group Association Structure:

```

db 14 ; Group Association structure
db 11 ; Length
dw 28h ; Handle
db 01h ; String Number (First String)
db 04 ; CPU Structure
dw 08h ; CPU Structure's Handle
db 07 ; Cache Structure
dw 09h ; Cache Structure's Handle
db 'Primary CPU Module', 0
db 0

```

#### Second Group Association Structure:

```

db 14 ; Group Association structure
db 11 ; Length
dw 29h ; Handle
db 01h ; String Number (First String)
db 04 ; CPU Structure
dw 0Ah ; CPU Structure's Handle
db 07 ; Cache Structure
dw 09h ; Cache Structure's Handle
db 'Secondary CPU Module', 0
db 0

```

In the examples above, CPU structures 08h and 0Ah are associated with the same cache, 09h. This relationship could also be specified as a single group:

```

db 14 ; Group Association structure
db 14 ; Length (5 + 3 * 3)
dw 28h ; Structure handle for Group Association
db 1 ; String Number (First string)
db 4 ; 1st CPU
dw 08h ; CPU structure handle
db 4 ; 2nd CPU
dw 0Ah ; CPU structure handle
db 7 ; Shared cache
dw 09h ; Cache structure handle
db 'Dual-Processor CPU Complex', 0
db 0

```

### 3.3.16 System Event Log (Type 15)

The presence of this structure within the SMBIOS data returned for a system indicates that the system supports an event log. An event log is a fixed-length area within a non-volatile storage element, starting with a fixed-length (and vendor-specific) header record, followed by one or more variable-length log records. See 3.3.16.4 *Event Log Organization* on page 59 for more information. Refer also to 2.2.5 *Function 54h – SMBIOS Control* on page 19 for interfaces that can be used to control the event-log.

An application can implement event-log change notification by periodically reading the System Event Log structure (via its assigned handle) looking for a change in the *Log Change Token*. This token uniquely identifies the last time the event log was updated. When it sees the token changed, the application can retrieve the entire event log and determine the changes since the last time it read the event log.

| Offset | Spec Version | Name                    | Length | Value | Description   |
|--------|--------------|-------------------------|--------|-------|---|
| 00h    | 2.0+         | Type                    | BYTE   | 15    | Event Log Type Indicator  |
| 01h    | 2.0+         | Length                  | BYTE   | Var   | Length of the structure, including the Type and Length fields. The Length is 14h for v2.0 implementations or computed by the BIOS as $17h+(x*y)$ for v2.1 and higher implementations — where x is the value present at offset 15h and y is the value present at offset 16h.   |
| 02h    | 2.0+         | Handle                  | WORD   | Var   | The handle, or instance number, associated with the structure.  |
| 04h    | 2.0+         | Log Area Length         | WORD   | Var   | The length, in bytes, of the overall event log area, from the first byte of header to the last byte of data.  |
| 06h    | 2.0+         | Log Header Start Offset | WORD   | Var   | Defines the starting offset (or index) within the nonvolatile storage of the event-log's header, from the Access Method Address. For single-byte indexed I/O accesses, the most-significant byte of the start offset is set to 00h.   |
| 08h    | 2.0+         | Log Data Start Offset   | WORD   | Var   | Defines the starting offset (or index) within the nonvolatile storage of the event-log's first data byte, from the Access Method Address. For single-byte indexed I/O accesses, the most-significant byte of the start offset is set to 00h.<br><br><b>Note:</b> The data directly follows any header information. Therefore, the header length can be determined by subtracting the <i>Header Start Offset</i> from the <i>Data Start Offset</i> . |

| Offset | Spec Version | Name                          | Length | Value | Description  |
|--------|--------------|-------------------------------|--------|-------|--|
| 0Ah    | 2.0+         | Access Method                 | BYTE   | Var   | <p>Defines the Location and Method used by higher-level software to access the log area, one of:</p> <p>00h Indexed I/O: 1 8-bit index port, 1 8-bit data port. The Access Method Address field contains the 16-bit I/O addresses for the index and data ports. See 3.3.16.2.1 for usage details.</p> <p>01h Indexed I/O: 2 8-bit index ports, 1 8-bit data port. The Access Method Address field contains the 16-bit I/O address for the index and data ports. See 3.3.16.2.2 for usage details.</p> <p>02h Indexed I/O: 1 16-bit index port, 1 8-bit data port. The Access Method Address field contains the 16-bit I/O address for the index and data ports. See 3.3.16.2.3 for usage details.</p> <p>03h Memory-mapped physical 32-bit address. The Access Method Address field contains the 4-byte (Intel DWORD format) starting physical address.</p> <p>04h Available via General-Purpose NonVolatile Data functions, see 2.2.6 on page 21 for more information. The Access Method Address field contains the 2-byte (Intel WORD format) GPNV handle.</p> <p>05h-7Fh Available for future assignment via this specification</p> <p>80h-FFh BIOS Vendor/OEM-specific</p> |
| 0Bh    | 2.0+         | Log Status <sup>3</sup>       | BYTE   | Var   | <p>This bit-field describes the current status of the system event-log:</p> <p>Bits 7:2 Reserved, set to 0's</p> <p>Bit 1 Log area full, if 1</p> <p>Bit 0 Log area valid, if 1</p>  |
| 0Ch    | 2.0+         | Log Change <sup>3</sup> Token | DWORD  | Var   | <p>Unique token that is reassigned every time the event log changes. Can be used to determine if additional events have occurred since the last time the log was read.</p>   |

<sup>3</sup> The *Log Status* and *Log Change Token* fields might not be up-to-date (dynamic) when the structure is accessed using the table interface.



| Offset             | Spec Version | Name   | Length | Value  | Description  |
|--------------------|--------------|--|--------|--------|--|
| 10h                | 2.0+         | Access Method Address                        | DWORD  | Var    | The address associated with the access method; the data present depends on the Access Method field value. The area's format can be described by the following 1-byte-packed 'C' union:<br><pre>union {   struct   {     short  IndexAddr;     short  DataAddr;   } IO;   long  PhysicalAddr32;   short  GPNVHandle; } AccessMethodAddress;</pre> |
| 14h                | 2.1+         | Log Header Format                            | BYTE   | ENUM   | Identifies the format of the log header area, see 3.3.16.5 for details.  |
| 15h                | 2.1+         | Number of Supported Log Type Descriptors (x) | BYTE   | Varies | Number of supported event log type descriptors that follow. If the value is 0, the list that starts at offset 17h is not present.  |
| 16h                | 2.1+         | Length of each Log Type Descriptor (y)       | BYTE   | 2      | Identifies the number of bytes associated with each type entry in the list below. The value is currently "hard-coded" as 2, since each entry consists of two bytes. This field's presence allows future additions to the type list. Software that interprets the following list should not assume a list entry's length.                         |
| 17h to 17h+(x*y)-1 | 2.1+         | List of Supported Event Log Type Descriptors | Varies | Var    | Contains a list of Event Log Type Descriptors (see 3.3.16.1), so long as the value specified in offset 15h is non-zero.  |

### 3.3.16.1 Supported Event Log Type Descriptors

Each entry consists of a 1-byte type field and a 1-byte data-format descriptor, as defined by the following table. The presence of an entry identifies that the Log Type is supported by the system and the format of any variable data which accompanies the first bytes of the log's variable data — a specific log record might have more variable data than specified by its Variable Data Format Type.

| Offset | Name                      | Length | Value | Description                         |
|--------|---------------------------|--------|-------|-------------------------------------|
| 00h    | Log Type                  | BYTE   | ENUM  | See 3.3.16.6.1 on page 61 for list. |
| 01h    | Variable Data Format Type | BYTE   | ENUM  | See 3.3.16.6.2 on page 62 for list  |

### 3.3.16.2 Indexed I/O Access Method

This section contains examples (in x86 assembly language) which detail the code required to access the "indexed I/O" event-log information.

**3.3.16.2.1 1 8-bit Index, 1 8-bit Data (00h)**

To access the event-log, the caller selects 1 of 256 unique data bytes by

- 1) Writing the byte data-selection value (index) to the *IndexAddr* I/O address
- 2) Reading or writing the byte data value to (or from) the *DataAddr* I/O address

```

mov  dx, IndexAddr      ;Value from event-log structure
mov  al, WhichLoc      ;Identify offset to be accessed
out  dx, al
mov  dx, DataAddr      ;Value from event-log structure
in   al, dx            ; Read current value

```

**3.3.16.2.2 2 8-bit Index, 1 8-bit Data (01h)**

To access the event-log, the caller selects 1 of 65536 unique data bytes by

- 1) Writing the least-significant byte data-selection value (index) to the *IndexAddr* I/O address
- 2) Writing the most-significant byte data-selection value (index) to the (*IndexAddr+1*) I/O address
- 3) Reading or writing the byte data value to (or from) the *DataAddr* I/O address

```

mov  dx, IndexAddr      ;Value from event-log structure
mov  ax, WhichLoc      ;Identify offset to be accessed
out  dx, al            ;Select LSB offset
inc  dx
xchg ah, al
out  dx, al            ;Select MSB offset
mov  dx, DataAddr      ;Value from event-log structure
in   al, dx            ;Read current value

```

**3.3.16.2.3 1 16-bit Index, 1 8-bit Data (02h)**

To access the event-log, the caller selects 1 of 65536 unique data bytes by

- 1) Writing the word data-selection value (index) to the *IndexAddr* I/O address
- 2) Reading or writing the byte data value to (or from) the *DataAddr* I/O address

```

mov  dx, IndexAddr      ;Value from event-log structure
mov  ax, WhichLoc      ;Identify offset to be accessed
out  dx, ax
mov  dx, DataAddr      ;Value from event-log structure
in   al, dx            ;Read current value

```

**3.3.16.3 Access Method Address — DWORD Layout**

| Access Type          | BYTE 3   | BYTE 2   | BYTE 1     | BYTE 0     |
|----------------------|----------|----------|------------|------------|
| 00:02 — Indexed I/O  | Data MSB | Data LSB | Index MSB  | Index LSB  |
| 03- Absolute Address | Byte 3   | Byte 2   | Byte 1     | Byte 0     |
| 04 - Use GPNV        | 0        | 0        | Handle MSB | Handle LSB |

### 3.3.16.4 Event Log Organization

The event log is organized as an optional (and implementation-specific) fixed-length header, followed by one or more variable-length event records, as illustrated below. From one implementation to the next, the format of the log header and the size of the overall log area might change; all other required fields of the event log area will be consistent across all systems.

| Log Header (Optional) |        |      |       |      |      |        |        |                   |
|-----------------------|--------|------|-------|------|------|--------|--------|-------------------|
| Type                  | Length | Year | Month | Day  | Hour | Minute | Second | Log Variable Data |
| Reqd                  | Reqd   | Reqd | Reqd  | Reqd | Reqd | Reqd   | Reqd   | Optional          |

### 3.3.16.5 Log Header Format

The following table contains the byte enumeration values (available for SMBIOS v2.1 and later) which identify the standard formats of the event log headers.

| Byte Value | Meaning  | See ...    |
|------------|--|------------|
| 00h        | No header, e.g. the header is 0 bytes in length.       |            |
| 01h        | Type 1 log header                                      | 3.3.16.5.1 |
| 02h-7Fh    | Available for future assignment via this specification |            |
| 80h-FFh    | BIOS Vendor or OEM-specific format                     |            |

#### 3.3.16.5.1 Log Header Type 1 Format

The type 1 event log header consists of the following fields:

| Offset | Name                                    | Length     | Value  | Description  |
|--------|---|------------|--------|--|
| 00h    | OEM Reserved                            | 5<br>BYTES | Varies | Reserved area for OEM customization, not assignable by this specification.   |
| 05h    | Multiple Event Time Window              | BYTE       | Varies | The number of minutes which must pass between duplicate log entries which utilize a multiple-event counter, specified in BCD. The value ranges from 00h to 99h to represent 0 to 99 minutes.<br><br>See 3.3.16.6.3 <i>Multiple-Event Counter</i> on page 62 for usage details.                             |
| 06h    | Multiple Event Count Increment          | BYTE       | Varies | The number of occurrences of a duplicate event which must pass before the multiple-event counter associated with the log entry is updated, specified as a numeric value in the range 1 to 255 (the value 0 is reserved).<br><br>See 3.3.16.6.3 <i>Multiple-Event Counter</i> on page 62 for usage details. |
| 07h    | Pre-boot Event Log Reset — CMOS Address | BYTE       | Varies | Identifies the CMOS RAM address (in the range 10h - FFh) associated with the Pre-boot Event Log Reset; the value is 00h if the feature is not supported. See below for usage details.  |

| Offset    | Name                                      | Length  | Value   | Description   |
|-----------|---|---------|---------|---|
| 08h       | Pre-boot Event Log Reset — CMOS Bit Index | BYTE    | Varies  | Identifies the bit within the above CMOS RAM location which is set to indicate that the log should be cleared. The value is specified in the range 0 to 7, where 0 specifies the LSB and 7 specified the MSB. See below for usage details.    |
| 09h       | CMOS Checksum — Starting Offset           | BYTE    | Varies  | Identifies the CMOS RAM address associated with the start of the area which is to be checksummed, if the value is non-0. If the value is 0, the CMOS Address field lies outside of a checksummed region in CMOS. See below for usage details. |
| 0Ah       | CMOS Checksum — Byte Count                | BYTE    | Varies  | Identifies the number of consecutive CMOS RAM addresses, starting at the Starting Offset, which participate in the CMOS Checksum region associated with the pre-boot event log reset. See below for usage details.                            |
| 0Bh       | CMOS Checksum — Checksum Offset           | BYTE    | Varies  | Identifies the CMOS RAM address associated with the start of two consecutive bytes into which the calculated checksum value is stored. See below for usage details.   |
| 0Ch - 0Eh | Reserved                                  | 3 BYTES | 000000h | Available for future assignment via this specification.   |
| 0Fh       | Header Revision                           | BYTE    | 01h     | Identifies the version of Type 1 header implemented.  |

The Type 1 Log Header also provides pre-boot event log reset support. Application software can set a system-specific location of CMOS RAM memory (accessible via I/O ports 70h and 71h) to cause the event log to be cleared by the BIOS on the next reboot of the system.

To perform the field setting, application software follows these steps, so long as the *Pre-boot Event Log Reset — CMOS Address* field of the header is non-zero:

- Read the address specified from CMOS RAM set the bit specified by the *CMOS Bit Index* field to 1. Rewrite the CMOS RAM address with the updated data.
- If the *CMOS Checksum — Starting Offset* field is non-zero, recalculate the CMOS RAM checksum value for the range starting at the *Starting Offset* field for *Byte Count* bytes into a 2-byte value. Subtract that value from 0 to create the checksum value for the range and store that 2-byte value into the CMOS RAM; the least-significant byte of the value is stored at the CMOS RAM *Checksum Offset* and the most-significant byte of the value is stored at  $(Checksum Offset)+1$ .

### 3.3.16.6 Log Record Format

Each log record consists of a *required* fixed-length record header, followed by (optional) additional data which is defined by the event type. The fixed-length log record header is present as the first 8-bytes of each log record, regardless of event type, and consists of:

| Offset  | Name              | Format | Description   |
|---------|-------------------|--------|---|
| 00h     | Event Type        | BYTE   | Specifies the "Type" of event noted in an event-log entry as defined in 3.3.16.6.1  |
| 01h     | Length            | BYTE   | Specifies the byte length of the event record, including the record's Type and Length fields. The most-significant bit of the field specifies whether (0) or not (1) the record has been read. The implication of the record having been <u>read</u> is that the information in the log record has been processed by a higher software layer.                           |
| 02h-07h | Date/Time Fields  | BYTE   | These fields contain the BCD representation of the date and time (as read from CMOS) of the occurrence of the event. The information is present in year, month, day, hour, minute, second order.<br><b>Note:</b> The century portion of the two-digit year is implied as '19' for year values in the range 80h to 99h and '20' for year values in the range 00h to 79h. |
| 08h+    | Log Variable Data | Var    | This field contains the (optional) event-specific additional status information.  |

#### 3.3.16.6.1 Event Log Types

| Value | Description   |
|-------|---|
| 00h   | Reserved.   |
| 01h   | Single-bit ECC memory error   |
| 02h   | Multi-bit ECC memory error  |
| 03h   | Parity memory error   |
| 04h   | Bus time-out  |
| 05h   | I/O Channel Check   |
| 06h   | Software NMI  |
| 07h   | POST Memory Resize  |
| 08h   | POST Error  |
| 09h   | PCI Parity Error  |
| 0Ah   | PCI System Error  |
| 0Bh   | CPU Failure   |
| 0Ch   | EISA FailSafe Timer time-out  |
| 0Dh   | Correctable memory log disabled   |
| 0Eh   | Logging disabled for a specific Event Type – too many errors of the same type received in a short amount of time. |
| 0Fh   | Reserved  |
| 10h   | System Limit Exceeded (e.g. voltage or temperature threshold exceeded).   |
| 11h   | Asynchronous hardware timer expired and issued a system reset.  |
| 12h   | System configuration information  |
| 13h   | Hard-disk information   |
| 14h   | System reconfigured   |
| 15h   | Uncorrectable CPU-complex error   |
| 16h   | Log Area Reset/Cleared  |
| 17h   | System boot. If implemented, this log entry is guaranteed to be the first one written on any system boot.         |

| Value   | Description   |
|---------|---|
| 18h-7Fh | Unused, available for assignment by this specification.   |
| 80h-FFh | Available for system- and OEM-specific assignments.   |
| FFh     | End-of-log. When an application searches through the event-log records, the end of the log is identified when a log record with this type is found. |

### 3.3.16.6.2 Event Log Variable Data Format Types

The Variable Data Format Type, specified in the Event Log structure's Supported Event Type fields, identifies the standard-format that application software can apply to the first  $n$  bytes of the associated Log Type's variable data. Additional, OEM-specific, data might follow in the log's variable data field.

| Value   | Name                                  | Description  |
|---------|---------------------------------------|--|
| 00h     | None                                  | No standard format data is available; the first byte of the variable data (if present) contains OEM-specific unformatted information.  |
| 01h     | Handle                                | The first WORD of the variable data contains the handle of the SMBIOS structure associated with the hardware element which failed.   |
| 02h     | Multiple-Event                        | The first DWORD of the variable data contains a multiple-event counter (see 3.3.16.6.3 for details).   |
| 03h     | Multiple-Event Handle                 | The first WORD of the variable data contains the handle of the SMBIOS structure associated with the hardware element which failed; it is followed by a DWORD containing a multiple-event counter (see 3.3.16.6.3 for details).   |
| 04h     | POST Results Bitmap                   | The first 2 DWORDs of the variable data contain the POST Results Bitmap, as described in 3.3.16.6.3.1 on page 63.  |
| 05h     | System Management Type                | The first DWORD of the variable data contains a value which identifies a system-management condition. See 3.3.16.6.3.2 on page 64 for the enumerated values.   |
| 06h     | Multiple-Event System Management Type | The first DWORD of the variable data contains a value which identifies a system-management condition (see 3.3.16.6.3.2 on page 64 for the enumerated values). This DWORD is directly followed by a DWORD which contains a multiple-event counter (see 3.3.16.6.3 for details). |
| 07h-7Fh | Unused                                | Unused, available for assignment by this specification.  |
| 80h-FFh | OEM assigned                          | Available for system- and OEM-specific assignments.  |

### 3.3.16.6.3 Multiple-Event Counter

Some system events can be persistent; once they occur, it is possible to quickly fill the log with redundant multiple logs. The Multiple Event Count Increment (*MECI*) and Multiple Event Time Window (*METW*) values can be used to reduce the occurrence of these multiple logs while providing multiple event counts.

**Note:** These values are normally specified within the event log header, see 3.3.16.5.1 *Log Header Type 1 Format* on page 59 for an example; if the values aren't specified in the header, the application software can assume that the *MECI* value is 1 and the *METW* value is 60 (minutes).

The multiple-event counter is a DWORD (32-bit) value which tracks the number of logs of the same type which have occurred within *METW* minutes. The counter value is initialized (in the log entry) to FFFFFFFFh, implying that only a single event of that type has been detected, and the internal BIOS counter<sup>4</sup> specific to that log type is reset to 0. When the BIOS receives the next event of that type, it increments its internal counter and checks to see what recording of the error is to be performed:

1. *A new log entry is written ...* and the internal BIOS counter reset to 0, if the date/time of the original log entry is outside of *METW* minutes.
2. *No recording ...* (other than the internal counter increment) if the log's current multiple-event counter is 00000000h or if the internal BIOS counter is less than *MECI*.
3. *The next non-zero bit of the multiple-event counter is set to 0 ...* otherwise.

### 3.3.16.6.3.1 POST Results Bitmap

This variable data type, when present, is expected to be associated with the POST Error (08h) event log type and identifies that one or more error types have occurred. The bitmap consists of two DWORD values, described in the table below. Any bit within the DWORD pair that is specified as Reserved is set to 0 within the log data and is available for assignment via this specification. A set bit ('1'b) at a DWORD bit position implies that the error associated with that position has occurred.

| Bit Position | First DWORD                              | Second DWORD                               |
|--------------|--|--|
| 0            | Channel 2 Timer error                    | Normally 0; available for OEM assignment   |
| 1            | Master PIC (8259 #1) error               | Normally 0; available for OEM assignment   |
| 2            | Slave PIC (8259 #2) error                | Normally 0; available for OEM assignment   |
| 3            | CMOS Battery Failure                     | Normally 0; available for OEM assignment   |
| 4            | CMOS System Options Not Set              | Normally 0; available for OEM assignment   |
| 5            | CMOS Checksum Error                      | Normally 0; available for OEM assignment   |
| 6            | CMOS Configuration Error                 | Normally 0; available for OEM assignment   |
| 7            | Mouse and Keyboard Swapped               | PCI Memory Conflict                        |
| 8            | Keyboard Locked                          | PCI I/O Conflict                           |
| 9            | Keyboard Not Functional                  | PCI IRQ Conflict                           |
| 10           | Keyboard Controller Not Functional       | PNP Memory Conflict                        |
| 11           | CMOS Memory Size Different               | PNP 32 bit Memory Conflict                 |
| 12           | Memory Decreased in Size                 | PNP I/O Conflict                           |
| 13           | Cache Memory Error                       | PNP IRQ Conflict                           |
| 14           | Floppy Drive 0 Error                     | PNP DMA Conflict                           |
| 15           | Floppy Drive 1 Error                     | Bad PNP Serial ID Checksum                 |
| 16           | Floppy Controller Failure                | Bad PNP Resource Data Checksum             |
| 17           | Number of ATA Drives Reduced Error       | Static Resource Conflict                   |
| 18           | CMOS Time Not Set                        | NVRAM Checksum Error, NVRAM Cleared        |
| 19           | DDC Monitor Configuration Change         | System Board Device Resource Conflict      |
| 20           | Reserved, set to 0                       | Primary Output Device Not Found            |
| 21           | Reserved, set to 0                       | Primary Input Device Not Found             |
| 22           | Reserved, set to 0                       | Primary Boot Device Not Found              |
| 23           | Reserved, set to 0                       | NVRAM Cleared By Jumper                    |
| 24           | Second DWORD has valid data              | NVRAM Data Invalid, NVRAM Cleared          |
| 25           | Reserved, set to 0                       | FDC Resource Conflict                      |
| 26           | Reserved, set to 0                       | Primary ATA Controller Resource Conflict   |
| 27           | Reserved, set to 0                       | Secondary ATA Controller Resource Conflict |
| 28           | Normally 0; available for OEM assignment | Parallel Port Resource Conflict            |

<sup>4</sup> All BIOS counters which support the Multiple-Event Counters are reset to zero each time the system boots.

|    |  |                                 |
|----|--|---------------------------------|
| 29 | Normally 0; available for OEM assignment | Serial Port 1 Resource Conflict |
| 30 | Normally 0; available for OEM assignment | Serial Port 2 Resource Conflict |
| 31 | Normally 0; available for OEM assignment | Audio Resource Conflict         |

### 3.3.16.6.3.2 System Management Types

The following table defines the system management types present in event log record's variable data. In general, each type is associated with a management event that occurred within the system.

| Value                 | Name  |
|-----------------------|---|
| 00000000h             | +2.5V Out of range, #1  |
| 00000001h             | +2.5V Out of range, #2  |
| 00000002h             | +3.3V Out of range  |
| 00000003h             | +5V Out of range  |
| 00000004h             | -5V Out of range  |
| 00000005h             | +12V Out of range   |
| 00000006h             | -12V Out of range   |
| 00000007h - 0000000Fh | Reserved for future out-of-range voltage levels, assigned via this specification  |
| 00000010h             | System board temperature out of range   |
| 00000011h             | Processor #1 temperature out of range   |
| 00000012h             | Processor #2 temperature out of range   |
| 00000013h             | Processor #3 temperature out of range   |
| 00000014h             | Processor #4 temperature out of range   |
| 00000015h - 0000001Fh | Reserved for future out-of-range temperatures, assigned via this specification  |
| 00000020h - 00000027h | Fan n (n = 0 to 7) Out of range   |
| 00000028h - 0000002Fh | Reserved for future assignment via this specification   |
| 00000030h             | Chassis secure switch activated   |
| 00000031h - 0000FFFFh | Reserved for future assignment via this specification   |
| 0001xxxxh             | A system-management probe or cooling device is out-of-range. The xxxx portion of the value contains the handle of the SMBIOS structure associated with the errant device. |
| 00020000h - 7FFFFFFFh | Reserved for future assignment via this specification   |
| 80000000h - FFFFFFFFh | OEM assigned  |

### 3.3.17 Physical Memory Array (Type 16)

This structure supports the population of the DMTF|Physical Memory Array group, as defined in the DMTF's `MASTER.MIF`.

**Note:** The DMTF's *System Standard Groups Definition* contains examples of this implementation. Refer to the section titled *Enhanced Physical Memory*.

| Offset | Spec Version | Name     | Length | Value  | Description  |
|--------|--------------|----------|--------|--------|--|
| 00h    | 2.1+         | Type     | BYTE   | 16     | Physical Memory Array type   |
| 01h    | 2.1+         | Length   | BYTE   | 0Fh    | Length of the structure.   |
| 02h    | 2.1+         | Handle   | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | 2.1+         | Location | BYTE   | ENUM   | The physical location of the Memory Array, whether on the system board or an add-in board. See 3.3.17.1 for definitions. |
| 05h    | 2.1+         | Use      | BYTE   | ENUM   | Identifies the function for which the array is used. See 3.3.17.2 for definitions.                                       |



| Offset | Spec Version | Name                            | Length | Value  | Description  |
|--------|--------------|---------------------------------|--------|--------|--|
| 06h    | 2.1+         | Memory Error Correction         | BYTE   | ENUM   | The primary hardware error correction or detection method supported by this memory array. See 3.3.17.3 for definitions.  |
| 07h    | 2.1+         | Maximum Capacity                | DWORD  | Varies | The maximum memory capacity, in kilobytes, for this array. If the capacity is unknown, this field contains 8000 0000h.   |
| 0Bh    | 2.1+         | Memory Error Information Handle | WORD   | Varies | The handle, or instance number, associated with any error which was previously detected for the array. If the system does not provide the error information structure, the field contains FFFEh; otherwise, the field contains either FFFFh (if no error was detected) or the handle of the error-information structure. See also 3.3.19 32-bit Memory Error Information (Type 18) on page 69 and 3.3.34 64-bit Memory Error Information (Type 33) on page 87. |
| 0Dh    | 2.1+         | Number of Memory Devices        | WORD   | Varies | The number of slots or sockets available for Memory Devices in this array. This value represents the number of Memory Device structures which comprise this Memory Array. Each Memory Device has a reference to the 'owning' Memory Array.   |

### 3.3.17.1 Memory Array — Location

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                     |
|------------|-----------------------------|
| 01h        | Other                       |
| 02h        | Unknown                     |
| 03h        | System board or motherboard |
| 04h        | ISA add-on card             |
| 05h        | EISA add-on card            |
| 06h        | PCI add-on card             |
| 07h        | MCA add-on card             |
| 08h        | PCMCIA add-on card          |
| 09h        | Proprietary add-on card     |
| 0Ah        | NuBus                       |
| A0h        | PC-98/C20 add-on card       |
| A1h        | PC-98/C24 add-on card       |
| A2h        | PC-98/E add-on card         |
| A3h        | PC-98/Local bus add-on card |

### 3.3.17.2 Memory Array — Use

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning          |
|------------|------------------|
| 01h        | Other            |
| 02h        | Unknown          |
| 03h        | System memory    |
| 04h        | Video memory     |
| 05h        | Flash memory     |
| 06h        | Non-volatile RAM |
| 07h        | Cache memory     |

### 3.3.17.3 Memory Array — Error Correction Types

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning        |
|------------|----------------|
| 01h        | Other          |
| 02h        | Unknown        |
| 03h        | None           |
| 04h        | Parity         |
| 05h        | Single-bit ECC |
| 06h        | Multi-bit ECC  |
| 07h        | CRC            |

## 3.3.18 Memory Device (Type 17)

This structure supports the population of the DMTF|Memory Device group, as defined in the DMTF's `MASTER.MIF`.

**Note:** If a system includes memory-device sockets, the SMBIOS implementation includes a *Memory Device* structure instance for each slot whether or not the socket is currently populated.

| Offset | Spec Version | Name                | Length | Value  | Description   |
|--------|--------------|---------------------|--------|--------|---|
| 00h    | 2.1+         | Type                | BYTE   | 17     | Memory Device type  |
| 01h    | 2.1+         | Length              | BYTE   | Varies | Length of the structure, either 15h or 17h depending on whether the <i>Speed</i> of the device is included. |
| 02h    | 2.1+         | Handle              | WORD   | Varies | The handle, or instance number, associated with the structure.  |
| 04h    | 2.1+         | Memory Array Handle | WORD   | Varies | The handle, or instance number, associated with the Memory Array to which this device belongs.              |

| Offset | Spec Version | Name                            | Length | Value  | Description  |
|--------|--------------|---------------------------------|--------|--------|--|
| 06h    | 2.1+         | Memory Error Information Handle | WORD   | Varies | The handle, or instance number, associated with any error which was previously detected for the device. If the system does not provide the error information structure, the field contains FFFEh; otherwise, the field contains either FFFFh (if no error was detected) or the handle of the error-information structure. See 3.3.19 <i>32-bit Memory Error Information (Type 18)</i> on page 69 and 3.3.34 <i>64-bit Memory Error Information (Type 33)</i> on page 87.                             |
| 08h    | 2.1+         | Total Width                     | WORD   | Varies | The total width, in bits, of this memory device, including any check or error-correction bits. If there are no error-correction bits, this value should be equal to Data Width. If the width is unknown, the field is set to FFFFh.  |
| 0Ah    | 2.1+         | Data Width                      | WORD   | Varies | The data width, in bits, of this memory device. A Data Width of 0 and a Total Width of 8 indicates that the device is being used solely to provide 8 error-correction bits. If the width is unknown, the field is set to FFFFh.  |
| 0Ch    | 2.1+         | Size                            | WORD   | Varies | The size of the memory device. If the value is 0, no memory device is installed in the socket; if the size is unknown, the field value is FFFFh.<br><br>The granularity in which the value is specified depends on the setting of the most-significant bit (bit 15). If the bit is 0, the value is specified in megabyte units; if the bit is 1, the value is specified in kilobyte units. For example, the value 8100h identifies a 256KB memory device and 0100h identifies a 256MB memory device. |
| 0Eh    | 2.1+         | Form Factor                     | BYTE   | ENUM   | The implementation form factor for this memory device. See 3.3.18.1 for definitions.   |
| 0Fh    | 2.1+         | Device Set                      | BYTE   | Varies | Identifies when the Memory Device is one of a set of Memory Devices that must be populated with all devices of the same type and size, and the set to which this device belongs. A value of 0 indicates that the device is not part of a set; a value of FFh indicates that the attribute is unknown.<br><br><b>Note:</b> A <i>Device Set</i> number must be unique within the context of the Memory Array containing this Memory Device.  |
| 10h    | 2.1+         | Device Locator                  | BYTE   | STRING | The string number of the string that identifies the physically-labeled socket or board position where the memory device is located, e.g. "SIMM 3".   |
| 11h    | 2.1+         | Bank Locator                    | BYTE   | STRING | The string number of the string that identifies the physically-labeled bank where the memory device is located, e.g. "Bank 0" or "A".  |

| Offset | Spec Version | Name        | Length | Value     | Description   |
|--------|--------------|-------------|--------|-----------|---|
| 12h    | 2.1+         | Memory Type | BYTE   | ENUM      | The type of memory used in this device, see 3.3.18.2 for definitions.   |
| 13h    | 2.1+         | Type Detail | WORD   | Bit Field | Additional detail on the memory device type, see 3.3.18.3 for definitions.  |
| 15h    | 2.3+         | Speed       | WORD   | Varies    | Identifies the speed of the device, in megahertz (MHz). If the value is 0, the speed is unknown.<br><b>Note:</b> $n$ MHz = (1000 / $n$ ) nanoseconds (ns) |

### 3.3.18.1 Memory Device — Form Factor

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning          |
|------------|------------------|
| 01h        | Other            |
| 02h        | Unknown          |
| 03h        | SIMM             |
| 04h        | SIP              |
| 05h        | Chip             |
| 06h        | DIP              |
| 07h        | ZIP              |
| 08h        | Proprietary Card |
| 09h        | DIMM             |
| 0Ah        | TSOP             |
| 0Bh        | Row of chips     |
| 0Ch        | RIMM             |
| 0Dh        | SODIMM           |

### 3.3.18.2 Memory Device — Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning |
|------------|---------|
| 01h        | Other   |
| 02h        | Unknown |
| 03h        | DRAM    |
| 04h        | EDRAM   |
| 05h        | VRAM    |
| 06h        | SRAM    |
| 07h        | RAM     |
| 08h        | ROM     |
| 09h        | FLASH   |
| 0Ah        | EEPROM  |
| 0Bh        | FEPRM   |
| 0Ch        | EPROM   |
| 0Dh        | CDRAM   |
| 0Eh        | 3DRAM   |
| 0Fh        | SDRAM   |
| 10h        | SGRAM   |

### 3.3.18.3 Memory Device — Type Detail

**Important Note:** Bit-field values are controlled by the DMTF, not this specification.

**Note:** Multiple bits are set if more than one attribute applies.

| Word | Bit Position | Meaning             |
|------|--------------|---------------------|
|      | Bit 0        | Reserved, set to 0. |
|      | Bit 1        | Other               |
|      | Bit 2        | Unknown             |
|      | Bit 3        | Fast-paged          |
|      | Bit 4        | Static column       |
|      | Bit 5        | Pseudo-static       |
|      | Bit 6        | RAMBUS              |
|      | Bit 7        | Synchronous         |
|      | Bit 8        | CMOS                |
|      | Bit 9        | EDO                 |
|      | Bit 10       | Window DRAM         |
|      | Bit 11       | Cache DRAM          |
|      | Bit 12       | Non-volatile        |
|      | Bits 13:15   | Reserved, set to 0. |

### 3.3.19 32-bit Memory Error Information (Type 18)

This structure supports the population of the [DMTF|Physical Memory Array](#) and [DMTF|Memory Device](#) groups, as defined in the DMTF's `MASTER.MIF`. The *Last Error Update* field, present in those groups, is not supplied in this structure since that field's attribute is known at the system-management application layer, not the BIOS.

| Offset | Spec Version | Name                       | Length | Value  | Description  |
|--------|--------------|----------------------------|--------|--------|--|
| 00h    | 2.1+         | Type                       | BYTE   | 18     | 32-bit Memory Error Information type   |
| 01h    | 2.1+         | Length                     | BYTE   | 17h    | Length of the structure.   |
| 02h    | 2.1+         | Handle                     | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | 2.1+         | Error Type                 | BYTE   | ENUM   | The type of error that is associated with the current status reported for the memory array or device. See 3.3.19.1 for definitions..   |
| 05h    | 2.1+         | Error Granularity          | BYTE   | ENUM   | Identifies the granularity, e.g. device vs. Partition, to which the error can be resolved. See 3.3.19.2 for definitions.   |
| 06h    | 2.1+         | Error Operation            | BYTE   | ENUM   | The memory access operation that caused the error. See 3.3.19.3 for definitions.   |
| 07h    | 2.1+         | Vendor Syndrome            | DWORD  | Varies | The vendor-specific ECC syndrome or CRC data associated with the erroneous access. If the value is unknown, this field contains 0000 0000h.                                    |
| 0Bh    | 2.1+         | Memory Array Error Address | DWORD  | Varies | The 32-bit physical address of the error based on the addressing of the bus to which the memory array is connected. If the address is unknown, this field contains 8000 0000h. |

| Offset | Spec Version | Name                 | Length | Value  | Description   |
|--------|--------------|----------------------|--------|--------|---|
| 0Fh    | 2.1+         | Device Error Address | DWORD  | Varies | The 32-bit physical address of the error relative to the start of the failing memory device, in bytes. If the address is unknown, this field contains 8000 0000h. |
| 13h    | 2.1+         | Error Resolution     | DWORD  | Varies | The range, in bytes, within which the error can be determined, when an error address is given. If the range is unknown, this field contains 8000 0000h.           |

### 3.3.19.1 Memory Error — Error Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                    |
|------------|----------------------------|
| 01h        | Other                      |
| 02h        | Unknown                    |
| 03h        | OK                         |
| 04h        | Bad read                   |
| 05h        | Parity error               |
| 06h        | Single-bit error           |
| 07h        | Double-bit error           |
| 08h        | Multi-bit error            |
| 09h        | Nibble error               |
| 0Ah        | Checksum error             |
| 0Bh        | CRC error                  |
| 0Ch        | Corrected single-bit error |
| 0Dh        | Corrected error            |
| 0Eh        | Uncorrectable error        |

### 3.3.19.2 Memory Error — Error Granularity

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                |
|------------|------------------------|
| 01h        | Other                  |
| 02h        | Unknown                |
| 03h        | Device level           |
| 04h        | Memory partition level |

### 3.3.19.3 Memory Error — Error Operation

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning       |
|------------|---------------|
| 01h        | Other         |
| 02h        | Unknown       |
| 03h        | Read          |
| 04h        | Write         |
| 05h        | Partial write |

### 3.3.20 Memory Array Mapped Address (Type 19)

This structure supports the population of the DMTFMemory Array Mapped Addresses group, as defined in the DMTF's `MASTER.MIF`. One structure is present for each contiguous address range described.

See also 3.3.17 *Physical Memory Array (Type 16)* on page 64, 3.3.18 *Memory Device (Type 17)* on page 66, and 3.3.21 *Memory Device Mapped Address (Type 20)* on page 72.

| Offset | Spec Version | Name                | Length | Value  | Description  |
|--------|--------------|---------------------|--------|--------|--|
| 00h    | 2.1+         | Type                | BYTE   | 19     | Memory Array Mapped Address indicator  |
| 01h    | 2.1+         | Length              | BYTE   | 0Fh    | Length of the structure.   |
| 02h    | 2.1+         | Handle              | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | 2.1+         | Starting Address    | DWORD  | Varies | The physical address, in kilobytes, of a range of memory mapped to the specified <i>Physical Memory Array</i> .  |
| 08h    | 2.1+         | Ending Address      | DWORD  | Varies | The physical ending address of the last kilobyte of a range of addresses mapped to the specified <i>Physical Memory Array</i> .  |
| 0Ch    | 2.1+         | Memory Array Handle | WORD   | Varies | The handle, or instance number, associated with the <i>Physical Memory Array</i> to which this address range is mapped. Multiple address ranges can be mapped to a single <i>Physical Memory Array</i> . |
| 0Eh    | 2.1+         | Partition Width     | BYTE   | Varies | Identifies the number of <i>Memory Devices</i> that form a single row of memory for the address partition defined by this structure.   |

### 3.3.21 Memory Device Mapped Address (Type 20)

This structure supports the population of the DMTF|Memory Device Mapped Addresses group, as defined in the DMTF's `MASTER.MIF`. One structure is present for each contiguous address range described.

See also 3.3.17 *Physical Memory Array (Type 16)* on page 64, 3.3.18 *Memory Device (Type 17)* on page 66, and 3.3.20 *Memory Array Mapped Address (Type 19)* on page 71.

| Offset | Spec Version | Name                               | Length | Value  | Description   |
|--------|--------------|------------------------------------|--------|--------|---|
| 00h    | 2.1+         | Type                               | BYTE   | 20     | Memory Device Mapped Address indicator  |
| 01h    | 2.1+         | Length                             | BYTE   | 13h    | Length of the structure.  |
| 02h    | 2.1+         | Handle                             | WORD   | Varies | The handle, or instance number, associated with the structure.  |
| 04h    | 2.1+         | Starting Address                   | DWORD  | Varies | The physical address, in kilobytes, of a range of memory mapped to the referenced <i>Memory Device</i> .  |
| 08h    | 2.1+         | Ending Address                     | DWORD  | Varies | The physical ending address of the last kilobyte of a range of addresses mapped to the referenced <i>Memory Device</i> .  |
| 0Ch    | 2.1+         | Memory Device Handle               | WORD   | Varies | The handle, or instance number, associated with the <i>Memory Device</i> structure to which this address range is mapped. Multiple address ranges can be mapped to a single <i>Memory Device</i> .  |
| 0Eh    | 2.1+         | Memory Array Mapped Address Handle | WORD   | Varies | The handle, or instance number, associated with the <i>Memory Array Mapped Address</i> structure to which this device address range is mapped. Multiple address ranges can be mapped to a single <i>Memory Array Mapped Address</i> .   |
| 10h    | 2.1+         | Partition Row Position             | BYTE   | Varies | Identifies the position of the referenced <i>Memory Device</i> in a row of the address partition. For example, if two 8-bit devices form a 16-bit row, this field's value will be either 1 or 2.<br><br>The value 0 is reserved; if the position is unknown, the field contains FFh.  |
| 11h    | 2.1+         | Interleave Position                | BYTE   | Varies | The position of the referenced <i>Memory Device</i> in an interleave. The value 0 indicates non-interleaved, 1 indicates first interleave position, 2 the second, and so on. If the position is unknown, the field contains FFh.<br><br>For example: in a 2:1 interleave, the value 1 indicates the device in the 'even' position; in a 4:1 interleave, the value 1 indicates the first of four possible positions. |



| Offset | Spec Version | Name                   | Length | Value  | Description   |
|--------|--------------|------------------------|--------|--------|---|
| 12h    | 2.1+         | Interleaved Data Depth | BYTE   | Varies | <p>The maximum number of consecutive rows from the referenced <i>Memory Device</i> that are accessed in a single interleaved transfer. If the device is not part of an interleave, the field contains 0; if the interleave configuration is unknown, the value is FFh.</p> <p>For example, if a device transfers two rows each time it is read, its <i>Interleaved Data Depth</i> is set to 2. If that device is 2:1 interleaved and in Interleave Position 1, the rows mapped to that device are 1, 2, 5, 6, 9, 10, etc.</p> |

### 3.3.22 Built-in Pointing Device (Type 21)

This structure supports the population of the DMTF Pointing Device group, as defined in the *DMTF Mobile Supplement to Standard Groups, v1.0* and describes the attributes of the built-in pointing device for the system — the presence of this structure does not imply that the built-in pointing device is active for the system's use!

| Offset | Spec Version | Name              | Length | Value  | Description  |
|--------|--------------|-------------------|--------|--------|--|
| 00h    | 2.1+         | Type              | BYTE   | 21     | Built-in Pointing Device indicator   |
| 01h    | 2.1+         | Length            | BYTE   | 07h    | Length of the structure.   |
| 02h    | 2.1+         | Handle            | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | 2.1+         | Type              | BYTE   | ENUM   | The type of pointing device, see 3.3.22.1.   |
| 05h    | 2.1+         | Interface         | BYTE   | ENUM   | The interface type for the pointing device, see 3.3.22.2.  |
| 06h    | 2.1+         | Number of Buttons | BYTE   | Varies | The number of buttons on the pointing device. If the device has three buttons, the field value is 03h. |

### 3.3.22.1 Pointing Device — Type

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning     |
|------------|-------------|
| 01h        | Other       |
| 02h        | Unknown     |
| 03h        | Mouse       |
| 04h        | Track Ball  |
| 05h        | Track Point |
| 06h        | Glide Point |
| 07h        | Touch Pad   |

### 3.3.22.2 Pointing Device — Interface

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning                 |
|------------|-------------------------|
| 01h        | Other                   |
| 02h        | Unknown                 |
| 03h        | Serial                  |
| 04h        | PS/2                    |
| 05h        | Infrared                |
| 06h        | HP-HIL                  |
| 07h        | Bus mouse               |
| 08h        | ADB (Apple Desktop Bus) |
| A0h        | Bus mouse DB-9          |
| A1h        | Bus mouse micro-DIN     |
| A2h        | USB                     |

## 3.3.23 Portable Battery (Type 22)

This structure supports the population of the [DMTF|Portable Battery](#) group, as defined in the *DMTF Mobile Supplement to Standard Groups, v1.0* and describes the attributes of the portable battery(s) for the system. The structure contains the static attributes for the group. Each structure describes a single battery pack's attributes.

| Offset | Spec Version | Name         | Length | Value  | Description  |
|--------|--------------|--------------|--------|--------|--|
| 00h    | 2.1+         | Type         | BYTE   | 22     | Portable Battery indicator   |
| 01h    | 2.1+         | Length       | BYTE   | 1Ah    | Length of the structure.   |
| 02h    | 2.1+         | Handle       | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | 2.1+         | Location     | BYTE   | STRING | The number of the string that identifies the location of the battery, e.g. "in the back, on the left-hand side." |
| 05h    | 2.1+         | Manufacturer | BYTE   | STRING | The number of the string that names the company that manufactured the battery.                                   |

| Offset | Spec Version | Name                          | Length | Value  | Description  |
|--------|--------------|-------------------------------|--------|--------|--|
| 06h    | 2.1+         | Manufacture Date              | BYTE   | STRING | The number of the string that identifies the date on which the battery was manufactured. V2.2+ implementations which use a Smart Battery will set this field to 0 (no string) to indicate that the <i>SBDS Manufacture Date</i> field contains the information.              |
| 07h    | 2.1+         | Serial Number                 | BYTE   | STRING | The number of the string that contains the serial number for the battery. V2.2+ implementations that use a Smart Battery will set this field to 0 (no string) to indicate that the <i>SBDS Serial Number</i> field contains the information.                                 |
| 08h    | 2.1+         | Device Name                   | BYTE   | STRING | The number of the string that names the battery device, e.g. "DR-36".  |
| 09h    | 2.1+         | Device Chemistry              | BYTE   | ENUM   | Identifies the battery chemistry, see 3.3.23.1. V2.2+ implementations that use a Smart Battery will set this field to 02h ( <i>Unknown</i> ) to indicate that the <i>SBDS Device Chemistry</i> field contains the information.   |
| 0Ah    | 2.1+         | Design Capacity               | WORD   | Varies | The design capacity of the battery in mWatt-hours. If the value is unknown, the field contains 0. For v2.2+ implementations, this value is multiplied by the <i>Design Capacity Multiplier</i> to produce the actual value.  |
| 0Ch    | 2.1+         | Design Voltage                | WORD   | Varies | The design voltage of the battery, in mVolts. If the value is unknown, the field contains 0.   |
| 0Eh    | 2.1+         | SBDS Version Number           | BYTE   | STRING | The number of the string that contains the <i>Smart Battery Data Specification</i> version number supported by this battery. If the battery does not support the function, no string is supplied.  |
| 0Fh    | 2.1+         | Maximum Error in Battery Data | BYTE   | Varies | The maximum error (as a percentage in the range 0 to 100) in the Watt-hour data reported by the battery, indicating an upper bound on how much additional energy the battery might have above the energy it reports having. If the value is unknown, the field contains FFh. |
| 10h    | 2.2+         | SBDS Serial Number            | WORD   | Varies | The 16-bit value that identifies the battery's serial number. This value, when combined with the Manufacturer, Device Name, and Manufacture Date will uniquely identify the battery. The <i>Serial Number</i> field must be set to 0 (no string) for this field to be valid. |

| Offset | Spec Version | Name                       | Length | Value  | Description   |
|--------|--------------|----------------------------|--------|--------|---|
| 12h    | 2.2+         | SBDS Manufacture Date      | WORD   | Varies | The date the cell pack was manufactured, in packed format:<br>Bits 15:9      Year, biased by 1980, in the range 0 to 127.<br>Bits 8:5        Month, in the range 1 to 12.<br>Bits 4:0        Date, in the range 1 to 31.<br>For example, 01 February 2000 would be identified as 0010 1000 0100 0001b (0x2841). The <i>Manufacture Date</i> field must be set to 0 (no string) to for this field to be valid. |
| 14h    | 2.2+         | SBDS Device Chemistry      | BYTE   | STRING | The number of the string that identifies the battery chemistry, e.g. "PbAc". The <i>Device Chemistry</i> field must be set to 02h ( <i>Unknown</i> ) for this field to be valid.  |
| 15h    | 2.2+         | Design Capacity Multiplier | BYTE   | Varies | The multiplication factor of the <i>Design Capacity</i> value and assures that the mWatt hours value does not overflow for SBDS implementations. The multiplier default is 1, SBDS implementations use the value 10 to correspond to the data as returned from the SBDS Function 18h.   |
| 16h    | 2.2+         | OEM-specific               | DWORD  | Varies | Contains OEM- or BIOS vendor-specific information.  |

### 3.3.23.1 Portable Battery — Device Chemistry

**Important Note:** Enumerated values are controlled by the DMTF, not this specification.

| Byte Value | Meaning              |
|------------|----------------------|
| 01h        | Other                |
| 02h        | Unknown              |
| 03h        | Lead Acid            |
| 04h        | Nickel Cadmium       |
| 05h        | Nickel metal hydride |
| 06h        | Lithium-ion          |
| 07h        | Zinc air             |
| 08h        | Lithium Polymer      |

### 3.3.24 System Reset (Type 23)

This structure supports the population of the DMTF System Reset group, as defined in the DMTF's MASTER.MIF and describes whether Automatic System Reset functions enabled (*Status*). If the system has a watchdog Timer and the timer is not reset (*Timer Reset*) before the *Interval* elapses, an automatic system reset will occur. The system will re-boot according to the *Boot Option*. This function may repeat until the *Limit* is reached, at which time the system will re-boot according to the *Boot Option at Limit*.

**Note:** This structure type was added for specification v2.2.

| Offset | Name           | Length | Value     | Description  |
|--------|----------------|--------|-----------|--|
| 00h    | Type           | BYTE   | 23        | System Reset indicator   |
| 01h    | Length         | BYTE   | 0Dh       | Length of the structure.   |
| 02h    | Handle         | WORD   | Varies    | The handle, or instance number, associated with the structure.   |
| 04h    | Capabilities   | BYTE   | Bit-field | Identifies the system reset capabilities for the system.<br>Bits 7:6 Reserved for future assignment via this specification, set to 00b.<br>Bit 5 System contains a watchdog timer, either True (1) or False (0).<br>Bits 4:3 <i>Boot Option on Limit</i> . Identifies the system action to be taken when the Reset Limit is reached, one of:<br>00b Reserved, do not use.<br>01b Operating system<br>10b System utilities<br>11b Do not reboot<br>Bits 2:1 <i>Boot Option</i> . Indicates the action to be taken following a watchdog reset, one of:<br>00b Reserved, do not use.<br>01b Operating system<br>10b System utilities<br>11b Do not reboot<br>Bit 0 <i>Status</i> . Identifies whether (1) or not (0) the system reset is enabled by the user. |
| 05h    | Reset Count    | WORD   | Varies    | The number of automatic system resets since the last intentional reset. A value of 0FFFFh indicates unknown.   |
| 07h    | Reset Limit    | WORD   | Varies    | The number of consecutive times the system reset will be attempted. A value of 0FFFFh indicates unknown.   |
| 09h    | Timer Interval | WORD   | Varies    | The number of minutes to use for the watchdog timer. If the timer is not reset within this interval, the system reset timeout will begin. A value of 0FFFFh indicates unknown.   |
| 0Bh    | Timeout        | WORD   | Varies    | Identifies the number of minutes before the reboot is initiated. It is used after a system power cycle, system reset (local or remote), and automatic system reset. A value of 0FFFFh indicates unknown.   |

### 3.3.25 Hardware Security (Type 24)

This structure supports the population of the DMTF|Hardware Security group, as defined in the DMTF's MASTER.MIF and describes the system-wide hardware security settings.

**Note:** This structure type was added for specification v2.2.

| Offset | Name                       | Length | Value     | Description  |
|--------|----------------------------|--------|-----------|--|
| 00h    | Type                       | BYTE   | 24        | Hardware Security indicator  |
| 01h    | Length                     | BYTE   | 05h       | Length of the structure.   |
| 02h    | Handle                     | WORD   | Varies    | The handle, or instance number, associated with the structure.   |
| 04h    | Hardware Security Settings | BYTE   | Bit-field | Identifies the password and reset status for the system:<br>Bits 7:6 <i>Power-on Password Status</i> , one of:<br>00b    Disabled<br>01b    Enabled<br>10b    Not Implemented<br>11b    Unknown<br>Bits 5:4 <i>Keyboard Password Status</i> , one of:<br>00b    Disabled<br>01b    Enabled<br>10b    Not Implemented<br>11b    Unknown<br>Bits 3:2 <i>Administrator Password Status</i> , one of:<br>of:<br>00b    Disabled<br>01b    Enabled<br>10b    Not Implemented<br>11b    Unknown<br>Bits 1:0 <i>Front Panel Reset Status</i> , one of:<br>00b    Disabled<br>01b    Enabled<br>10b    Not Implemented<br>11b    Unknown |

### 3.3.26 System Power Controls (Type 25)

This structure supports the population of the DMTF System Power Controls group, as defined in the DMTF's `MASTER.MIF` and describes the attributes for controlling the main power supply to the system. Software that interprets this structure uses the month, day, hour, minute, and second values to determine the number of seconds until the next power-on of the system. The presence of this structure implies that a timed power-on facility is available for the system.

**Note:** This structure type was added for specification v2.2.

| Offset | Name                                 | Length | Value  | Description   |
|--------|--------------------------------------|--------|--------|---|
| 00h    | Type                                 | BYTE   | 25     | System Power Controls indicator   |
| 01h    | Length                               | BYTE   | 09h    | Length of the structure.  |
| 02h    | Handle                               | WORD   | Varies | The handle, or instance number, associated with the structure.  |
| 04h    | Next Scheduled Power-on Month        | BYTE   | Varies | Contains the BCD value of the month on which the next scheduled power-on is to occur, in the range 01h to 12h. See 3.3.26.1.        |
| 05h    | Next Scheduled Power-on Day-of-month | BYTE   | Varies | Contains the BCD value of the day-of-month on which the next scheduled power-on is to occur, in the range 01h to 31h. See 3.3.26.1. |
| 06h    | Next Scheduled Power-on Hour         | BYTE   | Varies | Contains the BCD value of the hour on which the next scheduled power-on is to occur, in the range 00h to 23h. See 3.3.26.1.         |
| 07h    | Next Scheduled Power-on Minute       | BYTE   | Varies | Contains the BCD value of the minute on which the next scheduled power-on is to occur, in the range 00h to 59h. See 3.3.26.1.       |
| 08h    | Next Scheduled Power-on Second       | BYTE   | Varies | Contains the BCD value of the second on which the next scheduled power-on is to occur, in the range 00h to 59h. See 3.3.26.1.       |

#### 3.3.26.1 System Power Controls — Calculating the Next Scheduled Power-on Time

The DMTF *System Power Controls* group contains a *Next Scheduled Power-on Time*, specified as the number of seconds until the next scheduled power-on of the system. Management software uses the date and time information specified in the associated SMBIOS structure to calculate the total number of seconds.

Any date or time field in the structure whose value is outside of the field's specified range does not contribute to the total-seconds count. For example, if the Month field contains the value 0xFF the next power-on is scheduled to fall within the next month, perhaps on a specific day-of-month and time.

### 3.3.27 Voltage Probe (Type 26)

This structure supports the population of the DMTF|Voltage Probe group, as defined in the DMTF's MASTER.MIF and describes the attributes for a voltage probe in the system. Each structure describes a single voltage probe.

**Note:** This structure type was added for specification v2.2.

| Offset | Name                | Length | Value     | Description  |
|--------|---------------------|--------|-----------|--|
| 00h    | Type                | BYTE   | 26        | Voltage Probe indicator  |
| 01h    | Length              | BYTE   | Varies    | Length of the structure, at least 14h.   |
| 02h    | Handle              | WORD   | Varies    | The handle, or instance number, associated with the structure.   |
| 04h    | Description         | BYTE   | STRING    | The number of the string that contains additional descriptive information about the probe or its location.   |
| 05h    | Location and Status | BYTE   | Bit-field | Defines the probe's physical location and status of the voltage monitored by this voltage probe. See 3.3.27.1.   |
| 06h    | Maximum Value       | WORD   | Varies    | The maximum voltage level readable by this probe, in millivolts. If the value is unknown, the field is set to 0x8000.  |
| 08h    | Minimum Value       | WORD   | Varies    | The minimum voltage level readable by this probe, in millivolts. If the value is unknown, the field is set to 0x8000.  |
| 0Ah    | Resolution          | WORD   | Varies    | The resolution for the probe's reading, in tenths of millivolts. If the value is unknown, the field is set to 0x8000.  |
| 0Ch    | Tolerance           | WORD   | Varies    | The tolerance for reading from this probe, in plus/minus millivolts. If the value is unknown, the field is set to 0x8000.  |
| 0Eh    | Accuracy            | WORD   | Varies    | The accuracy for reading from this probe, in plus/minus 1/100 <sup>th</sup> of a percent. If the value is unknown, the field is set to 0x8000.   |
| 10h    | OEM-defined         | DWORD  | Varies    | Contains OEM- or BIOS vendor-specific information.   |
| 14h    | Nominal Value       | WORD   | Varies    | The nominal value for the probe's reading in millivolts. If the value is unknown, the field is set to 0x8000. This field is present in the structure only if the structure's <i>Length</i> is larger than 14h. |

#### 3.3.27.1 Voltage Probe — Location and Status

**Important Note:** Each of the bit-field values map to enumerated values that are controlled by the DMTF, not this specification.

| Bit Range | Field Name | Value    | Meaning         |
|-----------|------------|----------|-----------------|
| 7:5       | Status     | 001..... | Other           |
|           |            | 010..... | Unknown         |
|           |            | 011..... | OK              |
|           |            | 100..... | Non-critical    |
|           |            | 101..... | Critical        |
|           |            | 110..... | Non-recoverable |
| 4:0       | Location   | ...00001 | Other           |



|          |                          |
|----------|--------------------------|
| ...00010 | Unknown                  |
| ...00011 | Processor                |
| ...00100 | Disk                     |
| ...00101 | Peripheral Bay           |
| ...00110 | System Management Module |
| ...00111 | Motherboard              |
| ...01000 | Memory Module            |
| ...01001 | Processor Module         |
| ...01010 | Power Unit               |
| ...01011 | Add-in Card              |

### 3.3.28 Cooling Device (Type 27)

This structure supports the population of the DMTF|Cooling Device group, as defined in the DMTF's MASTER.MIF and describes the attributes for a cooling device in the system. Each structure describes a single cooling device.

**Note:** This structure type was added for specification v2.2.

| Offset | Name                     | Length | Value     | Description  |
|--------|--------------------------|--------|-----------|--|
| 00h    | Type                     | BYTE   | 27        | Cooling Device indicator   |
| 01h    | Length                   | BYTE   | Varies    | Length of the structure, at least 0Ch.   |
| 02h    | Handle                   | WORD   | Varies    | The handle, or instance number, associated with the structure.   |
| 04h    | Temperature Probe Handle | WORD   | Varies    | The handle, or instance number, of the temperature probe (see 3.3.29 <i>Temperature Probe (Type 28)</i> on page 82) monitoring this cooling device. A value of 0xFFFF indicates that no probe is provided.   |
| 06h    | Device Type and Status   | BYTE   | Bit-field | Identifies the cooling device type and the status of this cooling device, see 3.3.28.1.  |
| 07h    | Cooling Unit Group       | BYTE   | Varies    | Identifies the cooling unit group to which this cooling device is associated. Multiple cooling devices in the same cooling unit implies a redundant configuration. The value is 00h if the cooling device is not a member of a redundant cooling unit, non-zero values imply redundancy and that at least one other cooling device will be enumerated with the same value. |
| 08h    | OEM-defined              | DWORD  | Varies    | Contains OEM- or BIOS vendor-specific information.   |
| 0Ch    | Nominal Speed            | WORD   | Varies    | The nominal value for the cooling device's rotational speed, in revolutions-per-minute (rpm). If the value is unknown or the cooling device is non-rotating, the field is set to 0x8000. This field is present in the structure only if the structure's <i>Length</i> is larger than 0Ch.  |

### 3.3.28.1 Cooling Device —Device Type and Status

**Important Note:** Each of the bit-field values map to enumerated values that are controlled by the DMTF, not this specification.

| Bit Range | Field Name  | Value    | Meaning                  |
|-----------|-------------|----------|--------------------------|
| 7:5       | Status      | 001..... | Other                    |
|           |             | 010..... | Unknown                  |
|           |             | 011..... | OK                       |
|           |             | 100..... | Non-critical             |
|           |             | 101..... | Critical                 |
|           |             | 110..... | Non-recoverable          |
| 4:0       | Device Type | ...00001 | Other                    |
|           |             | ...00010 | Unknown                  |
|           |             | ...00011 | Fan                      |
|           |             | ...00100 | Centrifugal Blower       |
|           |             | ...00101 | Chip Fan                 |
|           |             | ...00110 | Cabinet Fan              |
|           |             | ...00111 | Power Supply Fan         |
|           |             | ...01000 | Heat Pipe                |
|           |             | ...01001 | Integrated Refrigeration |
|           |             | ...10100 | Active Cooling           |
|           |             | ...10101 | Passive Cooling          |

### 3.3.29 Temperature Probe (Type 28)

This structure supports the population of the `DMTFTemperature Probe` group, as defined in the DMTF's `MASTER.MIF` and describes the attributes for a temperature probe in the system. Each structure describes a single temperature probe.

**Note:** This structure type was added for specification v2.2.

| Offset | Name                | Length | Value     | Description   |
|--------|---------------------|--------|-----------|---|
| 00h    | Type                | BYTE   | 28        | Temperature Probe indicator   |
| 01h    | Length              | BYTE   | Varies    | Length of the structure, at least 14h.  |
| 02h    | Handle              | WORD   | Varies    | The handle, or instance number, associated with the structure.  |
| 04h    | Description         | BYTE   | STRING    | The number of the string that contains additional descriptive information about the probe or its location.                            |
| 05h    | Location and Status | BYTE   | Bit-field | Defines the probe's physical location and the status of the temperature monitored by this temperature probe. See 3.3.29.1.            |
| 06h    | Maximum Value       | WORD   | Varies    | The maximum temperature readable by this probe, in 1/10 <sup>th</sup> degrees C. If the value is unknown, the field is set to 0x8000. |
| 08h    | Minimum Value       | WORD   | Varies    | The minimum temperature readable by this probe, in 1/10 <sup>th</sup> degrees C. If the value is unknown, the field is set to 0x8000. |
| 0Ah    | Resolution          | WORD   | Varies    | The resolution for the probe's reading, in 1/1000 <sup>th</sup> degrees C. If the value is unknown, the field is set to 0x8000.       |

| Offset | Name          | Length | Value  | Description  |
|--------|---------------|--------|--------|--|
| 0Ch    | Tolerance     | WORD   | Varies | The tolerance for reading from this probe, in plus/minus 1/10 <sup>th</sup> degrees C. If the value is unknown, the field is set to 0x8000.  |
| 0Eh    | Accuracy      | WORD   | Varies | The accuracy for reading from this probe, in plus/minus 1/100 <sup>th</sup> of a percent. If the value is unknown, the field is set to 0x8000.   |
| 10h    | OEM-defined   | DWORD  | Varies | Contains OEM- or BIOS vendor-specific information.   |
| 14h    | Nominal Value | WORD   | Varies | The nominal value for the probe's reading in 1/10 <sup>th</sup> degrees C. If the value is unknown, the field is set to 0x8000. This field is present in the structure only if the structure's <i>Length</i> is larger than 14h. |

### 3.3.29.1 Temperature Probe — Location and Status

**Important Note:** Each of the bit-field values map to enumerated values that are controlled by the DMTF, not this specification.

| Bit Range | Field Name | Value         | Meaning                  |
|-----------|------------|---------------|--------------------------|
| 7:5       | Status     | 001 . . . . . | Other                    |
|           |            | 010 . . . . . | Unknown                  |
|           |            | 011 . . . . . | OK                       |
|           |            | 100 . . . . . | Non-critical             |
|           |            | 101 . . . . . | Critical                 |
|           |            | 110 . . . . . | Non-recoverable          |
| 4:0       | Location   | . . . 00001   | Other                    |
|           |            | . . . 00010   | Unknown                  |
|           |            | . . . 00011   | Processor                |
|           |            | . . . 00100   | Disk                     |
|           |            | . . . 00101   | Peripheral Bay           |
|           |            | . . . 00110   | System Management Module |
|           |            | . . . 00111   | Motherboard              |
|           |            | . . . 01000   | Memory Module            |
|           |            | . . . 01001   | Processor Module         |
|           |            | . . . 01010   | Power Unit               |
|           |            | . . . 01011   | Add-in Card              |

### 3.3.30 Electrical Current Probe (Type 29)

This structure supports the population of the DMTF|Electrical Current Probe group, as defined in the DMTF's `MASTER.MIF` and describes the attributes for an electrical current probe in the system. Each structure describes a single electrical current probe.

**Note:** This structure type was added for specification v2.2.

| Offset | Name        | Length | Value  | Description  |
|--------|-------------|--------|--------|--|
| 00h    | Type        | BYTE   | 29     | Electrical Current Probe indicator   |
| 01h    | Length      | BYTE   | Varies | Length of the structure, at least 14h.   |
| 02h    | Handle      | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | Description | BYTE   | STRING | The number of the string that contains additional descriptive information about the probe or its location. |

| Offset | Name                | Length | Value  | Description   |
|--------|---------------------|--------|--------|---|
| 05h    | Location and Status | BYTE   | ENUM   | Defines the probe's physical location and the status of the current monitored by this current probe. See 3.3.30.1.  |
| 06h    | Maximum Value       | WORD   | Varies | The maximum current readable by this probe, in milliamps. If the value is unknown, the field is set to 0x8000.  |
| 08h    | Minimum Value       | WORD   | Varies | The minimum current readable by this probe, in milliamps. If the value is unknown, the field is set to 0x8000.  |
| 0Ah    | Resolution          | WORD   | Varies | The resolution for the probe's reading, in tenths of milliamps. If the value is unknown, the field is set to 0x8000.  |
| 0Ch    | Tolerance           | WORD   | Varies | The tolerance for reading from this probe, in plus/minus milliamps. If the value is unknown, the field is set to 0x8000.  |
| 0Eh    | Accuracy            | WORD   | Varies | The accuracy for reading from this probe, in plus/minus 1/100 <sup>th</sup> of a percent. If the value is unknown, the field is set to 0x8000.  |
| 10h    | OEM-defined         | DWORD  | Varies | Contains OEM- or BIOS vendor-specific information.  |
| 14h    | Nominal Value       | WORD   | Varies | The nominal value for the probe's reading in milliamps. If the value is unknown, the field is set to 0x8000. This field is present in the structure only if the structure's <i>Length</i> is larger than 14h. |

### 3.3.30.1 Current Probe — Location and Status

**Important Note:** Each of the bit-field values map to enumerated values that are controlled by the DMTF, not this specification.

| Bit Range | Field Name | Value    | Meaning                  |
|-----------|------------|----------|--------------------------|
| 7:5       | Status     | 001..... | Other                    |
|           |            | 010..... | Unknown                  |
|           |            | 011..... | OK                       |
|           |            | 100..... | Non-critical             |
|           |            | 101..... | Critical                 |
|           |            | 110..... | Non-recoverable          |
| 4:0       | Location   | ...00001 | Other                    |
|           |            | ...00010 | Unknown                  |
|           |            | ...00011 | Processor                |
|           |            | ...00100 | Disk                     |
|           |            | ...00101 | Peripheral Bay           |
|           |            | ...00110 | System Management Module |
|           |            | ...00111 | Motherboard              |
|           |            | ...01000 | Memory Module            |
|           |            | ...01001 | Processor Module         |
|           |            | ...01010 | Power Unit               |
|           |            | ...01011 | Add-in Card              |

### 3.3.31 Out-of-Band Remote Access (Type 30)

This structure supports the population of the [DMTF|Out-of-Band Remote Access](#) group, as defined in the DMTF's `MASTER.MIF` and describes the attributes and policy settings of a hardware facility that may be used to gain remote access to a hardware system when the operating system is not available due to power-down status, hardware failures, or boot failures.

**Note:** This structure type was added for specification v2.2.

| Offset | Name              | Length | Value     | Description   |
|--------|-------------------|--------|-----------|---|
| 00h    | Type              | BYTE   | 30        | Out-of-Band Remote Access indicator   |
| 01h    | Length            | BYTE   | 06h       | Length of the structure.  |
| 02h    | Handle            | WORD   | Varies    | The handle, or instance number, associated with the structure.  |
| 04h    | Manufacturer Name | BYTE   | STRING    | The number of the string that contains the manufacturer of the out-of-band access facility.   |
| 05h    | Connections       | BYTE   | Bit-field | Identifies the current remote-access connections:<br>Bits 7:2 Reserved for future definition by this specification, set to all zeros.<br>Bit 1 <i>Outbound Connection Enabled.</i> Identifies whether (1) or not (0) the facility is allowed to initiate outbound connections to contact an alert management facility when critical conditions occur.<br>Bit 0 <i>Inbound Connection Enabled.</i> Identifies whether (1) or not (0) the facility is allowed to initiate outbound connections to receive incoming connections for the purpose of remote operations or problem management |

### 3.3.32 Boot Integrity Services (BIS) Entry Point (Type 31)

Structure type 31 (decimal) is reserved for use by the Boot Integrity Services (BIS). Refer to the [Boot Integrity Services API Specification](#) for content details.

**Note:** This structure type was added for specification v2.3.

### 3.3.33 System Boot Information (Type 32)

The client system firmware, e.g. BIOS, communicates the *System Boot Status* to the client's Pre-boot Execution Environment (PXE) boot image or OS-present management application via this structure. When used in the PXE environment, for example, this code identifies the reason the PXE was initiated and can be used by boot-image software to further automate an enterprise's PXE sessions. For example, an enterprise could choose to automatically download a hardware-diagnostic image to a client whose reason code indicated either a firmware- or operating system-detected hardware failure.

**Note:** This structure type was added for specification v2.3.

| Offset | Name        | Length                    | Value  | Description   |
|--------|-------------|---------------------------|--------|---|
| 00h    | Type        | BYTE                      | 32     | System Boot Information structure identifier  |
| 01h    | Length      | BYTE                      | Varies | Length of the structure, in bytes; at least 0Bh.  |
| 02h    | Handle      | WORD                      | Varies |   |
| 04h    | Reserved    | 6 BYTES                   | 00h    | Reserved for future assignment via this specification, all bytes are set to 00h.                              |
| 0Ah    | Boot Status | <i>Length-10</i><br>Bytes | Varies | The Status and Additional Data fields that identify the boot status. See 3.3.33.1 for additional information. |

#### 3.3.33.1 System Boot Status

| Description  | Status  | Additional Data |
|--|---------|-----------------|
| No errors detected   | 0       | None            |
| No bootable media  | 1       | none            |
| The "normal" operating system failed to load.  | 2       | none            |
| Firmware-detected hardware failure, including "unknown" failure types.   | 3       | none            |
| Operating system-detected hardware failure. For ACPI OS's, the system firmware might set this reason code when the OS reports a boot failure via interfaces defined in the <i>Simple Boot Flag Specification</i> .   | 4       | none            |
| User-requested boot, usually via a keystroke   | 5       | none            |
| System security violation  | 6       | none            |
| Previously-requested image. This reason code allows a coordination between OS-present software and the OS-absent environment. For example, an OS-present application might enable (via a platform-specific interface) the system to boot to the PXE and request a specific boot-image. | 7       | varies          |
| A system watchdog timer expired, causing the system to reboot.   | 8       | none            |
| Reserved for future assignment via this specification.   | 9-127   | Varies          |
| Vendor/OEM-specific implementations. The Vendor/OEM identifier is the "Manufacturer" string found in the <i>System Identification</i> structure.   | 128-191 | Varies          |
| Product-specific implementations. The product identifier is formed by the concatenation of the "Manufacturer" and "Product Name" strings found in the <i>System Information</i> structure.   | 192-255 | Varies          |

### 3.3.34 64-bit Memory Error Information (Type 33)

This structure supports the population of the DMTF|Physical Memory Array and DMTF|Memory Device groups, as defined in the DMTF's `MASTER.MIF`, when the error address is above 4G (0xFFFFFFFF). The *Last Error Update* field, present in those groups, is not supplied in this structure since that field's attribute is known at the system-management application layer, not the BIOS.

**Note:** This structure type was added for specification v2.3.

| Offset | Name                       | Length | Value  | Description  |
|--------|----------------------------|--------|--------|--|
| 00h    | Type                       | BYTE   | 33     | 64-bit Memory Error Information type   |
| 01h    | Length                     | BYTE   | 1Fh    | Length of the structure.   |
| 02h    | Handle                     | WORD   | Varies | The handle, or instance number, associated with the structure.   |
| 04h    | Error Type                 | BYTE   | ENUM   | The type of error that is associated with the current status reported for the memory array or device. See 3.3.19.1 for definitions..   |
| 05h    | Error Granularity          | BYTE   | ENUM   | Identifies the granularity, e.g. device vs. Partition, to which the error can be resolved. See 3.3.19.2 for definitions.   |
| 06h    | Error Operation            | BYTE   | ENUM   | The memory access operation that caused the error. See 3.3.19.3 for definitions.   |
| 07h    | Vendor Syndrome            | DWORD  | Varies | The vendor-specific ECC syndrome or CRC data associated with the erroneous access. If the value is unknown, this field contains 0000 0000h.  |
| 0Bh    | Memory Array Error Address | QWORD  | Varies | The 64-bit physical address of the error based on the addressing of the bus to which the memory array is connected. If the address is unknown, this field contains 8000 0000 0000 0000h. |
| 13h    | Device Error Address       | QWORD  | Varies | The 64-bit physical address of the error relative to the start of the failing memory device, in bytes. If the address is unknown, this field contains 8000 0000 0000 0000h.              |
| 1Bh    | Error Resolution           | DWORD  | Varies | The range, in bytes, within which the error can be determined, when an error address is given. If the range is unknown, this field contains 8000 0000h.                                  |

### 3.3.35 Management Device (Type 34)

The information in this structure defines the attributes of a *Management Device*. A *Management Device* might control one or more fans or voltage, current, or temperature probes as defined by one or more *Management Device Component* structures — see 3.3.36 *Management Device Component (Type 35)* on page 88.

**Note:** This structure type was added for specification v2.3.

| Offset | Name   | Length | Value  | Description  |
|--------|--------|--------|--------|--|
| 00h    | Type   | BYTE   | 34     | Management Device indicator                                    |
| 01h    | Length | BYTE   | 0Bh    | Length of the structure.                                       |
| 02h    | Handle | WORD   | Varies | The handle, or instance number, associated with the structure. |

| Offset | Name         | Length | Value  | Description   |
|--------|--------------|--------|--------|---|
| 04h    | Description  | BYTE   | STRING | The number of the string that contains additional descriptive information about the device or its location. |
| 05h    | Type         | BYTE   | Varies | Defines the device's type, see 3.3.35.1   |
| 06h    | Address      | DWORD  | Varies | Defines the device's address  |
| 0Ah    | Address Type | BYTE   | Varies | Defines the type of addressing used to access the device, see 3.3.35.2.                                     |

### 3.3.35.1 Management Device — Type

| Byte Value | Meaning                     |
|------------|-----------------------------|
| 01h        | Other                       |
| 02h        | Unknown                     |
| 03h        | National Semiconductor LM75 |
| 04h        | National Semiconductor LM78 |
| 05h        | National Semiconductor LM79 |
| 06h        | National Semiconductor LM80 |
| 07h        | National Semiconductor LM81 |
| 08h        | Analog Devices ADM9240      |
| 09h        | Dallas Semiconductor DS1780 |
| 0Ah        | Maxim 1617                  |
| 0Bh        | Genesys GL518SM             |
| 0Ch        | Winbond W83781D             |
| 0Dh        | Holtek HT82H791             |

### 3.3.35.2 Management Device — Address Type

| Byte Value | Meaning  |
|------------|----------|
| 01h        | Other    |
| 02h        | Unknown  |
| 03h        | I/O Port |
| 04h        | Memory   |
| 05h        | SM Bus   |

## 3.3.36 Management Device Component (Type 35)

This structure associates a cooling device or environmental probe with structures that define the controlling hardware device and (optionally) the component's thresholds.

**Note:** This structure type was added for specification v2.3.

| Offset | Name                     | Length | Value  | Description   |
|--------|--------------------------|--------|--------|---|
| 00h    | Type                     | BYTE   | 35     | Management Device Component indicator   |
| 01h    | Length                   | BYTE   | 0Bh    | Length of the structure.  |
| 02h    | Handle                   | WORD   | Varies | The handle, or instance number, associated with the structure.  |
| 04h    | Description              | BYTE   | STRING | The number of the string that contains additional descriptive information about the component.  |
| 05h    | Management Device Handle | WORD   | Varies | The handle, or instance number, of the Management Device — see 3.3.35 <i>Management Device (Type 34)</i> on page 87 — that contains this component. |



| Offset | Name             | Length | Value  | Description   |
|--------|------------------|--------|--------|---|
| 07h    | Component Handle | WORD   | Varies | The handle, or instance number, of the probe or cooling device that defines this component. See 3.3.27 <i>Voltage Probe (Type 26)</i> on page 80, 3.3.28 <i>Cooling Device (Type 27)</i> on page 81, 3.3.29 <i>Temperature Probe (Type 28)</i> on page 82, and 3.3.30 <i>Electrical Current Probe (Type 29)</i> on page 83. |
| 09h    | Threshold Handle | WORD   | Varies | The handle, or instance number, associated with the device thresholds — see 3.3.37 <i>Management Device Threshold Data (Type 36)</i> on page 90. A value of 0FFFFh indicates that no <i>Threshold Data</i> structure is associated with this component.   |

### 3.3.37 Management Device Threshold Data (Type 36)

The information in this structure defines threshold information for a component (probe or cooling-unit) contained within a *Management Device*.

For each threshold field present in the structure:

- The threshold units (millivolts, milliamps, 1/10<sup>th</sup> degrees C, or RPMs) are as defined by the associated probe or cooling-unit component structure
- If the value is unavailable, the field is set to 0x8000.

**Note:** This structure type was added for specification v2.3.

| Offset | Name                              | Length | Value  | Description  |
|--------|-----------------------------------|--------|--------|--|
| 00h    | Type                              | BYTE   | 36     | Management Device Threshold Data structure indicator           |
| 01h    | Length                            | BYTE   | 10h    | Length of the structure.                                       |
| 02h    | Handle                            | WORD   | Varies | The handle, or instance number, associated with the structure. |
| 04h    | Lower Threshold – Non-critical    | WORD   | Varies | The lower non-critical threshold for this component            |
| 06h    | Upper Threshold – Non-critical    | WORD   | Varies | The upper non-critical threshold for this component            |
| 08h    | Lower Threshold – Critical        | WORD   | Varies | The lower critical threshold for this component                |
| 0Ah    | Upper Threshold – Critical        | WORD   | Varies | The upper critical threshold for this component                |
| 0Ch    | Lower Threshold – Non-recoverable | WORD   | Varies | The lower non-recoverable threshold for this component         |
| 0Eh    | Upper Threshold – Non-recoverable | WORD   | Varies | The upper non-recoverable threshold for this component         |

### 3.3.38 Inactive (Type 126)

This structure definition supports a system implementation where the SMBIOS structure-table is a superset of all supported system attributes and provides a standard mechanism for the system BIOS to signal that a structure is currently inactive and should not be interpreted by the upper-level software.

For example, a portable system might include *System Slot* structures that are reported only when the portable has docked. An undocked system would report those structures as *Inactive*. When the system was docked, the structure Type would be changed from *Inactive* to the *System Slot* equivalent by the system-specific software.

Upper-level software that interprets the SMBIOS structure-table should bypass an *Inactive* structure just like a structure type that the software does not recognize.

**Note:** This structure type was added for specification v2.2.

| Offset | Name   | Length | Value  | Description  |
|--------|--------|--------|--------|--|
| 00h    | Type   | BYTE   | 126    | Inactive structure indicator                                   |
| 01h    | Length | BYTE   | Varies | Length of the structure.                                       |
| 02h    | Handle | WORD   | Varies | The handle, or instance number, associated with the structure. |

### 3.3.39 End-of-Table (Type 127)

This structure type identifies the end of the structure table, that might be earlier than the last byte within the buffer specified by the structure. To ensure backward compatibility with management software written to previous versions of this specification, a system implementation should use the end-of-table indicator in a manner similar to the *Inactive (Type 126)* structure type — the structure table is still reported as a fixed-length and the entire length of the table is still indexable. If the end-of-table indicator is used in the last physical structure in a table, the field's length is encoded as 4.

**Note:** This structure type was added for specification v2.2.

| Offset | Name   | Length | Value  | Description  |
|--------|--------|--------|--------|--|
| 00h    | Type   | BYTE   | 127    | End-of-table indicator.  |
| 01h    | Length | BYTE   | Varies | Length of the structure.                                       |
| 02h    | Handle | WORD   | Varies | The handle, or instance number, associated with the structure. |

# Appendices

## 4. Structure Checklist

### 4.1 Correlation to DMTF Groups

This checklist identifies which System Management BIOS structures are needed to populate DMTF groups required by DMI 2.0 (per *DMTF Desktop Management Interface (DMI) 2.0 Conformance Requirements*, Version 1.0).

| Structure Type                            | Needed for DMTF DMI 2.0   | DMTF Group Required | DMTF Group Supported                                      |
|---|---|---------------------|---|
| BIOS Information (Type 0)                 | Recommended   | Yes                 | DMTF System BIOS 001                                      |
| System Information (Type 1)               | Recommended   | Yes                 | DMTF ComponentID 001                                      |
| Base Board Information (Type 2)           | Optional  |                     |   |
| System Enclosure or Chassis (Type 3)      | Recommended   | Yes                 | DMTF Physical Container Global Table 001                  |
| Processor Information (Type 4)            | Recommended, one entry per processor socket                       | Yes                 | DMTF Processor 003  |
| Memory Controller Information (Type 5)    | Optional, types 16 and 17 preferred                               |                     |   |
| Memory Module Information (Type 6)        | Optional, types 16 and 17 preferred                               |                     |   |
| Cache Information (Type 7)                | Recommended, one entry per external processor cache at a minimum. | Yes                 | DMTF System Cache 002                                     |
| Port Connector Information (Type 8)       | Recommended   |                     |   |
| System Slots (Type 9)                     | Recommended   | Yes                 | DMTF System Slots 003                                     |
| On Board Devices Information (Type 10)    | Optional  |                     |   |
| OEM Strings (Type 11)                     | Optional  |                     |   |
| System Configuration Options (Type 12)    | Optional  |                     |   |
| BIOS Language Information (Type 13)       | Optional  |                     |   |
| Group Associations (Type 14)              | Optional  |                     |   |
| System Event Log (Type 15)                | Recommended   |                     |   |
| Physical Memory Array (Type 16)           | Recommended   | Yes                 | DMTF Physical Memory Array 001                            |
| Memory Device (Type 17)                   | Recommended   | Yes                 | DMTF Memory Device 001                                    |
| 32-bit Memory Error Information (Type 18) | Recommended, if a memory-related error occurred                   |                     | DMTF Physical Memory Array 001 and DMTF Memory Device 001 |
| Memory Array Mapped Address (Type 19)     | Recommended   | Yes                 | DMTF Memory Array Mapped Addresses 001                    |
| Memory Device Mapped Address (Type 20)    | Recommended   | Yes                 | DMTF Memory Device Mapped Addresses 001                   |
| Built-in Pointing Device (Type 21)        | Recommended for portable systems                                  | Mobile              | DMTF Pointing Device 001                                  |
| Portable Battery (Type 22)                | Recommended for portable systems.                                 | Mobile              | DMTF Portable Battery 001                                 |
| System Reset (Type 23)                    | Recommended <sup>5</sup>  |                     | DMTF System Reset 001                                     |
| Hardware Security (Type 24)               | Recommended <sup>5</sup>  |                     | DMTF Physical Hardware Security 001                       |
| System Power Controls (Type 25)           | Recommended <sup>5</sup>  |                     | DMTF System Power Controls 001                            |
| Voltage Probe (Type 26)                   | Recommended <sup>5</sup>  |                     | DMTF Voltage Probe 001                                    |
| Cooling Device (Type 27)                  | Recommended <sup>5</sup>  | Server              | DMTF Cooling Device 001                                   |

<sup>5</sup> If the feature is present in the system.

| Structure Type                                      | Needed for DMTF DMI 2.0                            | DMTF Group Required | DMTF Group Supported   |
|---|--|---------------------|--|
| Temperature Probe (Type 28)                         | Recommended <sup>5</sup>                           |                     | DMTF Temperature Probe 001   |
| Electrical Current Probe (Type 29)                  | Recommended <sup>5</sup>                           |                     | DMTF Electrical Current Probe 001  |
| Out-of-Band Remote Access (Type 30)                 | Recommended <sup>5</sup>                           |                     | DMTF Out-of-Band Remote Access 001   |
| Boot Integrity Services (BIS) Entry Point (Type 31) | N/A  | N/A                 | N/A  |
| System Boot Information (Type 32)                   | N/A  | N/A                 | N/A  |
| 64-bit Memory Error Information (Type 33)           | Recommended, if a memory-related error occurred    |                     | DMTF Physical Memory Array 001 and DMTF Memory Device 001  |
| Management Device (Type 34)                         | Recommended  |                     | DMTF Voltage Probe 001, DMTF Cooling Device 001, DMTF Temperature Probe 001, DMTF Electrical Current Probe 001 |
| Management Device Component (Type 35)               | Recommended  |                     | DMTF Voltage Probe 001, DMTF Cooling Device 001, DMTF Temperature Probe 001, DMTF Electrical Current Probe 001 |
| Management Device Threshold Data (Type 36)          | Recommended  |                     | DMTF Voltage Probe 001, DMTF Cooling Device 001, DMTF Temperature Probe 001, DMTF Electrical Current Probe 001 |
| Inactive (Type 126)                                 | Optional, use as needed                            |                     |  |
| End-of-Table (Type 127)                             | Required for SMBIOS 2.2 and later implementations. |                     |  |

## 4.2 Conformance Guidelines

The following describes the conformance requirements for an SMBIOS v2.3 or later implementation.

1. The table anchor string "\_SM\_" is present in the address range 0xF0000 to 0xFFFFF on a 16-byte boundary.
2. Table entry-point verification:
  - 2.1. The Entry Point Length field value is at least 0x1F.
  - 2.2. The entry-point checksum evaluates to 0.
  - 2.3. The SMBIOS Version (Major.Minor) is at least 2.3.
  - 2.4. The Intermediate Anchor String is "\_DMI\_"
  - 2.5. The intermediate checksum evaluates to 0.
3. The structure-table is traversable and conforms to the entry-point specifications:
  - 3.1. The structure-table's linked-list is traversable within the length and structure-count bounds specified by the entry-point structure.
  - 3.2. The overall size of the structure table is less than or equal to the Structure Table Length specified by the entry-point structure.
  - 3.3. Each structure's length must be at least 4 (the size of a structure header).
  - 3.4. No structure handle number is repeated.
  - 3.5. The last structure is the end-of-table (0x7F).
  - 3.6. The number of structures found within the table equals the Number of SMBIOS Structures field present in the entry-point.
  - 3.7. The maximum structure size (formatted area plus its string-pool) is less than or equal to the Maximum Structure Size specified by the entry-point.
4. Required structures and corresponding data are present, see 3.2 *Required Structures and Data* on page 27:

- 4.1. BIOS Information (Type 0)
  - 4.1.1. One and only one structure of this type is present.
  - 4.1.2. The structure Length field is at least 13h
  - 4.1.3. BIOS Version string is present and non-null
  - 4.1.4. BIOS Release Date string is present, non-null, and includes a 4-digit year.
  - 4.1.5. BIOS Characteristics: bits 3:0 are all 0, at least one of bits 31:4 is set to 1.
- 4.2. System Information (Type 1)
  - 4.2.1. One and only one structure of this type is present.
  - 4.2.2. The structure Length field is at least 19h.
  - 4.2.3. Manufacturer string is present and non-null
  - 4.2.4. Product Name string is present and non-null
  - 4.2.5. UUID field is neither 00000000 00000000 nor FFFFFFFF FFFFFFFF.
  - 4.2.6. Wake-up Type field is neither 00h (Reserved) nor 02h (Unknown).
- 4.3. System Enclosure (Type 3)
  - 4.3.1. One or more structure of this type is present.
  - 4.3.2. The structure length is at least 0Dh.
  - 4.3.3. Manufacturer string is present and non-null in each structure.
  - 4.3.4. Type field is neither 00h (Reserved) nor 02h (Unknown)
- 4.4. Processor Information (Type 4)
  - 4.4.1. The number of structures defines the maximum number of processors supported by the system; at least one structure with a Processor Type field of "Central Processor" must be present.
  - 4.4.2. Each structure's length is at least 20h.
  - 4.4.3. Socket Designation string is present and non-null
  - 4.4.4. Processor Type field is neither 00h (Reserved) nor 02h (Unknown)
  - 4.4.5. (\*)Processor Family field is neither 00h (Reserved) nor 02h (Unknown)
  - 4.4.6. (\*)Processor Manufacturer string is present and non-null
  - 4.4.7. Max Speed field is non-0.
  - 4.4.8. (\*)CPU Status sub-field of the Status field is not 0 (Unknown)
  - 4.4.9. Processor Upgrade field is neither 00h (Reserved) nor 02h (Unknown)
  - 4.4.10. Lx (x=1,2,3) Cache Handle fields, if not set to 0xFFFF, reference Cache Information (Type 7) structures.

*Note:* Fields preceded by (\*) are only checked if the CPU Socket Populated sub-field of the Status field is set to "CPU Populated".
- 4.5. Cache Information (Type 7)
  - 4.5.1. One structure is present for each external-to-the-processor cache.
  - 4.5.2. Each structure's Length is at least 13h.
  - 4.5.3. Socket Designation string is present and non-null if the cache is external to the processor (Location sub-field of Cache Configuration field is 01b).
  - 4.5.4. Operational Mode and Location sub-fields of the Cache Configuration field are not 11b (Unknown)

- 4.6. System Slots (Type 9)
  - 4.6.1. One structure is present for each upgradeable system slot.
  - 4.6.2. Each structure's Length is at least 0Dh.
  - 4.6.3. Slot Designation string is present and non-null.
  - 4.6.4. Slot Type is neither 00h (Reserved) nor 02h (Unknown).
  - 4.6.5. Slot Data Bus Width is neither 00h (Reserved) or 02h (Unknown)
  - 4.6.6. Current Usage is not set to 00h (Reserved). If the "Slot Type" provides device presence-detect capabilities, e.g. PCI or AGP, Current Usage is not set to 02h (Unknown).
  - 4.6.7. Slot ID is set to a meaningful value.
  - 4.6.8. Slot Characteristics 1, bit 0, is not set to 1.
- 4.7. Physical Memory Array (Type 16)
  - 4.7.1. At least one structure is present with "Use" set to 03h (System memory)
  - 4.7.2. Each structure's length is at least 0Fh.
  - 4.7.3. Location is neither 00h (Reserved) nor 02h (Unknown)
  - 4.7.4. Use is neither 00h (Reserved) nor 02h (Unknown).
  - 4.7.5. Memory Error Correction is neither 00h (Reserved) nor 02h (Unknown)
  - 4.7.6. Maximum Capacity is not set to 80000000h (Unknown)
  - 4.7.7. Number of Memory Devices is not 0 and equals the number of Memory Device (Type 17) structures that reference the handle of the Physical Memory Array structure.
- 4.8. Memory Device (Type 17)
  - 4.8.1. For each Physical Memory Array, there must be "Number of Memory Devices" Memory Device structures that map back (via Handle) to the referencing memory array. One structure is required for each socketed system-memory device, whether or not the socket is currently populated. If the system includes soldered-on system-memory, one additional structure is required to identify that memory device.
  - 4.8.2. Each structure's length is at least 15h.
  - 4.8.3. Memory Array Handle references a Physical Memory Device (Type 17) structure.
  - 4.8.4. Total Width is not 0FFFFh (Unknown) if the memory device is installed (Size is not 0).
  - 4.8.5. Data Width is not 0FFFFh (Unknown)
  - 4.8.6. Size is not 0FFFFh (Unknown)
  - 4.8.7. Form Factor is not 00h (Reserved) or 02h (Unknown)
  - 4.8.8. Device Set is not 0FFh (Unknown)
  - 4.8.9. Device Locator string is present and non-null.
- 4.9. Memory Array Mapped Address (Type 19)
  - 4.9.1. One structure is provided for each contiguous block of memory addresses mapped to a Physical Memory Array.
  - 4.9.2. Each structure's length is at least 0Fh.
  - 4.9.3. Ending Address value is higher in magnitude than the Starting Address value.
  - 4.9.4. Memory Array Handle references a Physical Memory Array (Type 17)
  - 4.9.5. Each structure's address range (Starting Address to Ending Address) is unique and non-overlapping.
  - 4.9.6. Partition Width is not 0.

- 4.10. Memory Device Mapped Address (Type 20)
  - 4.10.1. Sufficient structures are provided to provide device-level mapping to all address space defined by the Memory Array Mapped Address (Type 19) structures.
  - 4.10.2. Each structure's length is at least 13h.
  - 4.10.3. Ending Address value is higher in magnitude than the Starting Address value.
  - 4.10.4. Memory Device Handle references a Memory Device (Type 17) structure.
  - 4.10.5. Memory Array Mapped Address Handle references a Memory Array Mapped Address (Type 19) structure.
  - 4.10.6. Partition Row Position value is not 0 (Reserved), 0FFh (Unknown), or greater than the Partition Width field of the referenced Memory Array Mapped Address structure.
  - 4.10.7. Interleave Position is not 0FFh (Unknown)
  - 4.10.8. Interleaved Data Depth is not 0FFh (Unknown)
- 4.11. Boot Integrity Services (BIS) Entry Point (Type 31). This structure is optional, but if it is present the following checks are performed:
  - 4.11.1. The structure's length is at least 1Ch.
  - 4.11.2. The structure-level checksum evaluates to 00h.
  - 4.11.3. 16-bit Entry Point is not 0.
  - 4.11.4. 32-bit Entry Point is not 0.
- 4.12. System Boot Information (Type 32)
  - 4.12.1. One and only one structure of this type is present.
  - 4.12.2. The structure's length is at least 0Bh.



## 5. Using the Table Convention

This section contains pseudo-code that describes the method that application software can use to parse the table-based SMBIOS structures. The example searches for the first structure of the type specified, returning the handle of the structure found or 0xFFFF if no structure of the type was found in the list. *TableAddress* and *StructureCount* values are those previously found by locating the Table Entry Point structure in low memory.

```
typedef unsigned short ushort;
typedef unsigned char uchar;
typedef struct
{
    uchar Type;
    uchar Length;
    ushort Handle;
} HEADER;

ushort FindStructure( char *TableAddress, ushort StructureCount, uchar Type )
{
    ushort i, handle;
    uchar lasttype;

    i = 0;
    handle = 0xFFFF;

    while( i < StructureCount && handle == 0xFFFF )
    {
        i++;
        lasttype = ((HEADER *)TableAddress)->Type;
        if( lasttype == Type )
        {
            handle = ((HEADER *)TableAddress)->Handle;
        } /* Found first structure of the requested type */
        else
        {
            TableAddress += ((HEADER *)TableAddress)->Length;
            while( *((int *)TableAddress) != 0 )
            {
                TableAddress++;
            } /* Get past trailing string-list */

            TableAddress += 2;
        } /* Increment address to start of next structure */
    } /* END while-loop looking for structure type */

    return handle;
} /* END FindStructure */
```